Fairbanks-Morse Marine Engines



Cape Town Harbor, South Africa Fishing Boat powered with a 7½ H. P. Fairbanks-Morse Single-Cylinder, Two-Cycle, Type "K" Marine Engine

Are Used All Over The World

FAIRBANKS, MORSE & CO.

Chicago, Ill. St. Louis, Mo. Cleveland, Ohio Atlanta, Ga. Jacksonville, Fla. New Orleans, La. New York, N. Y. Springfield, Mass. Baltimore, Md. Louisville, Ky. Detroit, Mich. Cincinnati, Ohio



St. Paul, Minn. Minneapolis, Minn. Kansas City, Mo. Omaha, Neb. Denver, Colo. Buenos Aires

San Francisco, Cal. Los Angeles, Cal. Spokane, Wash. Seattle, Wash. Portland, Oregon Salt Lake City, Utah London

The Canadian Fairbanks-Morse Co., Limited

Toronto Calgary Ottawa St. John, N. B. Winnipeg Hamilton Victoria Quebec Edmonton

Saskatoon


Vancouver

INSTRUCTIONS NO. 2145-G

FOR SETTING UP AND OPERATING


FAIRBANKS - MORSE


TYPE "E" AND TYPE "G" TWO-CYCLE GASOLINE MARINE ENGINES



FAIRBANKS, MORSE & CO.

SCALE APRIL 13-1908






Foundation Plan Fairbanks-Morse 34 H. P. Type "E" Marine Engine

NUMERICAL INDEX

INDITIONIN I IIII III III

				UNIERIOAL	TIADI	~	
	ymbol	Page	Symbol Pag	e Symbol	Page	Symbol Pa	ge Symbol Page
	3124X	14-18	G2587 1	4 A31836	18	R48450	19 R48897 19
	3167X	14-17	A2650 1	2 A31841	17	R48451	19 R48898 19
(3262X	14-18	A2651 1	2 A31842	17	R48452	19 R48900 18
(3336X	14-18	R2652 1	2 A31843	16	R48453	19 R48003 10
(3378X	17	A2654 1		18	R48470	10 DA9004 10
(3374	14-18	R2660 1		17	R48471	10000
(3918X	12	A2667 1	6 A31847	16	A48510	
(31319A	12	A2668 1	6 R31848		A48511	
	1132/A	18	A2670 1		17 17	R48512	16 A48907 19 16 A48908 19
-	71020A	14_18	A2671 1	6 A31856	16	A 49514	16 R48913 19
-	71004A	14-18 12 18 18 14-18	A2672 1 A2673 1	6 A31857	17	A48514 R48515	16 A48941 18
-	11200 X	18	G267312-1	4 A31858	17	A48525	17 R48944 19
-	31385X	16	A2674 1		17	A48526	17 R48945 19
(11386X	17	A2675 1		17	R48528	17 R48948 19
6	G1387X G1388X G1389X	17	A2676 1			R48529	17 R48949 19
(11388 X	18	R2677 1	8 R31871	18	A48532	18 A48951 14
(11389X	18	R2678 1	8 A31875	17	R48533	17 A48952 14
(31390X	18	A2706 1	9 R31921	17	A48543	16 A48953 14
A	1390	12	G3009 1	4 A31961	14	R48544	16 A48954 14
(1390 31392X	18	G3108 1	6 A31962	. 14	R48545	16 A48955 14
(31393X	18	G323614-1	7* A32060	17	R48546	16 R48956 14
A	1395	16	G3238 1		17	R48547	16 A48957 14
A	1396	16	G323912-1	7 A32073	17	A48548	16 R48958 14
A	1398 31398X	16	G324014-1	7 A32077	17	R48549	16 R4896014-17
(31398X	14	G324114-1	7 R44600	12-18	R48550	16 R48962 14
1	1401	18	G3242 1	6 R48189	19	A48551	16 A49075 14
(31401X	14-17	G324312-1	8 R48349	19	A48553	16 R49076 17
1	R 1402 G 1402 X	18	G3244 1 G3245 1		19 19	R48554	16 A49080 19 18 A49082 19
(31402X $31403X$	17	G324512-1	8 A48352	19	R48557	18 R49130 19
	31403X 31404X		G3248 1	6 A48353	19	R48558	18 A49132 19
6	G1405X	14	G324914-1	6 A48354	19	A48559	18 A49133 19
6	G1406X	12	G3250 1		19	R48560	18 A49134 19
. (G1407X	12	G3251 1	2 A48363	14	R48561	18 A49135 19
(31408X	14	G3252 1	2 A48364	14	R48562	18 A49136 19
(31409 X	12	G325314-1	6 A48365		R48566	16 R49137 19
C	31411X	14	G325414-1	6 A48366	12	R48572	17 R49138 19
(31412X	14	G325514-1	6 R48367	14	R48577	18 R49188 19
(31413X	14-16	G325614-1	6 R48368	14	A485/8	17 R49189 19
-	31414X	16	G325714-1	6 R48369	12	R48579	17 R49190 19
	31415X	16	G325814-1	6 R48372	12	R48580	17 R49192 19
	31416X	18	G325914-1	6 A48381	12	R48581	17 R49193 19
(31417X	18	G326014-1	6 A48382	12	R4858217-	-18 R49223 19
(31418X	18	G326114-1	6 R48383	12	A48583	18 A49224 19
(31428X	14	G326214-1	6 R48384	12	A48584	18 R49225 19 -18 R49226 19
	31430X	18	G326314-1	6 A48387	14-17	R4858512-	-18 R49226 19 18 A49234 19
,	31431X	18	G326414-1	6 A48388	14-17	R48586 R48602	18 A49234 19 18 R49235 19
-	1431 G1432X	19	G326514-1 G326614-1	7 R48389 7 R48390	14_17	R48603	18 R49236 19
1	1433	16	G326714-1	7 R48392	14-17	R48639	17 R49240 19
-	G1444X	17	G3268 1		14-17	R48640	16 R49245 12
(71452X	14-16	G327614-1	6 R48394	14-17	R48666	17 A49352 16
(31455X	12	G327714-1	6 R48396	14-17	R48667	17 A49398 17
(31456X	17	G327814-1		14	R4866812-	-18 A49401 17
(G1457X	17	G327914-1	6 R48398	14	R48670	16 R49405 17
(G1458X	17	G328014-1		17	R4869812-	-16 R49406 17
(31459X	17	G328114-1	6 A48400	14-17	R48699	16 A49408 17
(31460X	17	G328214-1	6 R48401	12-17	R48700	17 R49409 17
(G1461X	17	G328314-1	6 R48402	14	R4871814-	-17 A49410 17
(31462X	17	G3288 1	4 R48403	14	R48755	17 A49411 17
(31463X	17		4 R48404	14	A48787	14 A49412 17
	31464X		G3290		14 14	R48788 A48789	19 A49413 17 12 R49414 17
6	31799X	14-16	G3294 1 G3297 1		14	R48790	12 R49414 17 18 R49434 18
6	31799X	19	G329812-1	6 A48408	12	R48791	18 R49435 18
6	G1801X	19	G3299 1		12-18	R48793	16 R49436 18
(G1802X	19	G3300 1		12	R48848	18 A49446 19
(G1803X	19	G3301 1	4 R48413	14-18	R48849	18 A49464 17
. (31826	12	G339814-1	6 R48414		R48850	18 A49470 17
(31860X	14-18	G3690 1	4 R48415	14-18	R48851	18 R49471 16
(G1861X	14–18	G3691 1	4 R48416	14-18	R48852	18 A49472 16
(31862X	18	G377314-1	6 R48418	14	R48853	18 A49496 17
(31863X	18	G378714-1	b R48419	14-17	R48854	18 A49497 17
(32049	12	G378814-1	6 A48423		R48855	18 A49498 17
(32059X	16	G378914-1	6 A48424	14	R48856	18 A49499 17
(32060X	14-16	G379914-1	6 R48428	19	D40050	18 A49500 17
(72001X	14-16	G380014-1	6 A48429	19	R48858	18 A49500 17 19 R49501 17 19 R49502 17 19 R49503 17 18 A49504 17 18 A49505 17 19 R49507 17
(22002A	14-16	G380114-1	6 R48430	19 19	P48860	19 A49502 17 19 R49503 17
2	72064 X	14-16	G380214-1 G380314-1	6 R48431 6 A48432	19	A48861	18 A49504 17
(G2086X	17		8 A48438	19	A48862	18 A49505 17
6	G2087X	12		8 R48439	19	R48864	19 R49507 17
12	G2124X	14	G3868 1	6 R48440	19	R48865	19 R49577 17
	72125X	18	G3885.	8 R48441	19	R48866	19 R49610 17
- M. (32129X	17	G3885 1 A31807 1	2 A48442	19	R48867	19 R49611 17
(£2310	14-17	A31808 1	2 A48443	19	R48891	19 A49682 12
(G2313	16	R31809 1	4 R48444	. 19	R48892 R48893	19 R49683 17
(G2348	14-18	A31810 1	4 A48445	. 19	R48893	19 R49686 17
(32350	14-18		2 A48447	. 19	R48894	19 A410014 17
(32373	16-17-18		4 A48448	. 19	R48895	19 A410015 17
(x238U	14-17-18	A31814 1	9 R48449	. 19	R48896	19 R411267 16



Port Side—Type "G", 12 H. P., Double Cylinder—Fig. X1925

ANNOUNCEMENT

As our motors are used by people varying widely in mechanical ability, we have endeavored to make the following instructions clear, complete and simple, and to cover every question liable to arise in the installing, operating and maintenance of the motor, and at the same time to be understood clearly by a person of slight mechanical knowledge.

If, however, any additional information is desired, and if any instructions are not clear, we shall always be pleased to give further instruction.

Our motors are entirely beyond the experimental stage, and the methods herewith set forth we believe to be the best. We would suggest rigid compliance with them; but court correspondence with our customers, who may discover better means to the same end. We cannot, nor is it possible for any one to suggest quick and ingenious methods of repairing parts that may accidentally become broken. When an accident of this nature occurs it is best to order a new part at once.

In writing for supplies or repairs, always give letter and number of motor and refer to part broken or wanted by the number of the part. To avoid misunderstanding, we have established a rule requiring the return of the broken part, charges paid, claimed under our guarantee, that we may examine or determine if the claim is correct. We also, in order to save unnecessary book-keeping, send all repairs not replaced by us, C.O.D.

OPERATION OF FAIRBANKS-MORSE TWO-CYCLE ENGINES.

In the following pages we describe in detail the parts and construction of the Fairbanks-Morse Two-Two Types cycle, Three-port, Gasoline Marine Engines. These we build in two types, differing only in the method of "E" and "G" construction the reinvise of cycle, Three-port, Gasoline Marine Engines. construction, the principle of operation being exactly the same in each. The type "E" engine is made with a solid cylinder head, and is made in two sizes only. The type "G" engine is made with a removable cylinder head and in four sizes.

Two-Cycle Principle


The two-cycle type is the simplest so far developed in gas-engine practice, and owing to the fact that there is an impulse every revolution run with a minimum amount of vibration, this, coupled with the fact that there are no valves or complicated mechanism, makes the two-cycle engine preferable to the four-cycle for some

Three-port Design

We have adopted the three-port type, as tests made during the last few years have demonstrated that the three-port engine, when properly designed, is more economical, will run faster and develop more power than the type which has a check valve in the base; the clatter, wear and trouble from a rapidly moving check valve are also eliminated.

The principle of operation can be clearly seen by a reference to the sectional view of the engine.

When the piston moves upward, a charge of vaporized gasoline is drawn from the carburetor and enters Operation the crank chamber at the port "A." As the piston descends this vapor is compressed. (In the following pages note the length of the bearing especially designed to prevent leakage and consequent loss of fuel and power.) As the piston reaches the lower end of the stroke it uncovers the transfer port "B," allowing the compressed








Fig. ME2475

vapor to pass into the upper end of the cylinder "C." At the beginning of the upward stroke of the piston, the transfer port has closed, and the gas that is held in the cylinder is highly compressed. The gas is then ignited by an electric spark in the ignition chamber. The expansion caused by the ignition of this gas forces the piston downward, producing the working stroke. As the piston passes downward the exhaust port is uncovered and the burnt products are entirely exhausted from the cylinder. The momentum of the fly-wheel carries the piston upward and the cycle of operations is repeated.

INSTALLATION.

Keelson and Bilge Keelsons.

In constructing a power boat, a Keelson is usually notched over the ribs and bolted to the keel. In addition to this, bilge keelsons or stringers are recommended, one on either side, and running nearly parallel to the keelson.

These keelsons also should be notched to fit over and securely fastened to the ribs and planking. The Fasten keelsons, coming under the motor foundation timbers and over a number of ribs, distribute the strain over a large area and contribute largely to the stiffness of the structure.

The hole in the shaft log should be at least \(\frac{1}{4}\)" larger than the propeller shaft, otherwise the swelling of the wood may bind the propeller shaft, causing loss of power. Care should be taken to see that it is of such a pitch or angle that the propeller will be entirely submerged, and that no part of the motor bed or fly Hole wheel will come in contact or touch the inside of boat aside from the foundation timbers.

With a properly constructed dead-wood, there is no shaft hole lining needed except where the stuffing box is placed on the inside of the boat. With the last named arrangement a brass or iron tube may be used, the stuffing box fastened to the inboard end and the stern bearing to the outboard end.

The shaft hole being bored, stretch a fine line through the center of it; fasten the outboard end to a stick nailed to the stern of the boat; make the other end fast inside of the boat, go over the line carefully and see that it is in the exact center of the hole throughout the swing, and if the shaft hole has been properly bored, a plumb bob held beside the line should point to the center of the keelson, provided boat sits level.

The face of the stern post must be absolutely smooth and at exactly right angles with the line which has been stretched where the center of the shaft should be.

Foundation.

The foundation timbers should be securely fastened to keelsons at the given distance from the line, and Foundation at the same pitch or angle as the line.

These foundation timbers may run either athwart ship or fore and aft; in either case they must be securely fastened to every timber or plank over which they pass. The table of motor dimensions gives all necessary measurements, but it is well to check your measurements over when you receive the motor.

Place the motor on the foundation at the proper position fore and aft, and in line with the center of the The shaft now being in place, compare the faces of flange couplings and see that their faces come together fairly. The least variation at this point, if allowed to remain, will cause undue friction and heating.

With motor securely bolted down and faces of flanges on the coupling coming up perfectly fair, you may feel reasonably sure your motor and shaft are in line. This is important.

Stern Bearing and Stuffing Box.

Bolt the stern bearing to stern-post with a film of white lead between. See that the shaft turns perfectly Stern free after the stern bearing is fastened to place. If it binds the shaft, it would indicate that the face of the stern-post is not exactly at right angles to the shaft and must be dressed off until the shaft works freely.

If a log is used, the inside stuffing box is bolted to the inboard end, after having squared the end the same as described for the stern post. If the log is not used, a sleeve, one end of which screws into the stern bearing, long enough to extend into the boat far enough to admit of the stuffing box being screwed on the inboard end,

Bore Shaft

Stuffing Box

Line up Accurately

Face of Stern Post Smooth

Measurements

Place Motor

in Position Motor and Shaft in Line

Bearing

Inside

Reverse Gear

The Baldridge Gear Co., Detroit, Mich., will stand back of the Baldridge Reverse Gears, and take are of all complaints and difficulties in connection with their gears, if same is taken up with them direct by our customer.

Fresh or Piping. Salt Water Fitting

Use care in cutting threads on all pipe so that they will make up tight, using white lead on all joints of water and exhaust. When boat is to be used on salt water, all piping should be of brass or galvanized iron.

Exhaust Pipe

In piping for exhaust where elbows are necessary it is best to use 45 deg. elbows if possible. An exhaust pipe 5 to 6 feet in length will give best results.

and Bends

Exhaust Pipe

Be sure that exhaust piping is not arranged so that it fills with water, which may, by

Must not fill

of boat, come back into engine cylinder. Many cases of "hard to start" are directly traceable to water

with Water in cylinder resulting from disregard of above.

Make all pipe run as direct as possible, avoiding elbows and bends.

Tank

Expansion

If underwater exhaust is used an expansion tank (not a muffler) should be placed in exhaust pipe as near engine as possible. This expansion tank should be at least six times as large (cubic content) as cylinder for single cylinder engine, and larger for engines of more than one cylinder. A cock should be in exhaust pipe between engine and expansion tank to provide free opening to air for starting and backing.

to Pump

For the sea cock or intake to the pump, the pipe should have long running thread cut on the end intended Intake Pipe to go through the planking. The hole should be bored through the bottom of the boat small enough so that the pipe will screw tight into planking. Have a lock-nut both inside and out after the pipe is screwed through the planking far enough to admit of a full thread on the lock-nut outside. Put a few turns of white-leaded candle wicking under the lock-nuts, and screw down firmly, fastening the strainer scoop sent out with engine, over the end of the pipe, to keep all foreign matter out of the pump.

Water Scoop

The water scoop should be placed over the water intake pipe in such a position as to scoop the water to the pump when boat is going forward. If it is not so placed, the pump will not work. In case scoop becomes clogged with drift, leaves or sand, it can usually be freed by reversing the engine (if rotary pump is used) and connecting the water discharge pipe to the water with hose. This allows the pump to work backward, throwing a stream of water outward through screen, thus clearing it of obstruction. If plunger pump is used, the screen must be cleaned by hand.

Short Hose and never bent

If hose is used for intake connection to pump, the piece should be very short, and in no case should the hose serve as an elbow or bend. If it is bent or flattened the pump will not draw water through the hose.

Drain Crank Cases

We strongly recommend piping the engine so that crank cases can be readily drained. A tapped hole will be found in bottom of crank case. Pipe from this hole should be run to either end of engine and provided with pet cock. This enables draining of crank case without reaching under engine, or removing crank case covers.

Discharge above Water Line

The discharge from the water-jacket overboard should be above the water line if possible, and should be fastened as described above for the sea-cock pipe; all water pipe should be no smaller than the openings in or out of the motor for same.

Gasoline Tank.

Prevent Overflow of Gasoline Tank

The gasoline tank should be securely fastened in boat and placed high enough to insure a good flow of gasoline to carburetor. If tank is placed under the deck, a threaded filling pipe with deck plate attached should be screwed into tank, and securely fastened to deck so that there will be no leak of gasoline into boat if tank should overflow when filling.

Strain Gasoline

All gasoline put into tank should be strained through chamois skin, so no water or other foreign matter will pass through it.

Gasoline Pipe.

Copper Gasoline Pipe -Keep Clean

Gasoline pipe should be of seamless copper, and should be run from the tank to the carburetor as directly as possible along the keelson. See that the gasoline tank and pipe are thoroughly clean before making up. This should be done with either shellac or soap, care being taken that it is used only on outside threads, as there would be the danger of stopping gasoline flow.

Shut-off Cock for Gasoline

A strainer should be placed at outlet of tank to catch any dirt or scale, which might get into the gasoline pipe or carburetor. A shut-off cock should be placed at gasoline tank and another at carburetor.

Drain Muffler

The exhaust muffler is provided with a threaded pipe opening, which should have pipe connection to outboard to drain any excess of water from muffler. The muffler should be so placed that this drain will be at the lowest part and above the water line.

Water to Exhaust.

Cool Exhaust Pipe

On the Type "G" engines r rovision is made for allowing a quantity of water into exhaust piping. This should be just sufficient to keep exhaust pipe from getting too hot. Flooding exhaust with water will result in reduced speed.

Lubrication.

Where the engine shaft bearings are lubricated by grease cups these should be kept well filled. The Grease Cup handle should be screwed down a little when the engine is started and at such intervals while the engine is running as may be found necessary to keep the bearings in proper condition. As these bearings are fitted very close, it is best to lubricate them quite freely during the first few days the engine is in operation.


Good Quality Grease

Use a good quality of grease.

OILING SYSTEM, TYPE "E" ENGINE.

Fig. ME2446. "A." Oil cup with sight feed. ("B." Two-cylinder engine has one cup with two sight feeds.) "C." Oil enters cylinder here, thoroughly lubricating cylinder, the surplus is conducted by hollow pin "D" and through opening "E" in piston pin to upper connecting rod bearing and through tube "F" (which is fastened to connecting rod) to crank bearing "G." Surplus oil falls to bottom of crank case, where it is caught by scoop on bottom of connecting rod. The crank shaft bearings "H" and "H" are lubricated by grease cups "I" and "I." Only one oil cup to fill, only one to watch.

Oiling System Sight-feed Oil Cup and Grease Cups



OILING SYSTEM, TYPE "G" ENGINE.

Referring to figure ME2460, fill the reservoir "A" with a good quality gas-engine oil and screw filler cap downtight. The tube "B" connects upper part of oil reservoir with crank case, so that on first downward Oil forced by stroke of piston the crank case pressure is conducted to oil reservoir and pressure is maintained by check valve "C." The pressure in oil reservoir forces the oil up tube "D" to the sight feeds "E," where the rate of feed is regulated by thumb-nuts "F." From one of the sight feeds a tube conducts the oil to the cylinder at "G;" this lubricates the cylinder and (through hollow piston pin) the upper connecting-rod bearing "H."

One tube conducts oil from one of the sight feeds "E" to the crank case at "I." This tube projects into crank case, to allow the drip from it to be caught by the centrifugal ring oiler "J," which is connected to hole "K" drilled in crank shaft, "K" conducting oil directly to crank. Any surplus oil falls to bottom of crank case and is caught by oil scoop on bottom of connecting rod.

In engines of more than one cylinder the crank shaft bearings between crank cases are lubricated by oil, each having separate tube from sight feeds. The end bearings of all engines are lubricated by grease cups "L" and "L."

This system insures constant and thorough lubrication. It starts when the engine starts and stops when the engine stops. The oil is carried in one receptacle, which is a great improvement over the many oil

While the engine is new, allow the oiler to feed from fifteen to twenty drops a minute. This can be reduced after the engine has been in use for a short time.

Too much oil will foul the spark plugs. Too little oil will not give a free running engine.

Always use a good grade of gas engine cylinder oil.

Occasionally the worn oil in the base should be removed and replaced by fresh oil.

Oiling System for Type "G" Compression




Fig. ME2460-Type "G" Engine

MODEL "D"

Fig. ME2470-Model "D" Schebler Carburetor

SCHEBLER CARBURETOR.

Model "D" Carburetor is adjusted by the following method:

Engine under load is slowed down by nearly closing throttle "P" and retarding spark. The gasoline valve "E" is closed until engine runs without missing.

When the engine is running slow, all the air taken through carburetor goes through the fixed opening below valve "A" and to get the proper mixture gasoline is turned on at needle "E" to make the right propor- Increase tion of gasoline vapor. This will allow engine being slowed down and yet be perfectly reliable. When throttle Speed is opened and spark advanced, engine increases speed and causes a greater suction on valve "D." This increased suction also opens valve "A" and allows a greater supply of air, and if spring "O" is at the proper tension engine will get a perfect mixture at high speed and also at slow speed.

If, on high speed, engine shows signs of not getting enough gasoline, tighten spring "O" by screwing in Increase

Flooding of carburetor may be caused by dirt getting under valve "H." By pressing down priming pin a few times, this may be dislodged.


A small hole is drilled in carburetor below throttle to prevent an accumulation of gasoline in intake pipe.

Defective carburetors, or trouble with same, should be taken up directly with the manufacturers. If Excess Gasoline Schebler carburetor, the Wheeler & Schebler Co., Indianapolis, Ind., will make any adjustments, replace carburetor, fill orders for repair parts, etc., if addressed direct.

It is recommended that a pan be placed under carburetor to prevent any gasoline that might drip from Place Drip carburetor getting into bottom of boat. Gasoline leaks to bottom of boat from piping or carburetor should not be allowed for a moment.

To Slow

Dislodge Dirt



The jump spark, which is the most popular system, consists of six important parts: the battery, switch, Jump Spark coil, timer, spark plug and connecting wires.

The battery should be so located in a boat that it will be kept dry, and so that it will be easily accessible. All connections should be securely made. An ammeter for testing the cells is a good investment. Each cell when new will test 15 to 20 amperes, and should not be used when exhausted below 8 or 9 amperes. Bear in mind that the least amount of tension on vibrator spring results in the least consumption of electric current and lengthens the life of battery.

Spark Coil.

This consists of an iron core, a high tension winding, a low tension winding, a vibrator and suitable binding posts for the connecting wires. The wiring diagrams on the following pages show the method of wiring. The coil should be located in a dry place.

In connection with the vibrator there is an adjustment for varying the tension on the vibrator. Increasing this tension gives a larger current consumption and a larger spark. Less tension means less current consumption and a weaker spark. It is better to adjust the vibrator for the least tension at which the coil will give a strong enough spark to operate the engine without missing. This will give longer life to the battery. A higher voltage and small current consumption is better for the coil than a low voltage and larger current

Orders for repair parts, defective coils, or any complaint regarding same, should be referred directly to the Coil Manufacturers. They will cheerfully answer all correspondence, and make good any trouble with their coils.

Keep Coil Dry

Keep Battery

Adiust. Tension on Coil Vibrator

Wiring Diagram for 18 H. P. Type "G" Marine Engine

Froper
Installation,
Gasoline Supply, Piping,
Ignition and
Reverse Lever
Position

Retard the

Spark


10

Proper Starting the Engine.

We will assume that the engine is properly installed in the boat; that the gasoline tank has a supply of fuel free from dirt and sediment; that the gasoline pipes have been properly flushed out and are not filled with dirt that will clog the carburetor; the oil cups and grease cups are full; the batteries are in good shape, properly placed and wired; the coil is in proper adjustment and the switch is in a convenient place, and that the propeller reverse lever is in the neutral position.

Open valve in inlet pipe to the water pump. Screw down the grease cups a little. Open feed on cylinder oilers so that each will feed 15 to 20 drops a minute. See that the gasoline is turned on. Set the throttle of the carburetor about two-thirds open. Press down priming pin "V" a few seconds to allow a little gasoline to flow into carburetor intake. Close the switch. Fill the priming cup and allow the gasoline to pass into the cylinder

Retard the spark. (On Type "E" engines moving the timer lever to the left retards the spark. On Type "G" engines moving it to the right retards the spark.)



INSTRUCTIONS—FAIRBANKS-MORSE TWO-CYCLE MARINE ENGINES



Fig. Z1779A

Grasp the fly wheel, using the corrugations on the inside of flange, and move the fly wheel as you would in cranking, or rock the engine backward sharply against the compression; either way will start it. While we furnish a crank with the equipment, we strongly advise against its use, as a little practice will allow you to start much easier with the fly wheel, and this eliminates all danger from "kick-back."

On multi-cylinder engines, prime each cylinder and proceed in the same way.

Advance the ignition and open the throttle on the carburetor to increase the speed of the engine.

In speeding up it is preferable to advance the ignition and then increase the opening in the throttle of the carburetor.

In slowing down it is usually best to partly close the throttle and then retard the ignition by moving the timer handle to the left.

To Stop the Engine.

Open the switch. Close the oil cups and the valve in gasoline

To start again within an hour or so it is usually not necessary to use any gasoline in the priming cups, an explosive mixture having been left in the base of the engine when shutting down.

A little experience, remembering that a cold engine needs more gasoline and a warm engine less gasoline through the priming cups, will make starting very easy.

In cold weather we would recommend that a supply of warm air from the exhaust pipe be piped to the carburetor.

In the case of an engine having three or more cylinders, before stopping, if the engine is speeded up for a moment or so by opening throttle, and the switch thrown out, the engine can generally be started by throwing in the switch and moving the timer handle to late ignition and then advancing.

CAUTION.—The boat should never be cut loose until the motor is running, nor should the motor be stopped until the boat is secured to its moorings.

Locating Trouble.

If, after a proper trial, the motor fails to start, first of all examine the spark. If the jump spark is used, disconnect the wire and take out the spark plug. Reconnect the wire and lay the plug on the top of the cylinder, in such a position as to ground the metal part with the cylinder. Then turn the fly wheel until a circuit is formed when a spark should show between the points of the spark plug.

If make and break is used, test this by turning the engine over until the points or electrodes within the cylinder are brought into contact, then detach the wiring from the stationary electrodes and pass the end of the wire across its post and see if there is a spark. If the spark shows all right, turn the fly wheel until the electrodes are separated and try again the same way. This time there should not be any spark.

If no spark occurs with the jump spark, look over the insulation wires and spark coil and see that the coil is vibrating. Examine the insulation of the plug and see that same is not cracked; also that the inside of plug is clean and points not over $\frac{1}{3}$ inch apart.

If no spark occurs with the make and break, look over the insulation wires and all connections. See that no wire is broken under the insulation and that connections are firmly made.

Ascertain if the battery is weak. When a motor stops and refuses to start, in ninety-nine cases out of every hundred the trouble will be found to be in the spark. In the case of dry cells, a weak battery will sometimes recuperate and show a good spark, but this will not last. This often puzzles the amateur, as he will try the spark and apparently it will be all right, and on the other hand the motor will stop after making only a few revolutions. Therefore, when testing the spark for weakness, try it repeatedly for at least a minute to ascertain if the spark holds its strength. We would recommend an ammeter, which is the only satisfactory way of testing the condition of a dry cell battery.

Never add new battery cells to an old set of batteries to strengthen them, as one old weak cell will bring down the new ones to its strength or voltage.

If the spark and ignition are not at fault, then look into the mixture. This may be either too rich or too poor in gasoline. A mixture that is too rich will cause a smoky exhaust, resulting in fouling the cylinder, electrodes and valves. A mixture that is too poor will not ignite regularly and there is apt to be slow firing, which is one of the causes of back firing.

Commercial gasoline frequently contains water. Always strain through a chamois leather, which will prevent either dirt or water going into the tank.

If neither the mixture nor the ignition is at fault, look to the compression of the cylinder. If the cylinder leaks or loses its compression through a leak, it will result in a loss of power and may cause the motor to stop. A two cycle motor may leak past the piston if the rings become fouled or worn, or it may leak at the spark plug or in the base, any of which will cause a loss of compression.

It will sometimes happen that the flow of gasoline to the carburetor is interrupted by not having a proper vent in the tank. If this has not been provided for, it will be sufficient to unscrew the filler plug slightly at intervals.

Care of Engine During Winter.

Gasoline engines often suffer from neglect during the winter months, when their services are no longer required. They rust and corrode, when an hour put in as the launch is hauled out would leave the engine in such condition that in the spring wiping off with a cloth would remove all traces of the winter's idleness. As soon as cool weather sets in, the water should be drained off the engine each time it is used, so that there will be nothing to freeze and crack the cylinder. When launch is hauled out and engine is still in position, give it about a minute's run with plenty of lubricating oil, and with water connections broken and cocks open. This will dry out any water that may remain. Next coat all parts, except the brass work, with grease or oil—the ordinary lubricating oil will do. Wipe all brass clean and dry. Remove coil, spark plugs and dry cells from the launch and store in a dry place.

With these slight precautions, spring will find the engine in excellent condition.

Grasp Fly-wheel

11

y Fly-wheel

Start Engine

Increase Speed

Speeding up

Slowing Down

Shut off Switch, Oil and Gasoline To start again within an Hour Cold or Warm Engine

In Cold Weather To Start

on Spark

Darooy

Examine Spark
Plug in
"Jump
Spark"

Test Spark in "Make and Break"

Examine
wiring for
Jump Spark

Examine Wiring for Make and Break

Weak Battery

Never add New Cells to Old Set

Examine Gasoline and Air Mixture

Test Compression

Gasolina

Vent in Gasoline Tank Do not expose to Rust and Corrode Prevent Freezing in Cold Weather Coat Parts with Oil or Grease Store Coil, Cells and

Store Coil, Cells and Spark Plugs in Dry Place Excellent

Condition in Spring

Let us do the After considerable running there may be some slight repairs or adjustments to be made, in which case Overhauling ship the engine to us, and we will have it overhauled by our experts and carefully adjusted. The charges for Let us do the when any is this service are as low as is consistent with first class work. necessary

TO CALCULATE SPEED OF BOAT.

Measure Course Note Time

To find the speed of a boat over a course of known length, the following formula will be found useful:

A equals length of course.

B equals minutes in one hour.

Ascertain Speed

C equals minutes required to run the course.

Then A times B divided by C equals rate of speed per hour. For example, it is 2½ miles from your dock to a given point, and the boat makes the run in 8 minutes 45 seconds. What is the rate of speed per hour?

A equals 2½ miles, 2.25. B equals minutes in hour.

C equals run in minutes, 8.75. 2 25 times 60 equals 135.00, divided by 8.75, equals 15.43 (speed per hour).

Good Judgment, Care and Thought-

Thoroughly Understand your Motor

Keep Motor Perfectly Clean

Care and Attention to Motor

Conclusion and Final Admonition.

In conclusion we wish to say that a little good judgment, care and thoughtfulness on the part of the operator will do more to keep the motor in good working order than a book full of instructions. We do not claim that our motor will run itself, or keep forever in repair without attention.

It requires judgment, patience, and mechanical ability to run any piece of machinery. It is of great importance that the owners of motors should personally understand them thoroughly and be qualified to operate them without having to depend on an engineer entirely.

The motor should be kept perfectly clean, as nothing adds more to the looks and running qualities of a

motor than cleanliness.

We wish also to say to the purchasers and operators of our motors that success in producing good results would be to a mutual extent dependent, not only on the ability and accuracy of the motor, but also on care and attention exercised in the setting of the same in general, and in its several parts, as a motor, no matter how perfect, will do more or less work, good or bad, in proportion to the skill expended in setting and operating the

Don't try to start the motor with the switch off.

Don't try to start the motor without opening the gasoline valves.

Don't try to run with worn-out batteries.

Don't try to run with soot-fouled spark plugs. Don't crank your head off—look for the cause.

Don't cast off until you have the motor running.

Don't stop the engine until the boat is secured to its moorings. Don't forget to open the lubricators when the motor is started.

Don't forget to close the lubricators when the motor is stopped.

Don't forget to see that the pump is working.

Don't let the base of the motor get out of oil.

Don't get too much oil in the base of motor. Don't forget to oil the motor frequently.

Don't lorget to oil the motor frequently.

Don't use anything but gasoline cylinder oil in the motor.

Don't use more gasoline than the motor requires.

Don't forget to drain the motor in cold weather.

Don't forget to strain the gasoline when filling the tank.

Don't let batteries get wet.

Don't let wires come in contact with the motor.


Don't let wires run through bilge water.

Don't let wire connections and terminals get loose.

Don't forget that eighty-five per cent. of motor failures can be traced to electric trouble; either in the battery or the coil, or the wiring, or the plugs.

REPAIR PARTS FOR TYPE "E" TWO-CYCLE MARINE ENGINE

Name of Part	1 Cyl. 3½ H. P. Symbol.	2 Cyl. 7 H. P. Symbol.	Name of Part	1 Cyl. 3½ H. P. Symbol.	2 Cyl. 7 H. P. Symbol.
Cylinders.			Flywheel.	The state of the s	
Cylinder and upper base babbitted			Fly Wileel.	101011	101011
and with timer bushing	A2650	A1390	Flywheel	A31811	A31811
Cylinder hand hale plate	A48381		Flywheel key	G3239	G3239
Cylinder hand hole plate		A48381	Flywheel nut	R48401	R48401
Cylinder hand hole plate gasket	R48384	R48384	Flywheel with timer gear and screws	G1404X	G1404X
Cylinder hand hole plate cap screws.	G2673	G2673			
Lower half crank case babbitted	A2651	A2654	Thrust Bearing.		
Cylinder and lower half crank case			Ball thrust bearing comp., with ring		
cap screws, slotted	R49245	R49245	and collars	G1455X	G1455X
Cylinder and lower half crank case				CILLOUIL	G110011
cap screws, plain	G2049	G2049	Couplings.		
Inlet and exhaust flange	A48382	A48382	Coupling—engine end	A48366	A48366
Inlet and exhaust flange gasket	R48383	R48383	Coupling—engine end key	R48409	
Inlet and exhaust flange cap screws	G3251	G3251	Coupling—engine end key	R48409	R48409
Carburetor (1" Planhard)	G1319X	G1319X	Coupling—engine end set screw	G3243	G3243
Carburetor (1" Schebler)	G918X	G918X	Coupling—propeller end	A48365	A48365
Carburetor inlet pipe (Planhard)	A48789	A48789	Coupling—propeller end key	R48411	R48411
Carburetor inlet pipe (Schebler)	A49682	A49682	Coupling—propeller end set screw	G3252	G3252
Name plates	R48698	R48698	Coupling flange cap screws	G3246	G3246
Name plate screws		G3298	Pistons.		
Priming cups	G2087X		Pistons complete with rings, pins		
Drain cock	G1826	G1826	r istons complete with rings, pins	G1409X	C110037
Crank Shafts.	G1020	0 1020	and set screw		G1409X
			Piston body only	A31807	A31807
Crank shaft complete, with counter-	0140037	CHANNE	Piston rings each	A31808	A31808
weights and screws	G1406 X	G1407X	Piston pin	R48372	R48372
Crank shaft only	R2652	R2660	Piston pin set screw		R44600
Crank shaft counterweights	A48408	A48408	Piston pin bushing with dowel		R48369
Crank shaft counterweight screws	R48585	R48585	Piston ring dowel	R48668	R48668



REPAIR PARTS FOR TYPE "E" TWO-CYCLE MARINE ENGINE

ter and and	101011						
Name of Part	1 Cyl. 3½ H. P. Symbol.	2 Cyl. 7 H. P. Symbol.	Name of Part	1 Cyl. 3½ H. P. Symbol.	2 Cyl. 7 H. P. Symbol.		0
Connecting Rod.			Water Pump (Rotary).				
Connecting rod and cap complete			Water pump complete with inside				
with bushing eyebolt and nut, oil			gears and screws, shafts and nuts		G140177		
pipe, link and shims	G1405X	G1405X	and packing	G1401X A48387	G1401X A48387		
Connecting rod and cap only Connecting rod bushing upper half	R31809 R48367	R31809 R48367	Water pump body only	A48388	A48388		
Connecting rod bushing lower half	R48368	R48368	Water pump screws	G3241	G3241		
Connecting rod oil pipe	R48402	R48402	Water pump packing nut	R48389	R48389 R48390		
Connecting rod eyebolt	R48403 R48404	R48403 R48404	Water pump lock nut	R48390 R48394	R48394		
Connecting rod link	R48405	R48405	Water pump gears Water pump short gear shaft	R48392	R48392		
Connecting rod shims for 6	R48407	R48407	Water pump long gear shaft	R48393	R48393		
Connecting rod link and eyebolt pins	R48406	R48406	Water pump supporting stud and nut	R48396 A48397	R48396 A48397		
Bemus Timer used on part of engines for year of 1914.			Water pump pipe Water pump close nipple brass	G2310	G2310		
Bemus Timer.			Water pump gasket to cylinder	R48398	R48398		
Timer only, complete with main cast-			Water pump pinion on pump shaft Water pump pinion set screw	A48363 G3240	A 48363 G3240		
ing, handle with circuit breaker,			Water Pump Pipe, Screws, to Cylin-				
revolving center piece with collar			der	G3236	G3236		
and taper pin, fibre ring with contacts and cover	G2060X	G2061X	Water Scoop with Screen	A48400 A48364	A48400 A48364		
Timer main casting with handle and	G20002	G2001A	Water Pump Pinion on Engine Shaft. Water Pump Gear Shield	A31810	A31810		
circuit breaker	G2063X	G2063X	Water Pump Gear Shield Screws	G2380	G2380		
Timer revolving center piece with pin Timer collar for revolving center piece	G3787	G3787	Water Pump (Plunger)				
Timer collar taper pin	G3788 G3773	G3788 G3773	Water Pump, complete with Bracket			4	
Timer bevel contact roller	G3276	G3276	Pipe, Gasket and necessary Screws	CHANGE	C140037		
Timer bolt holding insulating ring	G3277	G3277	to attach to Engine	G1428X A31962	G1428X A31962		
Timer two-piece lock nut for cover Timer insulating ring only arranged	G3278	G3278	Water Pump Bracket	A31961	A31961		
for one contact socket	G3398		Water Pump Inlet Valve	R48958	R48958		
Timer insulating ring only arranged		Coore	Water Pump Outlet Valve	A48957 A48951	A48957 A48951		
for two contact socket Timer insulating ring contact com-		G3279	Water Pump Cap Water Pump Plug	R48960	R48960		
plete, consists of ball, socket,			Water Pump Plunger	A48952	A48952		124
spring and cap	G1452X	G1452X	Eccentric Strap, Upper Half	A48953 A48954	A48953 A48954		
Timer contact steel ball socket	G1607 G3280	G1607 G3280	Eccentric Strap, Lower Half		R48962	A LIKE Y	
Timer contact steel ball socket lock			Plunger Pin	R48956	R48956		
Timer contact steel ball socket cap	G3281	G3281	Eccentric	A48955 R48398	A48955 R48398		
nut	G3282	G3282	Bracket to Crank Case Screw (½"x¾").	G3301	G3301		
Timer contact steel ball spring	G3283	G3283	Water Pipe to Pump Screw	G3236	G3236		
Timer cover complete with ground contact	G2064X	G2064X	Bracket to Pump Cap Screw(5/16"x 1\frac{1}{4}")	G3009	G3009		
Timer circuit breaker brass post	G3799	G3799	Water Pipe	A49075	A49075		
Timer circuit breaker brass knurled	G3800	G3800	No. 2 Winkley Oiler	G167X	G167X		
Timer circuit breaker spring	G3801	G3801	Lubricating System.				
Timer circuit breaker fibre bushing		G3802	Cylinder, Oiler only	G1398X	G1398X		
Timer circuit breaker fibre push plug	G3803	G3803	Cylinder, Oiler Nipple	G2348 G2587			
Long Bros. Timer used previous to 1914.			Cylinder Oiler, Oil Pipe sightfeed to				
Timer, complete	G1384X	G1413X	Cylinder No. 1, with connections		G1411X		
Timer cover	G3253	G3253	Cylinder Oiler, Oil Pipe sightfeed to		G1412X		
Timer wing nuts	G3254 G3255	G3254 G3255	Cylinder No. 2, with connections. Cylinder Grease Cups. Cylinder Grease Cup Nipples	G1382	G1382		
Timer taper pins	G3249	G3249	Cylinder Grease Cup Nipples	G2348	G2348		
Timer hex. trolley screw	G3256	G3256	Cylinder Grease Cup Nipples Cylinder to Oiler Screw (12-20x5/8). Oil Cup Glasses, each 3"x3". Oil Cup Glasses (2\frac{2}{2}\frac{1}{2}\frac{2}{2}\frac{1}{				
Timer trolley spring Timer circuit breaker spring	G3257 G3258	G3257 G3258	Oil Cup Glasses (2½"x2 1/8")				
Timer circuit breaker bushing	G3259	G3259	Oil Cup Glass Gasket				
Timer brass screws	G3260	G3260	Sight Feed Glasses				
Timer brass hex. nuts	G3261 G3262	G3261 G3262	Cylinder-Grease Cup Coupling	G2350	G2350		
Timer steel set screws	G3263	G3263	Starting Crank.				
Timer trolley and roller	G3264	G3264 G3265	Starting Crank, complete	G1408X	G1408X		
Timer circuit breaker nut	G3265 G3266	G3266	Starting Crank Bolt with Nut	R48413	R48413		
Timer circuit breaker push button	G3267	G3267	Starting Crank Handle	R48414 R48415	R48414 R48415	1	
Timer self closing top oilers Timer bracket clamp screw		G3268 G3297	Starting Crank PawlStarting Crank Pawl Bolt with Nut.		R48416		
Timer shaft	R48418	R48418					
Timer bracket with set screws	A48787	A48787	Muffler.	G2124X	G2124X		
Timer base and handle	G3294 G3288	G3294 G3288	Muffler, complete	GEILTA	Calaire		
Timer ring with contact	G3289	G3290	Electrical Equipment.	CITOL	C1704		
Timer gear on timer shaft	A48423	A48423	Dry Cells	G734 G124X	G734 G124X		177
Timer gear on crank shaft cap screw	A48424 R48718	A48424 R48718	Switch	G202A	G262X		
Timer gear shield	A31813	A31813	Spark Coil	G1860X			E 37
Timer gear shield screws	G2380 R48419	G2380 R48419	Primary Wire, per foot				
Timer shaft bushing Timer bracket to cylinder screw	G2673	G2673	Secondary Wire, per foot	1	1		

Accessories: G3691 No. 26 Wrench G3690 No. 727 Wrench

Lubricating Oil and Can

Can of Hard Grease

REPAIR PARTS FOR TYPE "G" MARINE ENGINES

REPAIR PARTS FOR TYP	E "G" IMIA	ARINE ENC	TIMES	
Name of Part.	6 H. P. 1 Cylinder Symbol	12 H. P. 2 Cylinders Symbol	18 H. P. 3 Cylinders Symbol	24 H. P. 4 Cylinders Symbol
Cylinder and Upper Base	A2670	A2670	A2670	A2670
Cylinder and Upper Base Cylinder Head, nickled Cylinder Head Cap Screws	A31847 R48550	A2671 A31847 R48550	A2671 A31847 A48550	A2671 A31847
Cylinder Head Gasket. Cylinder Hand Hole Plate.	R31848 A48553	R31848 A48553	R31848 A48553	A48550 R31848
Cylinder Hand Hole Plate Gasket	R48554 G2373	R48554 G2373	R48554 G2373	A48553 R48554 G2373
Lower Half of Crank Case, babbitted	A2667 G3242	A2668 G3242	A1396 G3242	A1395 G3242
Name Plate Name Plate Screws.	R48698 G3298	R48698 G3298	R48698 G3298	R48698 G3298
Hybaust Connection	A2672 A48543	A2673 A48543	A2674 A48543	A1398 A48543
Exhaust Pipe Flange Exhaust Pipe Flange Gasket Exhaust Pipe Dowel Nipple	R48544 R48670	R48544 R48670	R48544 R48670	R48544 R48670
Exhaust Pipe Flange Cap Screw Exhaust Pipe Drain Plug. Exhaust Pipe Woter Volve complete	G3108 G2313 G1385X	G3108 G2313 G1385X	G3108 G2313	G3108 G2313
Exhaust Pipe Water Valve, complete Exhaust Pipe Water Valve Bushing Exhaust Pipe Water Valve Stem	R48566 R48545	R48566 R48545	G1385X R48566 R48545	G1385X R48566
Exhaust Pipe Water Valve Handle with Dowel	R48546 R48547	R48546 R48547	R48546 R48547	R48545 R48546 R48547
Exhaust Pipe Clamp Exhaust Pipe Clamp Stud	A48548 R48549	A48548 R48549	A48548 R48549	A48548 R48549
Exhaust Pipe Clamp Stud Nut	G3248 A31843	G3248 A31856	G3248 A2675	G3248 A1433
Intake Connection Dowel Pins	R48640 R48793	R48640 R48793	R48640 R48793	R48640 R48793
Main Bearing Cor Bushing, Fly-wheel End.	R48699 R48512	R48699 R48512	R48699 R49471	R48699 R49471
Intake Connection Nipple Intake Connection Gasket Main Bearing Cap Bushing, Fly-wheel End Main Bearing Cap Bushing Timer End Main Bearing Cap Bushing, center Main Bearing Cap, Fly-wheel End Main Bearing Cap, Fly-wheel End Main Bearing Cap, Center Main Bearing Cap, Center Main Bearing Cap Screws By-pass Opening Plug	R48513 A48510	R48513 R48515 A48510	R48513 R48515 A49472	R48513 R48515
Main Bearing Cap, Timer End. Main Bearing Cap, Center	A48511	A48511 A48514	A48511 A48514	A49472 A48511 A48514
Main Bearing Cap Screws. By-pass Opening Plug.	G3108 A48551	G3108 A48551	G3108 A48551	G3108 A48551
By-pass Opening Plug. By-pass Screen. Bearing Cap Packing.	A49352 R411267	A49352 R411267	A49352 R411267	A49352 R411267
Bemus Timer used on part of engines for year of 1914.				
Bemus Timer.				
Timer only, complete with main casting, handle with circuit breaker, revolving center piece with collar and taper pin, fibre ring with contacts and cover	Clanco	Conety	Clancax	G
Timer main casting with handle and circuit breaker Timer revolving center piece with pin.	G2060X G2063X G3787	G2061X G2063X G3787	G2062X G2063X G3787	G2059X
Timer collar for revolving center piece	G3788 G3773	G3788 G3773	G3788 G3773	
Timer bevel contact roller. Timer bolt holding insulating ring	G3276 G3277	G3276 G3277	G3276 G3277	
Timer two-piece lock nut for cover. Timer insulating ring only arranged for one contact	G3278	G3278	G3278	
socket. Timer insulating ring only arranged for two contact	G3398	Caoro		
socket Timer insulating ring only arranged for three contact sockets		G3279	G3789	
Timer insulating ring only arranged for four contact		<i></i>	G9769	G3868
Timer insulating ring contact complete, consists of ball, socket, spring and cap	G1452X	G1452X	G1452X	G3000
Timer contact steel ball. Timer contact steel ball socket.	G1607 G3280	G1607 G3280	G1607 G3280	
Timer contact steel ball socket lock ring. Timer contact steel ball socket cap nut.	G3281 G3282	G3281 G3282	G3281 G3282	
Timer contact steel ball spring. Timer cover complete with ground contact.	G3283 G2064X	G3283 G2064X	G3283 G2064X	
Timer circuit breaker brass post. Timer circuit breaker brass knurled nut. Timer circuit breaker spring.	G3799 G3800 G3801	G3799 G3800 G3801	G3799 G3800 G3801	
Timer circuit breaker fibre bushing. Timer circuit breaker fibre push plug.	G3802 G3803	G3802 G3803	G3802 G3803	
Long Bros., Timer used previous to 1914 Timer, complete	G1384X	G1413X	G1414X	G1415X
Timer, Cover. Timer, Wing Nuts.	G3253 G3254	G3253 G3254	G3253 G3254	G3253 G3254
Timer, Steel Posts. Timer, Taper Pins. Timer, Hex. Trolley Screws.	G3255 G3249	G3255 G3249	G3255 G3249	G3255 G3249
Timer, Trolley Spring	G3256 G3257	G3256 G3257	G3256 G3257	G3256 G3257
Timer, Circuit Breaker Bushing. Timer, Breas Sarawa long	G3258 G3259	G3258 G3259	G3258 G3259	G3258 G3259
Timer, Brass Screws, long Timer Hex. Nuts. Timer Steel Collars.	G3260 G3261	G3260 G3261 G3262	G3260 G3261 G3262	G3260 G3261
Timer Brass Screws, short. Timer Trolley and Roller	G3262 G3263 G3264	G3262 G3263 G3264	G3262 G3263 G3264	G3262 G3263 G3264
	COLOX	COLUI	G0201	C10204

REPAIR PARTS FOR TYPE "G" MARINE ENGINES.

REPAIR PARTS FOR TY	PE G MAR	THE ENGINE	10.	
Name of Part.	6 H. P.	12 H. P.	18 H. P.	24 H. P.
	1 Cylinder	2 Cylinders	3 Cylinders	4 Cylinders
	Symbol.	Symbol.	Symbol:	Symbol.
Long Bros., Timer used previous to 1914—Continued Timer Circuit Breaker Screw. Timer Circuit Breaker Nut. Timer Circuit Breaker Push Button. Timer Shaft. Timer Bracket with Set Screw. Timer Gear on Timer Shaft. Timer Gear on Crank Shaft. Timer Gear on Crank Shaft Cap Screw. Timer Gear Shield. Timer Gear Shield Cap Screw. Timer Shaft Bushing. Timer Bracket to Cylinder Screw. Carburetor	G3265	G3265	G3265	G3265
	G3266	G3266	G3266	G3266
	G3267	G3267	G3267	G3267
	R48572	R48572	R48572	R48572
	A31552	A31552	A31852	A31852
	A48423	A48423	A48423	A48423
	A48578	A48578	A48578	A48578
	R48718	R48718	R48718	R48718
	A31849	A31849	A31849	A31849
	G2380	G2380	G2380	G2380
	R48419	R48419	R48419	R48419
	G2373	G2373	G2373	G2373
Carburetor (Schebler), 1½" Carburetor Control Lever Carburetor Control Lever Fulcrum Pin. Carburetor Control Lever Link Carburetor Control Lever Link	G2129X R31921 R48755 R48667	G2129X - A31875 R48755 R48667	G2129X A31875 R48755	G2129X A31875 R48755
Carburetor Control Lever Link Drain Cocks Priming Cups Water Pump (Rotary) Water Pump (Rotary)	G378X	G378X	G378X	G378X
	G2086X	G2086X	G2086X	G2086X
Water Pump, complete with Gears, Shaft, Screws and Nuts Water Pump Body. Water Pump Cover. Water Pump Packing Nut. Water Pump Lock Nut. Water Pump Gears. Water Pump Supporting Stud and Nut. Water Pipe. Water Pipe. Water Pipe Gasket (to Cylinder).	G1401X A48387 A48388 R48389 R48390 R48394 R48396 A31846 R48666	G1402X A31860 A48388 R48389 R48390 R48528 R48396 A31857 R48666	G1456X A 2676 A32077 A49470 A49401 A31859 R48666	G1456X A2676 A32077 A49470 A49401 A31858 R48666
Water Pipe Gasket (to Cylinder) Water Pipe Gasket (to Pump) Water Pump Pinion on Pump Shaft Water Pump Short Gear Shaft Water Pump Long Gear Shaft Water Scoop Water Pump Pinion on Engine Shaft Water Pump Gear Shield Water Pump Gear Shield . Water Pump Gear Shield Cap Screw Water Pump Gear Shield Cap Screw	R48392 R48393 A48400	R48700 A48526 R48523 R48529 A48400 A48525 A31867 G2310 G2380	A49464 R49405 R49406 A48400 A48525 A32073	A49464 R49405 R49406 A48400 A48525 A32073
Water Pump Pinion on Engine Shaft. Water Pump Gear Shield. Water Pump Glose Nipple (Brass). Water Pump Gear Shield Cap Screw. Water Pipe to Water Pump Screw, 5/16"x\frac{1}{2}". Water Pump Body Screw. Water Pump Pinion on Pump Shaft Set Screw. Water Pump Pipe Screw to Cylinder. Water Pump Pipe Screw To Cylinder.	G3241	G3241	G3241	G3241
	G3240	G3240	G3240	G3240
	G3236	G3236	G3236	G3236
Water Pump, complete with Bracket, Pipe, Gaskets and necessary Screws to attach to Engine. Water Pump only. Water Pump Body. Water Pump Eccentric Strap (Assembled). Water Pump Dutlet Valve. Water Pump Packing Nut. Water Pump Placking Nut. Water Pump Placking Nut. Water Pump Plunger. Water Pump Bracket. Water Pump Bracket. Water Pump Bracket. Water Pump Plunger Pin. Water Pump Plunger Pin. Water Pump Bracket. Water Pump Bracket. Strapp Plunger Pin Strapp Plunger Plunge	G1444X G1403X A32060 { A48399 A48400 A49408 R49409 A49411 A49411 A49412 A49413 R49613 R48639 R48639 R48669 G167X R48396 G3300 G1458X R49650 R48666	G1457 X G1403 X A32060 A48399 A48400 A49408 R49409 A49411 A49411 A49412 A49413 R49613 R48639 R48639 R48639 R48960 G167 X R48396 G3300 G1459 X R49507 R48666 R49577 G3245	G1462X G1464X A32068 A49497 A49498 A49500 R49501 A49501 A49505 R49505 R49503 A49496 G167X R48396 G3300 G1460X R49686 R48666 R49577 G3245	G1463 X G1464 X A32068 A49497 A49498 A49500 R49501 A49504 A49505 R49505 R49503 A49496 G167 X R48396 G3300 G1461 X R49686 R48666 R49577 G3245
Ball Thrust Bearing, complete with Ring and Collars Fly-wheel	G1386X	G1386X	G1386X	G1386X
Fly-wheel. Fly-wheel Nut. Fly-wheel Key. Connecting Rod	A31842	A31842	A31842	A31842
	R48401	R48401	R48401	R48401
	G3239	G3239	G3239	G3239
Connecting Rod and Cap, complete with Bushing, Bolts and Nuts. Connecting Rod and Cap. For engines numbered above 6,000:	G1387X	G1387X	G1387X	G1387X
	R31841	R31841	R31841	R31841
Connecting Rod Bushing, Upper Half	R49610	R49610	R49610	R49610
	R49611	R49611	R49611	R49611
Connecting Rod Bushing, Upper Half, Connecting Rod Bushing, Lower Half, Connecting Rod Shims (for 12) Connecting Rod Bolt. Connecting Rod Nuts for Bolt. Connecting Rod Bushing, Piston End	A410014	A410014	A410014	A410014
	A410015	A410015	A410015	A410015
	R48580	R48580	R48580	R48580
	R48579	R48579	R48579	R48579
	R48581	R48581	R48581	R48581
	R48582	R48582	R48582	R48582

REPAIR PARTS FOR TYPE "G" MARINE ENGINES.

				AND RESIDENCE OF THE PARTY OF T
Name of Part.	6 H. P. 1 Cylinder Symbol.	12 H. P. 2 Cylinders Symbol.	18 H. P. 3 Cylinders Symbol.	24 H. P. 4 Cylinders Symbol.
Crank Shaft Crank Shaft, complete with Oil Ring, Counterweights and Screws. Crank Shaft only. Crank Shaft Counterweight, Fly-wheel End Crank Shaft Counterweight, Prop. End Crank Shaft Counterweight Screw. Crank Shaft Oil Rings. Crank Shaft Oil Rings, Screws. Coupling		G1430X R2677 A48584 A48583 R48585 R48586 G3238	G1431X R1401 A48584 A48583 R48585 R48586 G3238	G1432X R1402 A48584 A48583 R48585 R48586 G3238
Coupling Flange, Engine End Coupling Flange, Engine End Key Coupling Flange, Propeller End. Coupling Flange, Propeller End Key Coupling Flange, Propeller End Key Coupling Flange Cap Screw Coupling Flange, Propeller End Screw Set. Coupling Flange, Propeller End Screw Set.	A48532 R48409 A48365 R48791 R48790 G3246 G3243 G3244	A48862 R48409 A48861 R48900 R48790 G3246 G3243 G3244	A48862 R48409 A48861 R48900 R48790 G3246 G3243 G3244	A48941 R48409 A48861
Piston, complete with Rings, Pin and Set Screw. Piston Body. Piston Rings. Piston Pin. Piston Pin. Piston Pin Set Screw. Piston Ring Dowel. Piston Pin Bushing. Lubricating System	G1390X A31836 R31871 R48577 R44600 R48668 R48582	G1390X A31836 R31871 R48577 R44600 R48668 R48582	G1390 X A31836 R31871 R48577 R44600 R48668 R48582	G1390X A31836 R31871 R48577 R44600 R48668 R48582
Oil Reservoir, complete with Filler Plug, Sight Glass, Washers, Nipple and Elbows. Oil Reservoir only Oil Reservoir Filler Plug Oil Reservoir Filler Plug Washer. Oil Reservoir Sight Glass Oil Reservoir Sight Glass Washers. Oil Reservoir Guide Plug Oil Reservoir Guide Plug Oil Reservoir Pressure Pipe Nipple Oil Reservoir Pressure Pipe Elbow Oil Reservoir Check Valve complete Oil Reservoir Check Valve Ball Case Oil Reservoir Check Valve Ball Retainer Oil Reservoir Check Valve 5/16" Ball. Oil Reservoir, Inside Discharge Pipe with Nipple Oil Reservoir, Feed Pipe to Sight Feed Connections Oil Pipe Union End Connection with Oil Ring Feed Pipe Oil Pipe Union End Connection, 1/8" Oil Pipe Union End Connection, 1/8" Oil Pipe Union Nut, 1/8" Feed Pipe, Sight Feed to Cylinder No. 1, with connection	G1392X A31844 A48559 R48560 R485567 R48557 R48558 R48561 R48562 G1393X R48602 R48603 G3250 G1327X R48849 G1328X R48849 G1328X R48470 R48471	G1392X A31844 A48559 R48550 R48557 R48557 R48557 R48561 R48562 G1393 X R48602 R48602 R48603 G3250 G1327 X R48849 G1328 X R48849 G1328 X R48470 R48470	G1392X A 31844 A48559 R485560 R48557 R48557 R48558 R48561 R48562 G1393X R48602 R48603 G3250 G1327X R48848 R48848 R48848 R48847 R48847 R48847	G1328X R48470 R48471
tions. Feed Pipe, Sight Feed to Oil Ring No. 1, with connection. Feed Pipe, Sight Feed to Cylinder No. 2, with connection. Feed Pipe, Sight Feed to Oil Ring No. 2, with connection. Feed Pipe, Sight Feed to Center Bearing Pipe No. 1, with connection.		R48850 R48851 R48852 R48853 R48854	R48850 R48851 R48852 R48853 R48854	R48850 R48851 R48852 R48853 R48854
Feed Pipe, Sight Feed to Center Bearing Cap No. 2, with			R48855 R48856 R48857	R48855 R48856 R48857
Feed Pipe, Sight Feed to Cylinder No. 4, with connections Feed Pipe, Sight Feed to Oil Ring No. 4 with connections. Feed Pipe, Sight Feed to Center Bearing Cap No. 3, with				R49435 R49436
connections Cylinder Grease Cups Cylinder Grease Cups Coupling Cylinder Grease Cup Nipples Cylinder to Oil Reservoir Screws Sight Feed to Cylinder Screws	G1382X G2350 G2348 G2373	G1382X G2350 G2348 G2373	G1382X G2350 G2348 G2373	R49434 G1382X G2350 G2348
Cylinder to Oil Reservoir Screws. Sight Feed to Cylinder Screws. Sight Feed Oilers, complete. Sight Feed Glasses, each. Sight Feed Glasses, Gaskets.		G1416X	G1417X	G1418X
Starting Crank Starting Crank, complete Starting Crank Bolt for Handle with Nut. Starting Crank Handle. Starting Crank Pawl. Starting Crank Pawl Bolt with Nut.	G1389X R48413 R48414 R48415 R48416	G1389X R48413 R48414 R48415 R48416	G1389X R48413 R48414 R48415 R48416	G1389X R48413 R48414 R48415 R48416
Muffler	G2125X	G2125X	G2125X	G2125X
Muffler, complete				
Muffler, complete. Electrical Dry Cells, each Dry Cells, connecting Wires. Spark Coil. Primary Wire, per foot.	G 734 G124X G1860X	G734 G124X G1861X	G734 G124X G1862X	G734 G124X G1863X


G3885 No.701A Wrench G3824 No.728 Wrench G3823 No. 35 Wrench Can of Hard Grease Lubricating Oil with Can


INSTRUCTIONS—FAIRBANKS-MORSE IWO-CICEE MINUTED ENGINEER


PROPELLER EQUIPMENT FOR TYPE "E" ENGINES.						
Name of Part	3 1/2 H. P. 3/4" Solid Propeller Outfit	3 1/2 and 7 H. P. 3/4" Reverse Propeller Outfit	7 H. P. 1" Solid Propeller Outfit			
Propeller Shaft (Steel)	R48428	R48451	B48788			
Propeller Shaft (Bronze)	R48897	R48898	R48858			
Propeller Shaft Key (Steel)	R48864	R48891	R48895			
Propeller Shaft Key (Bronze)	R48865	R48892	R48896			
Propeller Shaft Sleeve	1010000	R48439				
Stern Bearing complete with Stuffing Box and Lock Nut	G1799X	G1800X	G1801X			
Stern Bearing complete with Sturing Box and Bock 1740	A48429	A48438	R48903			
Stern Bearing Stuffing Box	R48430	R48440	R48904			
Stern Bearing Stuffing Box	R48431	R48441	R48441			
Stern Bearing Lag Stud	R48189	R48189	R48189			
Stern Bearing Lag Stud	R49193	R49193	R49193			
Stern Bearing Lag Stud Nut	1049199	A48354	1010100			
		R48355				
Lock Collar		R48452				
Inside Stuffing Box Cap		. N40402				
Inside Stuffing Box Lock Nut		A48353				
Shifting Collar		R48453				
Shifting Collar Screws						
Yoke		A48442 A48443				
Yoke Bracket		R48444				
Combination Bracket Pin for Reverse Mechanism						
Tie Rod for Reverse Mechanism		R48349				
Tie Rod Fork		A48445				
Reverse Lever		A31814				
Fulcrum Pin for Yoke						
Fulcrum Pin for Reverse Lever						
Link						
Upper Dog for Reverse Lever		A48447				
Lower Dog for Reverse Lever		A49446				
Bracket for Reverse Lever		A48352				
Latch for Lever		A48448				
Pin for Latch on Upper Dog						
Pin for Latch and Dog		R48450				
Tie Rod for Reverse Lever		R48350				
Spring for Lever		R48449				
Pin for Latch on Lever Quadrant		A48351				
3/8"x1" Hex. Head Cap Screw						
(For A48351).						
3/8"x3" Lag Screws (for A48352 and A1431)						
Spanner Wrench	A48432	A48432	A48432			
PROPELLER EQUIPMENT	FOR TYPE "	G" ENGINES.				


PROPELLER EQUIPMENT	FOR LIFE	G ENGINI	30.	
	6 H. P.	6 H. P.	12-18 H. P.	12-18-24 H. P.
	1 Cylinder	1 Cylinder	2-3 Cylinders	2-3-4 Cyl'ders
Name of Part.	3/4" Reversi-	1" Solid,	1" Reversible.	1 1/4" Solid,
	ble.Symbol.	Symbol.	Symbol.	Symbol.
Propeller Shaft, Steel	R48451	R48788	R48944	R48859
Propeller Shaft, Bronze	R48898	R48858	R48945	R48860
Propeller Shaft Key, Steel.	R48891	R48895	R48893	R48866
Describer Shaft Wass Droppe	R48892	R48896	R48894	R48867
Propeller Shaft Key, Bronze	G1800X	G1801X	G1802X	G1803X
	A48438	R48903	R48913	A48905
Stern Bearing	R48439	1740900	R49130	1110000
Propeller Shaft Sleeve	R48440	R48904	R49131	A48906
Stern Bearing Stuffing Box		R48441	A48907	A48907
Stern Bearing Stuffing Box Lock Nut	R48441	R49189	R49190	R49190
Stern Bearing Lag Stud	R49189	R49189 R49193	R49192	R49192
Stern Bearing Lag Stud Nut	R49193		A49135	1049192
Inside Stuffing Box and Lock Collar	R49188		A49133 A49132	
Lock Collar	R49138			
Inside Stuffing Box Cap	A49080	,	R49223	
Inside Stuffing Box Lock Nut	A49136		A49136	
Shifting Collar	A49133		A49133	
Shifting Collar Screws	R49137		R49137	
Yoke	A49134		A49134	
Yoke Bracket	A1431		A1431	
Combination Bracket				
Pin for Reverse Mechanism				
Tie Rod for Reverse Mechanism				
Tie Rod Fork				
Reverse Lever	A2706		A2706	
Fulcrum Pin for Yoke	R48949		R48949	
Fulcrum Pin for Reverse Lever	R48948		R48948	
Link	A49082		A49082	
Upper Dog Reverse Lever	R49225		R49225	
Lower Dog for Reverse Lever	A49224		A49224	
Bracket for Reverse Lever				
Latch for Lever	A49234		A49234	
Pin on Latch for Upper Dog	R49240		R49240	
Pin for Latch and Dog				
Tie Rod for Reverse Lever	R49226		R49226	
Spring for Lever	R49235			
Pin for Latch on Lever	R49236		R49236	
Quadrant				
3/8"x1" Hex. Head Cap Screw (for A48351)				
3/8"x3" Lag Screws (for A48352 and A1431)				
Spanner Wrench	A48432	A48432		
Spanner Wrench				A48908

For Repairs Parts or Special information for the Baldridge Reverse Gear, please communicate directly with Baldridge Gear Co., Detroit, Mich.










Fairbanks-Morse Type "K" Marine Engine

A Two Cycle, Heavy Duty Engine for Cruisers, Fishing and work Boats



MADE in one and two cylinders, developing $7\frac{1}{2}$ and 15 H. P. at 500 R. P. M. Cannot base fire. A simple device found on no other engine prevents base explosions and does not clog or choke the engine.

Remarkable economy—operates at lower cost than any other of its kind. Bearings extra large and all removable and renewable.

Accessibility is another strong feature—every part can be reached easily and without special tools.

Lubrication by gravity feed, centrifugal oil ring to crank—or oil in fuel. Make and break or self contained jump spark, requiring no battery for starting.

Water does not come in contact with cylinder head gasket but is bypassed through outside connections.

We will be glad to furnish further particulars regarding this engine upon your request.

		The second secon	1		1	
	FHG-	-C Brass Barrel Gas Startel mp with Lever Handle (32	GL	GL-C Gas Starter Cock. Gas Starter Cock Body fitted with	GG GJ	Burner Chimney. Burner Chimney to X Cyl. Studs.
		to 60 HP Type).		Gas Starter Cock Body fitted with GK Plug, GM Washer and GN	GH	Burner Chimney Asbestos Lining.
	F2 FR2	Starter Pump Barrel. Starter Pump Base.		Nut.	DH	Burner Fuel Pipe. Burner Tube Bushings.
	FG2	Starter Pump Cap.	CH-C	Combination Valve_Relief	TITIT	Burner Tubes (one set).
	TIDO	Cap to Engine Capscrews.	Va	C Combination Valve—Relief lve for 5 and 7 HP. Check	TFG	Rubber Gas Bag for Burner.
	FD2 ZE2	Starter Pump Piston (Top Section). Starter Pump Piston (Middle Sec-		Valve for 10 to 60 HP.		DW-C Oil Shield.
		tion).	GE	Combination Valve. Combination Valve Nut.	DW	Oil Shield.
	FE2	Starter Pump Piston (Bottom Sec-		Combination Valve Nut Taper Pin.		Capscrews for attaching Oil Shiel
	GO2	tion). Starter Pump Piston Leathers.	CH	Combination Valve Body.		to Engine. Additional Mach. Screws for attach
	FI2	Starter Pump Piston Rod.	G GB	Combination Valve Body Cap. Combination Valve Sleeve.		ing Oil Shield to Engine. (32 to 6
	FA2 FF2	Starter Pump Piston Rod End. Starter Pump Lever Handle.		Combination Valve Sleeve to G Cap		HP).
	FAA2	Starter Pump Lever Handle Pin and	GA	Mach. Screws. Combination Valve Stem Nut.	op a	Indian Duller (E to 40 TV
	FK2	Cotters.	GD	Combination Valve Galvanized Steel	DE-0	Engine Pulley (5 to 40 HI only).
	FKA2	Starter Pump Lever Handle Link. Starter Pump Lever Handle Link	ZG	Washers. Combination Valve Red Fibre Washer	SP	Engine Pulley fitted with Key and
		Pin and Cotters.	20	(10 to 60 HP).		Set Screws.
	FL	Starter Pump Lever Handle Link Bracket (32 and 40 HP).	aa	Combination Valve Rubber Gasket.	H	P-C Engine Power Plate.
	FL2	Starter Pump Lever Handle Link	GC	Combination Valve Spring (10 to 60 HP).	HP	Power Plate.
		Stud (50 and 60 HP).			- NETT-19	Power Plate to Engine Mach. Screws
		Starter Pump Lever Handle Link Bracket Capscrews (32 and 40	CH2-	C Brass Combination Cock (Old Style).	NID NI	P-C Engine Patent Plate.
	ET 40	HP).	CH2	Brass Combination Cock Body.	NP .	Patent Plate. Patent Plate to Engine Brass Mach
	FLA2	Starter Pump Lever Handle Link Stud Collar (50 and 60 HP).	G2 GA2	Brass Combination Cock Plug.		Screws.
		Starter Pump Lever Handle Link Stud Cotter (50 and 60 HP).	GB2	Brass Combination Cock Ball Valve. Brass Combination Cock Half Union		Patent Plate Mach. Screw Rubber Washers.
	FM2	Stud Cotter (50 and 60 HP). Starter Pump Discharge Valve Seat.		Nut.		
	FC2	Starter Pump Discharge Valve. Starter Pump Discharge Valve	GC2	Brass Combination Cock Half Union Coupling.	HC-C	Plate over Air Suction Hole
	FJ2	Starter Pump Discharge Valve	GE2	Brass Combination Cock Lever	HC	in Base. Plate over Air Suction Hole in En-
	FB2	Spring. Starter Pump Admission Valve.	GD2	Handle. Brass Combination Cock Lever		gine Base.
	FN2	Starter Pump Admission Valve Seat.		Handle Washer.		Plate to Base RHM Screws.
	FS2	Starter Pump Mixer Valve Seat with FU2 Bushing and FT2 Valve.	GM2	Brass Combination Cock Lever	HC1-0	Plate over Reservoir Hole
		Mach. Screws to attach FS2 to FR2.	CJ2	Handle Nut. Brass Combination Cock Nipple	HCl	in Head. Plate over Reservoir Hole in Head.
		Starter Pump Base to Engine Capscrews.		(Cock to Engine).		Plate to Cyl. Head RHM Screws.
	7177			FQ-C Detonator.	CG-C	Water Overflow Pipe and
	FY	Pipe and Fittings to con- nect Starter Pump with	FP	Detonator Tube.		Funnel.
		Engine.	FQ FV	Detonator Plunger. Detonator Plunger Cap.	CG	Water Overflow Pipe Funnel. Water Overflow Pipe and Fittings.
	arra	SYG-C Gas Valve.	FW	Detonator Plunger Spring.	-	
	SYG	Gas Valve Body. Body to Mixing Pipe Cap Screws.	FO	Detonator Screw Cap.	S	Cylinder Oiler.
	PFG	Gas Valve.	ma	TC-C Exhaust Pot.	SA	Crank Pin Oiler (5 to 15 HP).
	PGG	Gas Valve Nut. Gas Valve Nut Taper Pin.	TC TD	Exhaust Pot with Pipe Plug. Exhaust Pot Cover fitted with Studs	SAA	Oiler for Ring Oiling De-
	PLG	Gas Valve Tension Spring.		for TX Gland; also includes Studs		vice (20 to 60 HP).
	SZG	Gas Valve Body Cover Mach. Screws.		for NB Flange on 32 to 60 HP. Nuts for TX Gland Studs.	SAB	Main Bearing Oiler (32 to
		JDG-C Mixing Pipe.		Nuts for NB Flange Studs (32 to 60	ULL	60 HP).
	JDG	Mixing Pipe.		HP). Capscrews for attaching NB Flange	Con	aplete Set of Springs for
		Mixing Pipe to Engine Short Cap-		(5 to 25 HP).		Engine.
		screw. Mixing Pipe to Engine Long Cap-		Exhaust Pot to Cover Mach. Bolts and Washers.	NE OE	Spring for Exhaust Valve.
	TEC	screw.		Exhaust Pot to Cover Asbestos Gas-	MC	Spring for Suction Valve. Spring for Governor Weights (Two)
	JFG	Mixing Pipe Brace Rod. Mixing Pipe Brace Rod Nut.	TX	ket. Exhaust Pot Gland.	CA	Spring for Governor Detent Catch.
		Mixing Pipe Brace Rod Capscrews.	IA	Exhaust Pot Gland Asbestos Wick	ED	Spring for Igniter Rocker Arm at Gear.
	PKG	-C Gas Valve Operating	ND	Packing.	EO	Spring for Pawl on Igniter Rocker
	PKG	Mechanism. Gas Valve Operating Rod.	NB	Exhaust Pot Pipe Flange.	ES	Arm at Head. Spring for Igniter Movable Electrode
		Gas Valve Operating Rod Nut.	T	E-C Gas Bunsen Burner.		Catch.
		Gas Valve Operating Rod Set Screw. Gas Valve Operating Rod Set Screw	TE TZ	Bunsen Burner Body. Bunsen Burner Needle Valve.	ET	Spring for Igniter Movable Electrode
		Nut.		Bunsen Burner Needle Valve Nut.	GC	Collar. Spring for Check Valve (10 to 60
	PJG	Gas Valve Operating Arm.	TJ TI	Bunsen Burner Tube. Bunsen Burner Coupling.	TIO	HP).
		Gas Valve Operating Arm Cap Screw.	TL	Bunsen Burner Air Sleeve Ring.	FJ3	Spring for Starter Pump Discharge Valve (5 and 7 HP).
		Gas Valve Operating Arm Cap		Bunsen Burner Air Sleeve Ring Mach. Screw.	FJ2	Spring for Starter Pump Discharge
(QDG	Screw Nut. Gas Valve Operating Arm Spring.	TH	Bunsen Burner Air Collar.	FW	Valve (10 to 60 HP). Spring for Detonator Plunger (10 to
(ŽQĞ	Gas Valve Operating Arm Spring	TK	Bunsen Burner Nozzle.		60 HP).
		Eyebolt. Gas Valve Operating Arm Spring	TJ-C	Gas Bunsen Burner Outfit	UU	Spring for Main Bearing Oil Cup Covers (Two) 5 to 40 HP.
	odd	Eyebolt Nuts.		(Complete).	UU	Spring for Gear Box Oil Cup Cover
(QCG	Gas Valve Operating Arm Spring Eyebolt Clip.	TE-C DT	Gas Bunsen Burner (Complete). Gas Bunsen Burner Bracket.	QOG	(10 to 40 HP). Spring for Relief Cam Shifter Handle
		QCG Clip to Engine Capscrews (32)		Mach. Screw to hold DH Fuel Pipe		Stop Pin.
		to 60 HP).		Mach. Screw to hold DH Fuel Pipe in DT Bracket. DT Bracket to X Cyl. Capscrew.	PLG QDG	Spring for Gas Valve.
				2 - 2 - William of the Office Capacite We	and	Spring for Gas Valve Operating Arm.

Instructions No. 2048

Supplementing Instructions No. 2099

FOR CONNECTING AND OPERATING

FAIRBANKS - MORSE

TYPE "N"

HORIZONTAL GAS ENGINES WITH HIT AND MISS GOVERNOR

This book, together with Instructions No. 2099, should be carefully read before attempting to do anything with the engine




Fig. HE1425

FAIRBANKS, MORSE & CO.

(Incorporated)

Address Our Nearest Warehouse

Chicago, Ill.
Cincinnati, Ohio
Richmond, Va.
Jacksonville, Fla.
Atlanta, Ga.
New Orleans, La.

New York, N. Y. Cleveland, Ohio Louisville, Ky. Detroit, Mich. Milwaukee, Wis. Indianapolis, Ind.



St. Paul, Minn. Minneapolis, Minn. Omaha, Neb. Salt Lake City, Utah Spokane, Wash. Kansas City, Mo. Denver, Colo.

San Francisco, Cal. Los Angeles, Cal. Bakersfield, Cal. Santa Maria, Cal. Seattle, Wash. Portland, Oregon

London, England

Copyright 1910 by Fairbanks, Morse & Co.

INSTRUCTIONS No. 2048

For Connecting and Operating Fairbanks-Morse Type "N" Horizontal Gas Engine

Additional Instructions

Carefully read Instructions No. 2099 for the Gasoline Engine, accompanying this pamphlet. Matter referring to description, care of parts, starting engines, cleaning and taking apart, setting governor, electric gear and electric igniter, battery, lubricating oil, oiling and adjusting igniter is applicable to Gas Engines.

These Engines are Regularly Fitted with:

High compression piston.

Compression relief cam outfit, to be used when starting engines. Patent self-starter on engines of 15 H. P. and larger.
Water reservoir on engines of 10 H. P. and larger.

Gas bag with one length of gas pipe.

Gas Connections

Arrangement

Gas connections should be made as shown below. Use large rubber gas bag (3) on supply pipe to engine. A gasometer may be substituted for this gas bag. Always use full size of pipe that throttle valve will take. Locate gas bag as close to engine as possible, as the function of this bag is to always keep sufficient gas at the engine for a few explosions, and keep the gas under the same conditions at

Throttle Valve (9)

Valve Opening

The throttle valve is a dial cock, having a lever handle with indicator point. The dial plate on top is numbered. This valve is tagged when shipped, giving a number on dial at which the indicator point on the handle is to be set for starting, and a number for running. If the valve is not open to the proper point when running, the engine will not get a full charge of gas, and this will cause a cracking noise in the suction pipe. When the gas pressure is good, the engine will get its required supply with less than the opening indicated by figures on the dial. The figures are noted when the engine is tested at the factory, where the gas pressure is two inches of water pressure, which means that the gas pressure will balance a column of water two inches in height.




Chart No. 1004GN

Showing Connections for Engines Operating on Gas

Gas Valve.

Gas Supply Pipe.

Gas Bag.

Spring.

Spring Bracket. Gas Meter.

From Gas Main.

Gas Cock to Feed Starter Pump.

Gas Valve Operating Arm.

Mixing Pipe.

Water Reservoir.

Starter Pump Cock.

Gas Valve Rod.

Water Reservoir Supply Pipe.

Air Pipe. Supply Pipe to Starter Pump.

20. Water Reservoir Overflow Pipe.

Detonator.

Starter Pump Pipe. Rear Relief Cam Bracket.

Relief Cam Shifter Handle.

Front Relief Cam Bracket. Relief Cam Rod.

Relief Cam.

Exhaust Rod.

Gas Pressure Regulator

Where the gas pressure is greater than three or four inches of water pressure, a gas pressure regulator must be used to reduce this pressure. This will often be the case with natural gas, but seldom with city gas, unless a high pressure system is in use.

To Start Engine-Important

MM-C Lower Base (20 to 40 HP).

Lower Base fitted with XL and XM

Read carefully all of Instructions No. 2099. Carefully see that the engine is well oiled at all points, including piston.

1st. Relief Cam-Shift exhaust roller by means of handle so that relief cam, which is outside of regular cam, comes into action.

2nd. Igniter-Set on late spark. See page 14, Instructions No. 2099.

3rd. Switch—Close switch in battery box.

4th. Throttle Valve-Turn throttle valve handle to number indicated on tag to start on.

5th. Gas Valve-Open gas valve by striking sharply two or three times with the hand in order to admit some gas to the mixing pipe for the first charge.

6th. Starter Pump-Engines 15 H. P. and larger are provided with patent self-starter. Open cock in self-starter pipe; also gas inlet to starter pump, then give several quick strokes of the pump. Hold fly wheel till it pulls hard, then strike the detonator previously charged with a parlor cracking match, which explodes the mixture previously pumped into the cylinder. This gives the engine momentum enough to draw in the charge in the regular manner, which will be fired by the regular igniting device. Close the valve leading to starter pump, then gradually turn on more gas at the throttle valve until open to the proper number for running.

7th. Starting by Hand—Patent self-starter is not used. After complying with sections 1 to 5. turn the fly wheel by hand. After the cylinder has been filled and exploded, the engine will take up explosions in the usual manner.

8th. After Engine is Running—Set igniter on early spark. Shift exhaust roller from relief cam. Set throttle in running position. Turn on circulating water. Open water reservoir throttle. See Instructions No. 2099, page 4.

9th. Caution—The throttle valve should not be opened previous to starting unless the piston of engine is standing at a point where the operating rod is not in contact with the gas valve stem, otherwise gas will be admitted to engine. If engine stops for any considerable time, the throttle valve should be closed at once.

Turn off water reservoir. Turn off circulating water. Close throttle valve. Open battery switch.

Stop Engine

Engine Running

Caution

Pressure

Important

Admit Gas

Self-Starter

REPAIR LIST FOR FAIRBANKS-MORSE "TYPE N" HORIZONTAL GAS ENGINES.

When ordering parts for repairs, give the description as given in this list by both letters and names of parts wanted; also the style, number and horse-power of the engine for which the parts are wanted. Too much care cannot be taken in giving these particulars.

The symbol at the head of each paragraph covers all items mentioned in that paragraph.

Before ordering a complete group of parts by the symbol in heavy type at head of paragraph, carefully check over such paragraph to make sure that all parts included therein are wanted, as they will all be furnished unless otherwise specified.

Dowel (32 and 40 HP).

	Studs.	Exhaust Rocker Arm Pin Collar	T
L C	LL-C Pillow Block Cap. Pillow Block Cap, fitted with oil tube. Pillow Block Cap Oil Cover.	Mach. Screw (32 and 40 HP). Pillow Block Caps, with UC Covers, etc. (Two). Oil Drain Pipe in Base (10 to 60 HP).	TA
	Pillow Block Cap Oil Cover Rivet (5 to 40 HP).	BBG-C Piston.	SB
U	Pillow Block Cap Oil Cover Spring (5 to 40 HP).	BBG Piston fitted with XK Piston Pin	We way
	Pillow Block Cap Oil Cover Spring Screw (5 to 40 HP).	Set Screws and Nuts, Piston Ring Stop Pins, QM Oil Tube, and QN Eyebolt.	QI CB
1	KK-C Engine Crank Base.	QE Piston Rings.	CC
K	Crank Base, always fitted with fol- lowing parts:	QH Piston Pin.	CI
D	Main Bearing Brasses (Opposite Governor Side).	XCG-C Engine Cylinder.	Q
E	Main Bearing Brasses (Governor Side).	Cylinder Head Studs, XC Cyl.	QL
D	Crank Base to LL Cap Studs	Ring Studs (5 to 25 HP) and Exh. Shell Studs (5 to 25 HP).	TA
	Nuts for XD Studs. Half Nuts for XD Studs.	Nuts for XC Cyl. Ring Studs (5 to	TM
В	Crank Base to X Cylinder Studs.	XA Ring at open end of cylinder (5 to	TTT
V	Exhaust Rocker Arm Pin in KK	XA Ring at open end of cylinder (5 to 25 HP).	UE
	Base.	BBG-C Piston complete with QE Rings, QH	
	Exhaust Rocker Arm_Pin Nut (32 to 60 HP).	Pin, etc.	
V	Exhaust Rocker Arm Pin Collar.	QL-C Connecting Rod.	
	Exhaust Rocker Arm Pin Collar Ta-		QK
	per Pin (all sizes except 32 and	CB Connecting Rod Crank Brass and	

Exhaust Rocker Arm Pin Collar | CD Connecting Rod Bolts with Nuts, Half Nuts and Cotters. Connecting Rod Piston Pin Brasses, (Wedge Half and Back Half). Piston Pin Brass Wedge. Piston Pin Brass Wedge Bolt. Piston Pin Brass Wedge Bolt Nut. Connecting Rod Oiler. QLC-C Connecting Rod with Crank Brasses (only). Connecting Rod. Connecting Rod Crank Brass and Connecting Rod Bolts with Nuts Half Nuts and Cotters. QLT-C Connecting Rod with Piston Pin Brasses (only). Connecting Rod. Connecting Rod Piston Pin Brasses (Wedge Half and Back Half). Connecting Rod Piston Pin Brass Wedge. Connecting Rod Piston Pin Brass Wedge Bolt. Connecting Rod Piston Pin Brass Wedge Bolt Nut. QK-C Crankshaft. Crankshaft, fitted with Y Pinion and




CHART No. 1149GN

Repair Chart for Fairbanks-Morse Horizontal Type "N" Gas Engines

REW-C Water Reservoir (10 to

REW Water Reservoir Body, fitted with

Water Reservoir Body to JL Suction Elbow Cap Screws.

60 HP)

Brass Tube Nozzle.

	6	INST	RUCTIONS—FAIRBAN	KS-M	IORSE ENGINES	
OKB-	C Crankshaft with Oil Ring	CTL	35 - 11s Electrode Cotch Step Pin		Igniter Rocker Arm Cap Screw.	
QK-C	Crankshaft, fitted with Y Pinion and	STA ES ST	Movable Electrode Catch Stop Pin. Movable Electrode Catch Spring. Movable Electrode Catch Spring Pin.	PQ6	Igniter Rocker Arm Cap Screw Nut.	
BF-C	YA Key. Oil Ring as attached to Crankshaft.	ET	Movable Electrode Spring.	PP6	Igniter Rocker Arm Pawl Pin. Igniter Rocker Arm Pawl Pin Nut.	
RF-		WH6	C "1910 Pattern" Igniter	WQ6	Igniter Rocker Arm Pawl Bolt.	
C	C Oil Ring as attached to rankshaft (20 to 60 HP). Oil Ring on Crankshaft.	WH6	Igniter Body, fitted with STA6	EN6	Igniter Rocker Arm Pawl Bolt Nut. Igniter Rocker Arm Pawl Pin Stop.	
BD	Oil Ring on Crankshaft. Oil Ring to QK Crankshaft Mach.	WI6	Stop Pin. Fixed Electrode, fitted with EQ		Igniter Rocker Arm Pawl Pin Stop Mach. Screws.	
BF	Screws.	11.20	Contact Disc.	EO6	Igniter Rocker Arm Pawl Spring.	
BE	Oil Ring Brass Tube from BD to BE. Oil Ring Flange for BF Tube.	SF6	Fixed Electrode Nut. Fixed Electrode Lava Insulations(2).	WN-C	C Igniter Rocker Arm at lead ("1907" Pattern).	
	Oil Ring Flange to QK Crankshaft Mach. Screws.	WM6	Fixed Electrode Asbestos (faskets(4).	WN H	Iead ("1907" Pattern).	
	BD-C Ring Oiler Parts	WY6	Fixed Electrode Collar. Fixed Electrode Thumb Nut. Moyable Electrode, fitted with WK6		Igniter Rocker Arm. Igniter Rocker Arm Cap Screw. Igniter Rocker Arm Cap Screw Nut.	
	(20 to 60 HP).	WJ6	Collar and Collar Taper Pin.	PQ	Igniter Rocker Arm Pawl.	
BG	Oiler Bracket, on engine base. Oiler Bracket to engine cap screws.	WJA6	Movable Electrode Arm, fitted with EQ Contact Disc and EU6 Nut.	PP	Igniter Rocker Arm Pawl Pin. Igniter Rocker Arm Pawl Pin Nut.	
GS GR	Drass Ull Tithe with Rughing in Rt	WL6	Movable Electrode Pawl.	WQ	Igniter Rocker Arm Pawl Bolt.	
GT .	Bracket. Brass Oil Tube Eyebolt.	ES6	Movable Electrode Pawl Spring. Movable Electrode Pawl Spring	WO WS	Igniter Rocker Arm Pawl Bolt Nut. Igniter Rocker Arm Pawl Bolt Lever.	
BF-C	Oil Ring as attached to Crankshaft.	ET6	Taper Pin. Movable Electrode Return Spring.	WA	Igniter Rocker Arm Pawl Bolt Lever Stop Pin.	
TT :	Governor Bracket.	1110	OD-C Suction Valve.	EN WR	Igniter Rocker Arm Pawl Bolt Head. Igniter Rocker Arm Pawl Bolt	
11	Gov. Bracket to RA Fly Wheel	OD	Suction Valve. Suction Valve Collar Nut.		Spring.	
TU	Bolts (5 to 15 HP).	RH CQ	Suction Valve Lock Nut.	EO	Igniter Rocker Arm Pawl Spring.	
	Gov. Bracket to RA Fly Wheel Capscrews (20 to 60 HP).		Suction Valve Lock Nut Cotter.	WN2-	-C Igniter Rocker Arm at Iead ("1899" Pattern).	
MA	Nuts for TU Bolts (5 to 15 HP). Governor Weight.	JJ	JJ-C Cylinder Head. Cylinder Head, fitted with SD Ig-	WN2	Igniter Rocker Arm	
QS	Governor Weight Pin in TT Bracket. Governor Weight Pin Taper Pin.		niter Studs and with JI Igniter		Igniter Rocker Arm Cap Screw. Igniter Rocker Arm Cap Screw Nut.	
			Cover Plate and Mach. Screws on 10 to 60 HP.; also includes Studs	PQ2 PP2	Igniter Rocker Arm Pawl.	
TT-C	MA-C Governor Parts. Governor Brackets with TU Bolts, MA Weights and QS Pins (Two of		for N Exhaust Shell on 32 to 60 HP.		Igniter Rocker Arm Pawl Pin. Igniter Rocker Arm Pawl Pin Nut.	
	MA Weights and QS Pins (Two of each).	WH-C	Nuts for SD Igniter Studs. Igniter as attached to Head.	WQ2 WS2	Igniter Rocker Arm Pawl Bolt. Igniter Rocker Arm Pawl Bolt Nut.	
MC QQ	Governor Springs (Two).	VW	Igniter to Cyl. Head Asbestos Gas-	EO2	Igniter Rocker Arm Pawl Bolt Nut. Igniter Rocker Arm Pawl Bolt	
2.5	Governor Spring Eyebolts (Two). Nuts for Governor Spring Eyebolts	OD-C	ket. Suction Valve, with RH and CQ	EN2	Spring. Igniter Rocker Arm Pawl Bolt	
MB	(Four). Governor Sleeve.	OE	Nuts and Cotter. Suction Valve Spring.		Spring Washer.	*
R	Plain Fly Wheel (opposite	RG	Suction Valve Cap. Suction Valve Cap to JJ Head Mach.	WV-C	Igniter Rocker Arm at Gear. Igniter Rocker Arm, fitted with EC	
	Gov. side.)		Screws.		Spring Stud. Igniter Rocker Arm Roller working	
RA	Governor Fly Wheel.	AI .	Suction Valve Stem Bushing. Suction Valve Stem Bushing to JJ	WT	against gear.	
WG	Fly Wheel Keys.	PX	Head Screws. Suction Valve Spring Adjusting Nut	WU	Igniter Rocker Arm Roller Pin. Igniter Rocker Arm Roller Pin Nut.	
RA-C	Governor Fly Wheel with		(32 to 60 HP).	WV	W-C Igniter Arm at Gear on WW Shaft.	
1011	Governor Fly Wheel.	JJ0-0	Cylinder Head with Suction Valve (only).	WV-C	Igniter Arm at Gear (Complete).	
TT-C	Governor Fly Wheel. Governor Brackets with TU Bolts, MA Weights and QS Pins (Two of	JJ	Cylinder Head, fitted with SD Ig- niter Studs, and with JI Igniter	WW	Igniter Rocker Shaft. Igniter Arm to Shaft Key.	
MC	eacn).		Cover Plate and Mach. Screws on	WW.C	Igniter Rocker Shaft Mech-	
QQ	Governor Springs (Two). Governor Spring Eyebolts (Two). Nuts for QQ Eyebolts (Four).		10 to 60 HP; also includes Studs for N Exhaust Shell on 32 to 60		anism.	
		OD-C	HP.	WV-C {		
QKR-	Crankshaft fitted with Wheels and Gov. Parts. Crankshaft fitted with Y Pinion and		and Cotter. Suction Valve Spring. Suction Valve Cap.	WW	Igniter Rocker Shaft. Igniter Rocker Arm to Shaft Key.	
QK-C	Crankshaft fitted with Y Pinion and	OE RG	Suction Valve Spring. Suction Valve Cap.	ED	Igniter Rocker Arm Spring. Igniter Rocker Shaft Bracket.	
QKB-C	YA Key (5 to 15 HP). Crankshaft with Oil Ring attached		Suction Valve Cap to JJ Head Mach. Screws.	WP	Igniter Rocker Shaft Bracket to JJ	
RA-C	(20 to 60 HP).	AI	Suction Valve Stem Bushing.		Head Cap Screws.	
MB	Governor Fly Wheel with Governor Parts.		Suction Valve Stem Bushing to JJ Head Screws.	WX-C	Igniter Rocker Arm Spring	
R	Governor Sleeve on Crankshaft. Plain Fly Wheel (Opposite Gov.	PX	Head Screws. Suction Valve Spring Adjusting Nut (32 to 60 HP).	WX	Bracket. Bracket on Engine Base for ED	
WG	Side). Fly Wheel Keys.	JJW-	C Cylinder Head with Igniter	WX2	Bracket on Engine Base for ED Spring 5 and 8 HP). Eyebolt on Engine Base for ED	
WH	-C Igniter as attached to	JJ	(only). Cylinder Head, fitted with SD Ig-		Spring (10 to 60 HP). Cap Screw for WX Bracket (5 and 8 HP).	
WH	Head. Igniter Body.	00	niter Stude and with II Igniter		Nut for WX2 Evebolt (10 to 60 HP).	
WI	Fixed Electrode fitted with EQ Point.		Cover Plate and Mach. Screws on 10 to 60 HP; also includes Studs	EF	Evebolt in WX or WX2 for ED	
CD	Fixed Electrode Nut.		for N Exhaust Shell on 32 to 60 HP.		Spring. Nuts for EF Eyebolt.	

Nuts for SD Igniter Studs.

Igniter as attached to Head.

WN6-C Igniter Rocker Arm at Head ("1908" Pattern).

Igniter Rocker Arm.

Igniter to Head Asbestos Gasket.

Gear.

WCG-C Gear, Shaft and Cam.

Cam and Gear Shaft, fitted with WB

Cam, PCG Relief Cam and Mach.

Fixed Electrode Collar.

Movable Electrode Catch.

Fixed Electrode Thumb Nut.

WM

WJ

WL

Fixed Electrode Lava Insulation.

Fixed Electrode Asbestos Gaskets.

Movable Electrode, fitted with WK

Collar, Taper Pin and EQ Point.

PTG-C Relief Cam Shifter Handle. NA Exhaust Shell Cap. Relief Cam Shifter Handle. Exhaust Shell Cap Asbestos Gasket. Relief Cam Shifter Handle Set Screw Exhaust Shell Cap to N Shell Cap Relief Cam Shifter Handle Clip. Exhaust Shell Pipe Flange. Relief Cam Shifter Handle Clip Pin Exhaust Shell Pipe Flange Asbestos Relief Cam Shifter Handle Stop Pin Relief Cam Shifter Handle Stop Pin Spring. PAG-C Relief Cam Shifter Mechanism. Relief Cam Shifter Shaft Relief Cam Shifter Shaft Bracket (Cylinder end) SXG Bracket to Engine Cap Screws. Relief Cam Shifter Shaft Bracket (Crank end). POG Bracket to Engine Cap Screws. Relief Cam Shifter Block. Relief Cam Shifter Block Taper Pin. PTG-C Relief Cam Shifter Handle (Complete). EX-C Circuit Breaker. Contact Arm, fitted with EY 1 Bottom Insulation Block and Brass Contact Screw Insulation Block (Top Half). Thumb Nut on Brass Contact Screw. Mach. Screws for attaching to En-CU-C Valve Lock Mechanism. Valve Lock Shaft, fitted with CT Collar Hub, Taper Pin and CU Spring Blade. Valve Lock Operating Arm, fitted with pin for CV Roller and Taper Valve Lock Roller. Valve Lock Block on NN Exhaust ML CW Rod, fitted with Taper Pin and Brass Contact Screw. CO Valve Lock Shaft Bracket on Cylin-NG Valve Lock Shaft Bracket on Cylin-Cap Screws for either CO or CP SVG Brackets. NC-C Exhaust Valve. Exhaust Valve. Collar on Exhaust Valve for NE NN Exhaust Valve Nut.
Exhaust Valve Cotter (5 to 40 HP). NR Exhaust Valve Taper Pin (50 and 60 NA-C Exhaust Shell (5 to 25 HP Type). Exhaust Shell, fitted with Studs for NB Flange. Nuts for NB Flange Studs. Exhaust Shell Cap.
Exhaust Shell Cap Asbestos Gasket. Exhaust Shell Cap to N Shell Cap Screws. Exhaust Shell Pipe Flange. Exhaust Shell Pipe Flange Asbestos Exhaust Shell Valve Guide. Exhaust Shell Valve Guide to N Exhaust Valve, fitted with NL Collar, NR Nut and Cotter. Exhaust Valve Spring. NA-C Exhaust Shell (32 to 60 HP Type).

Exhaust Shell, fitted with NQ Valve
Guide Bushing, Studs for NB
Flange and Pipe Plugs.

Nuts for NB Flange Studs (32, 40 UU and 60 HP). Machine Bolts for attaching NB

Flange to N Shell (50 HP only).

INSTRUCTIONS—FAIRBANKS-MORSE ENGINES

Water Reservoir Packing Nut. Exhaust Valve, fitted with NL Col- VAW Water Reservoir Throttle Valve lar, NR Nut, and Cotter or Taper Stem with VDW Dial Handle. Water Reservoir Throttle Valve Exhaust Valve Spring. Water Reservoir Throttle Valve Pointer Mach. Screw. NAD-C Exhaust Shell fitted with Water Reservoir Vent Pipe. Valve Guide (5 to 25 HP). Water Reservoir Drain Plug. Exhaust Shell, fitted with Studs for Water Reservoir Brass Bushing 1" x NB Flange. Exhaust Shell Valve Guide. Water Reservoir Brass Bushing 3" x Exhaust Shell Valve Guide to N Shell Cap Screws. VQW Water Reservoir Pipe and Fittings. SQG-C Governor Detent. SUG-C Exhaust Rocker Arm (5 SQG Governor Detent Catch, fltted with QF Roller Pin and CL Eye Screw. to 40 HP Type). Exhaust Rocker Arm. Governor Detent Roller on QF Pin. Exhaust Rocker Arm Cap Screws in RDG Bracket with CM Eyescrew (5 to 40 HP). Nuts for Exhaust Rocker Arm Cap Evescrew in KK Base for CA Detent Spring on 50 and 60 HP. (Detent Exhaust Rocker Arm Catch Pin. Bracket cast on base.) Flat Head Capscrew for attaching Taper Pin for SVG Pin. Exhaust Rocker Arm Roller on SVG RDG to KK (5 to 40 HP). Pin. Hex. Head Capscrews for attaching RDG to KK (5 to 40 HP). SUG-C Exhaust Rocker Arm (50 and 60 HP Type). Pin in RDG Bracket for SQG Detent Catch Cotter for TQ Pin (5 to 40 HP). Nut for TQ Pin (50 and 60 HP). Exhaust Rocker Arm, fitted with Studs for CY Catch Plate. Nuts for CY Catch Plate Studs. Gov. Detent Catch Spring. Detent Catch Plate on SUG Arm. FH3G-C Brass Barrel Gas Starter Pin through SUG Arm and NN Rod. Pump (5 and 7 HP Type). Collar on SZ Pin. Starter Pump Cylinder. Taper Pin through ML Collar. Starter Pump Base. Pin in SUG Arm for NG Roller. FG3 Starter Pump Ca Nut for SS Pin. Cap to Cyl. RHM Screws. Exhaust Rocker Arm Roller on SS Starter Pump Piston (Lower Half) Pin. Starter Pump Piston (Upper Half). Roller on SVG Pin. Starter Pump Piston Leathers. Roller Pin for NGG Roller. FI3 Starter Pump Piston Rod and Han-Roller Pin Taper Pin. FB3 Starter Pump Admission Valve. FN3 Starter Pump Admission Valve Seat. NN-C Exhaust Rod. Starter Pump Discharge Valve. Starter Pump Discharge Valve Seat. Exhaust Rod. Exhaust Rod Guide. Starter Pump Discharge Valve FJ3 Exhaust Rod Guide to X Cylinder Spring. Starter Pump Mixer Valve Seat with Cap Screws. FU3 Bushing and FT3 Valve. Mach. Screws to attach FS3 to FR3. SW-C Exhaust Rocker Arm Pin Starter Pump to Engine Capscrews. in KK Base. FGG-C Cast Iron Gas Starter Pump Exhaust Rocker Arm Pin. Exhaust Rocker Arm Pin Nut (32 with Lever Handle (10 to 25 to 60 HP). HP Type). Exhaust Rocker Arm Pin Collar. Starter Pump Barrel. Exhaust Rocker Arm Pin Collar Ta- FG Starter Pump Cap. per Pin- (All sizes except 32 and Cap to F Barrel Mach. Screws. 40 HP). Starter Pump Piston (Lower Half). Exhaust Rocker Arm Pin Collar Starter Pump Piston (Upper Half). Dowel (32 and 40 HP). Exhaust Rocker Arm Pin Collar Starter Pump Piston Leathers. Starter Pump Piston Rod. Mach. Screw (32 and 40 HP). Starter Pump Piston Rod End. FAA Starter Pump Piston Rod End Pin and Cotters. JA-C Gear Box. Starter Pump Lever Handle. Gear Box and Cap, fitted with Oil Starter Pump Link. Starter Pump Link Pin and Cotters. Tube. Gear Box to KK Base Collar Studs. Starter Pump Suction and Discharge Nuts for JC Collar Studs. Ball Valves. Starter Pump Suction Valve Seat. Starter Pump Plug Fitted with Mach. Screw to hold Discharge Valve in Half Nuts for JC Collar Studs. Gear Box Oil Cup Cover. Gear Box Oil Cup Cover Rivet (10 to 40 HP). Place. Gear Box Oil Cup Cover Spring (10 FS Starter Pump Mixer Valve Seat with to 40 HP).
Gear Box Oil Cup Cover Spring FU Bushing and FT Valve. Mach. Screws to attach FS to F. Starter Pump to Engine Capscrews. Screw (10 to 40 HP).

INSTRUCTIONS No. 2072M

FOR SETTING UP AND OPERATING

FAIRBANKS-MORSE

TYPE "T"

Small Vertical Gasoline Engines with Hit-and-Miss Governor

This book should be carefully read before attempting to do anything with the engine




Fig. VE1637

Fig. VE1607

Jack of All Trades and 2, 4, 6, 9 and 12 H. P. Vertical Engines

FAIRBANKS, MORSE & CO.

(INCORPORATED)

(Copyright, 1916, Fairbanks, Morse & Co.)

FAIRBANKS, MORSE & CO.

Chicago, Ill.

Atlanta, Ga. Baltimore, Md. Boston, Mass. Buenos Aires Cincinnati, Ohio Cleveland, Ohio Denver, Colo. Des Moines, Iowa Detroit, Mich. Indianapolis, Ind. Jacksonville, Fla. Kansas City, Mo. London Los Angeles, Cal.



Louisville, Ky. Milwaukee, Wis. Minneapolis, Minn. New Orleans, La. New York, N. Y. Omaha, Neb. Portland, Ore. Salt Lake City, Utah San Francisco, Cal: Seattle, Wash. Spokane, Wash. St. Louis, Mo. St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited

Montreal Calgary Edmonton Hamilton Ottawa Quebec

Saskatoon St. John, N. B. Toronto Vancouver Victoria Winnipeg




Chart "H."

Vertical Section Showing Inlet Valve and Principal Working Parts.




Chart "J."

Vertical Section Showing Exhaust Valve and Principal Working Parts.

Instructions—Fairbanks-Morse Type "T" Gasoline Engines 1 2072M

INSTRUCTIONS No. 2072M

For Setting Up and Operating Fairbanks-Morse Type "T" Small Vertical and Jack of All Trades Gasoline Engines with Hit-and-Miss Governor

General Description.

The Fairbanks-Morse Type "T" Vertical and Jack of All Trades engines with hit-and-miss governors, have cylinders placed on top of the oil-tight base. The bearings run in an oil bath, and lubrication of the piston is effected by the centrifugal force of the crank which distributes the oil on the inside of the cylinder and perfectly lubricates the same. The whole is dust proof. The engines are equipped with "make and break" Descript electric ignition and can be operated with gasoline, petrol, naphtha, distillate, or gas with very little change in equipment.

The Jack of All Trades is complete in itself, engine, cooling tank, fuel tank and necessary fittings mounted on wood base, all connected and ready to run.

Locating Engine.


In locating the engine, at least two feet of space should be left on all sides of the engine for convenience in Space starting and for having sufficient room to get to the valves and connections.

Having a thin bed of cement and fine sand to finish top of foundation, set the engine on its foundation, as per foundation plan, draw down bolts, keeping engine level.

The Fairbanks-Morse Vertical Engine runs in the direction of arrow shown on fly-wheel, page 3. The Direction direction of motion is also shown by the direction of an arrow, cast on one side of the engine base.

Clean Out Pipe.

See that all pipes which are to be used have been carefully washed out with gasoline, to remove all scale Read and foreign matter. All openings and attachments are tagged with directions how to connect and operate. Be All Tags careful to follow directions on each tag.



Showing Water Connections Using Running Water




Chart No. 1189GN Showing Connections for Evaporator Tank and Fuel Tank in Base.

Water Tanks.

Full Size

The opening for water inlet pipe is near lower end of cylinder, and if cooling tank is used, the pipe (2) con-Pipe necting this opening with bottom of tank should be full size of this opening, and connected as shown. Flexible couplings (9) are furnished and should be used in pipes (2) and (3). The water outlet pipe (3) is in the cylinder head. If tank is used connect this with upper opening in tank. When tank used is of our standard dimensions the temperature will regulate itself under ordinary conditions. Tank should not be covered, as water should have exposure to atmosphere. It should be so arranged that the water can be drained from cylinder and connecting Freezing pipes, to prevent freezing and bursting in cold weather. Be sure to leave open end of pipe (5) over cylinder high enough to be above top of tank. In operation, the water must always be above the upper pipe in the tank, otherwise the water cannot circulate.

nside Valves

To obviate the necessity of draining tank entirely in freezing weather when engine is idle, the valves (6) and (7) may be placed inside the tank. This arrangement requires special fittings and nipples with sufficiently long thread to extend through bushing in tanks and allow two or three inches of water between valves and side of tank. These valves are then operated by key rod from top of tank.

To Drain Cylinder Elevated

To drain cylinder and pipe connections, close valves (6) and (7) and open valve (4).

The water circulation will be much better if the cooling tank can be elevated at least enough to bring Tanks the bottom above the lower water opening on the engine cylinder. We advise doing this where possible, as the power of the engine will be slightly increased by this improved circulation. If the tank is not set close to the engine, one size larger pipe should be used between the tank and the engine.

Evaporator Tank.

When equipped with evaporator tank, engine is regularly sent out piped as per Chart 1189GN

Boiling

In operating the engine, the tank should not be filled more than three-fourths full of water; otherwise Water water will slop out more or less after it becomes boiling hot. The water level should never be allowed to fall as low as the top of the cylinder, as the cylinder will then get too hot. It should be understood that it is expected that the water will boil, but that the engine will work properly when the water is boiling hot. The rate of evaporation is from 3/10 to 6/10 gallons per horse-power hour, depending on the load. Arrangements must be made to replenish the water occasionally as it is boiled away.

Drain Tank

In cold weather, the water should be drained from evaporator tank, when engine is idle, to prevent freezing

Running Water.

Regulate Water

If running water is used, place a valve (6) in the inlet pipe (2) close to the engine to regulate quantity of water admitted to the cylinder. Water flowing from cylinder should be from 160 degrees to 180 degrees Fahrenheit, for the maximum power capacity of the engine. To drain cylinder and pipe connections, close valve (7) and open valves (6) and (4).

Instructions—Fairbanks-Morse Type "T" Gasoline Engines 2072M


Exhaust Pipe.

The exhaust pipe from engine to exhaust pot is always shipped fitted for connecting up with the pot.

Long nipple (10) is to be placed in a vertical position and connected to the engine by means of an elbow and a horizontal nipple. On the two and four H. P. sizes this vertical nipple is screwed into a flange on the exhaust pot. On other sizes the vertical nipple is threaded on one end only, the end not threaded extending down through an expansion joint into the exhaust pot. This expansion joint is simply a stuffing box, the packing for which is asbestos wicking. This wicking is sent in the box of parts shipped with each engine.

The pipe (11) from the exhaust pot to open air should be the same size as openings in pot when straight, and larger for long and crooked runs; never use smaller pipe. It is dangerous to exhaust into any house flue.

Engines on wood bases are not equipped with exhaust pots, but are provided with silencers, shipped, piped up complete with engine. When installed in a house, additional pipe should be used in order to carry silencer Silencer outside of the building. Use a "T" on bottom of all upright exhaust pipes, with a drain fitted in the bottom of "T," as water collects in long pipes.



*Fuel Tank (H).

The fuel tank may be located outside of building, (Chart 663GN1) and should be placed in a horizontal position and sufficiently lower than the engine so that the oil will flow toward the tank from the engine. Anywhere from six to twenty-four inches drop will do. With this tank are furnished the proper connections for outlet and return pipe, which are carefully marked before shipping. Use the size pipe furnished. In connecting the fuel tank with engine, care must be taken to wash out every piece of pipe or joint with gasoline—this to remove all scale and loose matter, which, if left in pipes, would interfere with proper working of valves. Extra care must be taken in making all water and fuel pipe connections so they do not leak. Use soap or shellac in joints of fuel pipes and white lead in joints of water pipes.

Where gasoline engines are installed in basements, or in case where the engine room floor is below general level from which the gasoline tank will be filled, care should be taken to have the top of the gasoline tank slightly below the level of the engine room floor. In case the top of the filling pipe, connected to engine tank has to be above the level of the gasoline reservoir in the engine, the gasoline tank should be fitted with a Float reliable float device which will close the filling pipe before the tank is completely full. This float device will give warning so that the fuel will not overflow into the engine room in case there are any loose joints. Fuel tanks fitted with this float device will be furnished on special orders only.

*The word "fuel" in this instruction book applies to gasoline, petrol or naphtha.

2072M Instructions Fairbanks-Morse Type "T" Gasoline Engines

Tank in Base

Vent

When engine is equipped with evaporator tank, the fuel tank is regularly placed in the base of the engine (Chart 1189 GN) and is shipped piped up complete. Care should be taken to see that the cap on the fuel tank filler pipe is not screwed down to cover vent

Fuel Piping

hole in the side of the filler pipe so the air cannot enter tank and maintain atmospheric pressure on the fuel. The fuel pump (E) of the vertical engine is on the side of the engine base opposite the governor. To the bottom of pump is connected the suction pipe (O) from fuel supply tank (H) and the opening where this pipe should be connected is carefully tagged. From the pump the fuel is delivered to the small reservoir (P) on the cylinder head through the pipe (N) and the larger pipe (U) leading from the bottom of this reservoir is the overflow or return pipe for fuel. On the 9 and 12 H. P. sizes this pipe projects upward Extra Care and above the bottom of the reservoir inside and MUST NEVER BE DISTURBED, as it holds the fuel at the proper height in the reservoir, the fuel level on the other sizes is maintained by the peculiar construction

Avoid Traps

in Pipe

The engine is shipped with union attached to lower end of this pipe, and to this union connect return pipe (U) and carry down to floor or through floor, as required, and back to fuel tank with a gradual descent to assist free flow of surplus fuel back to tank.

Having all piping connected, it will be well to make yourself familiar with the following details, which describe all essential parts of the engine in their proper condition, and when all parts are connected as here described, the engine is sure to run.

DESCRIPTION AND INSTRUCTION AS TO THE ACTION AND CARE OF PARTS OF THE ENGINE

Fuel Inlet or Suction Valve.

of the reservoir.

Cotter Pin

This is an ordinary check valve, automatic in its action, located in the cylinder head. The lift is limited by means of a spring on the stem of the valve and a cotter pin through the nut on stem. Should this pin ever need renewing, care must be taken that the new pin is no longer than the original one, for if longer the ends will strike the side wall of shield (D) and the working of valve will be interfered with. The collar nut must be so set (except on 2 H. P.) as to hold valve closed when the catch (S) is down, as is the case when the engine is governing. Should the engine at any time on starting turn too easily or have lost the usual compression, it is evident that a leak is taking place, and this valve should be examined; it may not seat perfectly. This valve can be examined by taking out the screws and removing the shield (D). This will expose valve stem, and by working the valve, you can tell whether it works free, and by revolving backward and forward, clean the seat. Lost On again putting the parts together, care must be taken that they are not twisted and that they do not bind Compression the valve stem. Look at this very carefully. Also see that catch works free and locks valve, preventing all movement when exhaust valve is held open by governor.

Exhaust Valve.

To Replace Head


This valve is constructed same as the inlet valve, also stands in a vertical position, with the stem extend-To Reseat ing through the casing, and a spring over the stem to hold it to its seat. The nut holds the spring under compression. Should there be a lack of compression, after making sure the leak is not in inlet valve, examination of the exhaust valve must be made to see that it does not leak. To clean this valve remove cylinder head from cylinder. Then the valve can be removed from the head, and the seat can be cleaned by revolving the valve while being pressed to its seat in the head. To reseat, grind with emery and oil by revolving valve on seat until it will hold compression. Carefully clean both valve and seat with gasoline before replacing cylinder head. Use gasket of asbestos soaked in boiled linseed oil to insure tight joint, and be sure that the nuts on the studs holding cylinder head to cylinder are turned tight.

Fuel Pump (E). (Page 3.)

The small fuel pump (E) which supplies the reservoir (P) through pipe (N) is operated from the large gear shaft taking supply from Fuel Pump tank through pipe (O). The proper amount of fuel is maintained in the reservoir by an overflow pipe (U), which returns to fuel tank (H). Keep lubricating oil in cup on cap of pump to lubricate packing. Never screw cap down hard or the packing will cut the pump plunger.

Air Suction.

The suction action of piston draws air through air inlet passage. By the swift velocity of this in-going air, sufficient oil is picked up and drawn through a small nozzle, which extends into the passage, to form an explosive mixture.



Instructions—Fairbanks-Morse Type "T" Gasoline Engines 2072M

The Governor.

The governor on the gear shaft controls movement of exhaust valve and also locks the inlet valve in its seated position by the vertical rod and catch (S). When the governor is not in action, the arm (S) is lifted clear of the collar nut on stem of inlet valve within the shield (D). The valve lock (S) is not fitted to the 2 H. P. size.

Throttle Valve.

Throttle or needle valve (146) (see page 8) on 9 and 12 H. P. has a stuffing box (141) like the fuel pump, Throttle but in this case the gland should be kept drawn up tightly, so the valve will not turn from a set point while the engine is running. The function of this valve is to shut off the supply of fuel to the engine when engine is stopped and for regulating by set point, the proper quantity to be fed to engine to obtain the best results while running, The marks on dial were found best on our test floor but it may be necessary to set differently after a time.

INSTRUCTIONS FOR STARTING THE ENGINE

IMPORTANT. BEFORE starting engine, examine carefully and be sure that the nuts on study Importa holding cylinder head to cylinder are turned tight.

REPEAT this the first few times the engine is allowed to become cold, and whenever it has stood idle Avoid Le a considerable time. Attention to these points will prevent annoyances from leaks which otherwise might result from unequal expansion and contraction of metal and the drying and shrinking of gaskets.

How to Start the Engine.

Suppose the engine to be set, connected and ready to start. First see that all outside grease is removed and engine clean, fuel in the tank, and all parts properly oiled (see page 5).

Pump fuel into reservoir attached to cylinder head. The pump is worked by the handle (L) on the pump Fill Rese plunger link. Operating this rapidly will soon fill the reservoir. Open throttle valve on reservoir to point marked "1," set igniter at late spark (see page 15) on 6, 9, and 12 H. P., close air damper about two-thirds off and CLOSE SWITCH ON BATTERY.

Engines 2 to 6 H. P., inclusive, are provided with starter crank. Turn engine fly-wheels backward till you come against strong compression. This allows two revolutions of the fly-wheel before coming against the compression again. Engage the ratchet in crank-shaft key-way and turn rapidly (SO THAT THE FLY. WHEEL TURNS IN THE DIRECTION INDICATED BY THE ARROW CAST ON BASE) until the first ignition occurs; then remove the crank,

Engines 9 and 12 H. P. are provided with relief cam to relieve compression. When starting (1) drop handle of relief cam, which is located on the rocker arm which carries the exhaust rod and roller, to a horizontal position. (2) Grasp arm of fly-wheel and turn engine over as with starter crank. (3) After regular explosions occur, return relief cam handle to the vertical position.

In all cases, as soon as engine starts, set igniter at early spark (see page 15), open air damper and turn throttle valve back to point marked "2," which is the running point of the engine as tested at the factory. The conditions under which the engine operates in the field may somewhat differ from those prevailing on the test floor. The operator will, therefore, use some discretion as to the exact point at which the throttle valve will give the best results. If point "2" does not seem to afford just the right supply of fuel, turn the throttle a trifle, using a very little less or a very little more, and with a little experience the operator will soon determine what is the best setting for the valve. If too much fuel is used, a slow-burning mixture is formed, which does not develop the power that the proper m xture should, and if too little fuel is used, the mixture is too weak to develop

the power required. The machine to be driven should be detached from the engine until the engine is in motion Proper M either by shifting of belt to loose pulley, by slacking of belt by means of tightener, or by friction clutch pulley.

It may be necessary, at times, to throttle the air when taking in the first charge of fuel, by partially restricting the air suction opening with the hand, or with the damper in the air suction pipe.

The 9 and 12 H. P. engines are fitted with a small priming cup tapped into the air suction passage of the head.

This cup is to be filled about three-fourths full with gasoline before starting. Then, when engine is ready to start, this gasoline is allowed to run into the air suction passage where on first suction stroke it is drawn into Priming the cylinder with the air, making a mixture for the first explosion.

To stop engine, close the throttle valve and open switch on battery. In cold weather water should always be drained from engine cylinder and pipes to prevent freezing and bursting of same.

Close both cocks on water tank; then open the drain cock near the bottom of tank, and by so doing allow cylinder and pipe connections to be drained.

DIRECTIONS FOR CLEANING AND TAKING APART

Cleaning Pistons and Rings. (See page 9.)

Occasionally it may become necessary to remove the piston for the purpose of cleaning the rings, which may have become baked fast to piston and prevent the engine from holding its compression, if the proper amount or quality of lubricating oil has not been used. To remove the piston, take off hand hole plate (4) (page 9) To Remove from base, and remove cotters, oil dipper and nuts (28) from connecting rod studs. Now remove the bushing Piston

Drain W From Cvl

2072M Instructions Fairbanks-Morse Type "T" Gasoline Engines

cap (27A) and turn crank shaft so that wrist pin is in lowest position. Remove cotters and ear joint pin (81), and let exhaust rod (71) recline; also remove nut and washer (106) from igniter rod guide stud and slip igniter pawl block (100B or D)clear of same and allow igniter rod (98) to recline, being careful not to lose igniter slide bushing (105). Disconnect unions just below reservoir and remove the nuts from the studs which hold cylinder to base. Now cylinder may be lifted clear of the base and the piston withdrawn. In replacing piston, care must be taken to replace it in the same position as formerly. Care must also be taken to replace all parts in the reverse order from which they are removed and in the same positions. Spread all cotters and replace defective gaskets. The gaskets between cylinder and base and between hand hole plate and base may be of heavy paper.

To Remove Rings

The piston rings should be soaked with kerosene oil (for this is found best), and loosened up and grooves cleaned. Oil piston well before replacing it in cylinder. The rings can be removed by taking three strips of tin one-half inch wide and six inches long; slip one strip under each end of a ring; then take a third strip and slip it under the middle of the ring; the ring can then be slipped out of the groove and both cleaned and the ring replaced; then treat others in the same way.

Note the following conditions required to assure perfect working of engine:

Fuel Supply

See that the fuel pump on engine works perfectly and that lubricating oil is always kept in cup ontop of fuel pump. Each time, before starting, pump by hand until fuel flows into reservoir and back to tank. This is evidence that check valves are all right.

Inlet and Exhaust Valves.

Be sure that these valves are working properly. When turning the engine by hand, if compression is Valves strong, the valves are tight. After the engine has been standing some time, it is advisable to insert a wire nail in the small hole drilled in shield and lift the suction valve off the seat to insure its working free.

If necessary to put in any new gaskets, be sure to soak the gasket in boiled linseed oil. This will insure a tight joint; whereas, if gasket is put in dry, it is more liable to blow out. Use asbestos gaskets only in all joints in the combustion chamber.

Clean

Strainers

Mineral Oil

Oil Cup

A wire screen is attached to end of suction pipe in fuel tank, to prevent any foreign substances from entering pump and reservoir. These may become clogged and require cleaning.

Lubricating Oil.

Never start engine without having first oiled all parts well with hand oil can, and see that there is plenty of oil in the cups on cylinder and journal of the large gear.

With these conditions the engine is sure to work easily.


The oil used for lubricating the piston must be strictly mineral, free from vegetable or animal matter, of a high fire test, and fluid enough to be fed by the oiler. We recommend our "Hytest" Gas Engine Oil. Steam engine cylinder oil is too thick.

Compression grease cups are furnished on the main bearings of Hit and Miss Governor Engines of 2 to 6 H. P. and in these should be used a good grade of hard oil or grease.

Splash Oiler.

Engines with H. & M. Governor are regularly furnished with Splash Oiler (B) for piston pin and crank pin. On the foot of the engine base are two openings closed by pipe plugs, (see cut below). The lower opening (D) is horizontal and is to drain the oil from the base (A), the upper opening (E) is vertical and is used Oil in Base for filling. Oil should be put in until the ends of connecting rod bolts (C) will just touch the surface when the crank is down. This can be seen by removing one of the hand hole plates (F). Before replacing, note the height of the oil in the opening (E) and it will not be necessary to again remove the hand hole plate when filling.

The sight feed oil cup on the lower part of the engine cylinder, which oils the piston, constantly supplies oil to the base, so it will seldom be necessary to introduce oil as above described.



Instructions—Fairbanks-Morse Type "T" Gasoline Engines 2072M

REPAIR LIST

For Fairbanks-Morse Vertical Type "T" Gasoline Engines with Hit and Miss Governor

When ordering parts for repairs, give the description as given in this list by both numbers and names of parts wanted; also the style, number (which is stamped on cylinder head and cylinder at joint, also on patent plate) and horse-power of the engine for which the parts are wanted. Too much care cannot be taken in giving these particulars

The number followed by "C" at the head of each paragraph covers all items mentioned in that paragraph.

Before ordering a complete group of parts by the number in heavy type at head of paragraph, carefully check over such paragraph to make sure that all parts included therein are wanted, as they will all be furnished unless otherwise specified

The figure in parenthesis shows the number used on the engine. The repair symbol covers one piece.

egardl	ess of the number on the engine.	on the	engine. The repair symbol covers one piece,
NO.	DESCRIPTION.	No.	DESCRIPTION
	1-C. Cylinder.		9-C. Cylinder Head.
	Cylinder always fitted with:	9	Cylinder Head, fitted with 86 Igniter Studs
	Burner Hole Plug. 86 Igniter Studs (2 to 9 H. P.) (2).	PATE	(2) on 12 H. P.
	Cylinder Head Short Studs (2 on 2, 4	54K-C	C Suction Valve Complete (2 H. P.). Suction Valve Complete (4 to 12 H. P.).
	Cylinder Head Short Studs (2 on 2, 4 and 6 H. P., 4 on 9 and 12 H. P.).	61	Suction Valve Spring.
1	Cylinder Head Long Studs (2). 566 Patent Plate.	57-C	Suction Valve Cover Complete (4 to 12 H.P.).
	Patent Plate Machine Screws (4).	65-C 67	Exhaust Valve Complete. Exhaust Valve Spring.
	Patent Plate Rubber Washers (4).	01	Exhaust varve Spring.
	PipePlug forWaterOpening(4 to 12 H.P.). Pipe Plug for Oiler Opening.	191	B-C. Crankshaft with Fly-wheels and
30-C	Piston Complete with 33 Rings, 31 Pin, etc.	121	Pinion.
	Nuts for Cylinder Head Studs (4 on 2, 4 and	12B	Crankshaft.
	6 H. P., 6 on 9 and 12 H. P.).	13B	Fly-wheel (Governor Side) fitted with 119 Pinion Pin and 22 Clamp Bolt and Nuts.
	Nuts for Igniter Studs (2).	13	Fly-wheel (opposite Governor Side) fitted
-	C. Engine Crank Base (2 to 6 H. P.) [Engine Crank Base always fitted with:		with 22 Clamp Bolt and Nuts.
	3 Main Bearing Bushing.	21 118	Fly-wheel Keys (2).
	78 Exhaust Rocker Arm Pin with 79 Collar	110	Pinion an Crankshaft.
	and 80 Pin. Exhaust Rocker Arm Pin Set Screw.		14 C. Perller
7	50 Detent Spring Eyescrew.	14	Pulley.
	Cylinder Studs (4 on 2 and 4 H. P., 6 on		Pulley to Fly-wheel Machine Rolts (3 on 2
	6 H. P.). Bearing Plate Cap Screws.		and 4 H. P., 6 on 6 and 9 H. P.).
	Hand Hole Plate Cap Screws (8).		Pulley Key (12 H. P.). Pulley Key Set Screw (12 H. P.).
9	Pripe Plugs in Base (2).		
2	Bearing Plate fitted with 3 Main Bearing Bushing.		15B-C. Starter Crank (2 to 6 H. P.)
4	Hand Hole Plates (2).	15B	Starter Crank.
	Nuts for Cylinder Studs (4 on 2 and 4 H. P.,	16A	Starter Crank Pawl.
7-0	6 on 6, 9 and 12 H. P.). Engine Crank Base (9 and 12 H. P.)	17A 23	Starter Crank Pawl Pin with Cotters (2). Starter Crank Pawl Spring.
1-0	Engine Crank Base always fitted with:	20	Starter Crank I awr Spring.
	285 Main Bearing Cap.		
	286) 287) Main Bearing Bushing Complete with	24	Connecting Rod Oil Splasher. Connecting Rod Oil Splasher Nut (9 and 12
	287 Main Bearing Bushing Complete with Ring.		H. P.).
	Main Bearing Bushing Ring Machine		
	Screws (2). 289 Main Bearing Bushing Felt Washer.		25A-C Connecting Red
	289 Main Bearing Bushing Felt Washer. 290 Main Bearing Bushing Steel Washers(2).	25A	25A-C. Connecting Rod. Connecting Rod.
7 .	78 Exhaust Rocker Arm Pin with 79 Collar	25A 27A	Connecting Rod. Connecting Rod Cap.
	and 80 Pin. Exhaust Rocker Arm Pin Set Screw.	28A	Connecting Rod Bolts with Nuts, Half Nuts
	50 Detent Spring Eyescrew.	26A	and Cotters (2).
	Main Bearing Cap Studs (4).	26B	Connecting Rod Crank Pin Bushing.
	Main Bearing Cap Stud Nuts (4).	29A	Connecting Rod Piston Pin Bushing.
	Main Bearing Cap Stud Half Nuts (4). Main Bearing Cap Cap Screws (3).	610	Connecting Rod Shims (4 on 2, 4 and 6 H. P., 8 on 9 and 12 H. P.).
	Cylinder Studs (6).		8 on 9 and 12 11. F.).
	Bearing Plate Studs (8). Hand Hole Plate Studs (8).		
	Rand Hole Flate Study (8).	26A	A-C. Connecting Rod with Crank Pin Bearing Only.
	Bearing Plate always fitted with:	25A	Connecting Rod.
	285 Main Bearing Cap. 286)	25A 27A	Connecting Rod Cap.
	287 Main Bearing Bushing Complete with	28A	Connecting Rod Bolts with Nuts, Half Nuts
	[288] Ring.	26A	and Cotters (2).
9	Main Bearing Bushing Ring Machine	26B	Connecting Rod Crank Pin Bushing.

Main Bearing Bushing Felt Washer.
Main Bearing Bushing Steel Washers (2).

Main Bearing Cap Stud Half Nuts (4). Main Bearing Cap Screws (3).

Main Bearing Cap Studs (4). Main Bearing Cap Stud Nuts (4).

Nuts for Hand Hole Plate Studs (8). Nuts for Bearing Plate Studs (8).


Hand Hole Plates (2

29A-C. Connecting Rod with Piston Pin Bushing Only.

Connecting Rod Shims (4 on 2, 4 and 6 H. P.,

Connecting Rod. Connecting Rod Piston Pin Bushing.

8 on 9 and 12 H. P.).



45-0 gowing Lateret Keley

No.	DESCRIPTION.	No.		
30	Piston Cttod with Pi		85E-C. Igniter (1914 Pattern).	
	Piston fitted with Piston Pin Set Screws (and Nuts (2), and Piston Pin Set Screws (2)	(2)		
33	(3 on 2 4 and 6 H D	ns		The state of the s
00	Piston Rings (3 on 2, 4 and 6 H. P., 4 on 9 and 12 H.P.). 12 H.P.).	nd .	94E Movable Electrode Stop Pin. Spring Pin. Igniter Contact Screw.	
31	Piston Pin.	87E		
	36-C. Lower Base.		204E Fixed Flootrode Contact River with:	
36	Lower Base fitted with Dans 1 To	208E 207E		
	Screws (4) on 2, 4 and 6 H. P., and with Base to Engine Ca	h Zoil	lation lation Large Mica Insu-	
	Base to Engine Studs (4) on 9 and 12 H. P.	90E		
	Nuts for Lower Base to Engine Studs (9 and	, 89E	Igniter Fixed Floatrade Call	
	12 H. P.) (4).	a 88E		
	44-C Governor Slave			
44	44-C. Governor Sleeve and Weights.	91E	Igniter Movable Floatrode Collar.	
39 40	GOVernor Weights (2)			
	Cottons (4) Weight Fulcrum Pins (2) with		Igniter Movable Electrode Contact Screw.	
42	Governor Springs (2).	93E		
43	Governor Spring Eyebolts (2). Governor Spring Eyebolts (2).	97E	Spring. Igniter Movable Electrode Collar Spring. Dupley Wire Connector	
	Governor Spring Eyebolts (2).	623E	Duplex Wire Connector.	
	45-C. Governor Detent.	00	98-C. Igniter Rod	
	Governor Detent Rooker almost Culture	98	Igniter Rod. Igniter Rod Nut.	
45	51 Governor Detent Blade.	1001	B-C. Igniter Slide (1999 D. 14	
46	Governor Detent Roller Pin.		B-C. Igniter Slide (1908 Pattern) 6, 9 and 12 H. P.	
47		100B 99B	Igniter Slide. Igniter Slide Pawl.	
49	Cotters (2). Governor Detent Spring.	101B	Igniter Slide Pawl Facontrio Di-	
	Governor Detent Spring.	84B	12 III Ler Slide Pawl Facontrie Di- Cu a .	
	Suction Valve (4 to 12 H. P.)		Screws (2)	
54		102B	Igniter Slide Pawl Ston Stud	
	Nut and Cotter.		Igniter Slide Pawl Stop Stud Nut.	
	54K-C. Suction Valve (2 H. P.)	103B	Igniter Slide Pawl Spring.	100
54K	valve fitted with 5064 Washer and	104	Igniter Slide Stud.	
	Cotter.	106	Igniter Slide Pawl Stop Stud Lock Nut. Igniter Slide Pawl Spring. Igniter Slide Stud. Igniter Slide Stud Bushing. Igniter Slide Stud Washer. Igniter Slide Stud Washer.	
57-	C. Suction Valve Cover (4 to 12 H. P.)		Temoci Sinde Stud Niit.	
57		1001	O-C. Igniter Slide (1914 Pattern) 2 and	
	Suction Valve Cover Machine Screws (3 on 4 and 6 H. P., 4 on 9 and 12 H. P.). Suction Valve Lock fitted with 2.	100D	Igniter Slide.	
58	Suction Valve Lock fitted with Spring Pin.	99B 101	Igniter Slide Pawl	
59 60	Suction Valve Lock Pin with Cotters (2). Suction Valve Lock Spring.		Igniter Slide Pawl Pin. Igniter Slide Pawl Pin Nut.	
	valve Lock Spring.	102B	Igniter Slide Pawl Pin Nut. Igniter Slide Pawl Stop Stud.	
	65-C. Exhaust Valve.		Igniter Slide Pawl Stop Stud Nut.	
65	Exhaust Valve fitted with 66 Nut and Cotter.	103B 104	Igniter Slide Pawl Spring.	
		105	Igniter Slide Stud. Igniter Slide Stud Ducking	
69	-C. Exhaust Rocker Lever Bracket.	100	Igitter Slide Stud Washer	
73	Exhaust Rocker Lever Bracket.		ighter Side Stud Nut.	
		108	108-C. Circuit Breaker.	
	Exhaust Rocker Lever Fulcrum Pin. Exhaust Rocker Lever Fulcrum Pin Nut.		Circuit Breaker Contact Arm fitted with 110A Bottom Insulation Block and Brass Contact Saroy	1
		109	Contact Screw.	1 . 10 4
1 1	71-C. Exhaust Rod.	110	Circuit Breaker Thumb Nut. Circuit Breaker Top Insulation Block. Circuit Breaker to Engine Machine Greater	9.8
1	Exhaust Rod Nut	(2 Control to Engine Machine Screws (2)	V.
#	Xhaust Rod Dad		115-C. Governor Machanian	
	Exhaust Rod End Pin with Cotters (2).	44-C	Jovernor Gear and Shaft Complete.	
77-C.	Exhaust Rocker Arm (2 to 6 H. P.)	116 E	Governor Sleeve and Weights Complete. Exhaust Cam fitted with Key, and with	1
7 E		122 G	Exhaust Cam fitted with Key, and with 116B Relief Cam on 9 and 12 H. P.	
	August Rocker Arm Dell.	G	Gear Shart Pump Pin Cotter	
	Exhaust Rocker Arm Roller Pin. Exhaust Rocker Arm Roller Pin Taper Pin.	12	20-C. Governor Gear and Shaft	1
77A-C	. Exhaust Pooleon Anna	1	overnor Gear Shaft always fitted with:	
A E	xhaust Rocker Arm (9 and 12 H. P.)		dovernor Gear Shart Collar with 121	
	Xhaust Rocker Anna D. II. D.			
-	andust Hocker Arm Rollor Di- T	- (30	7 Governor Gear Shaft Pump Pin (6, 9 and 12 H.P.).	
R	elief Cam Levon Sat S.	1204	130A-C. Fuel Pump Link	LL.
R		130A Fu 129A Fu	lei Fump Link.	
Re	elief Cam Lever Stop Pin. elief Cam Lever Collar.	128A Fu	nel Pump Lever, nel Pump Link and Lever Pin with Cotters	
		PARTY OF THE PARTY	(2).	March Co. C. Company

Instructions—Fairbanks-Morse Type "T" Gasoline Engines 11 2072M

			2072M
NO.	DESCRIPTION	I NO.	
1341	B Fuel Pump Body with 529 Brass Pipe Plug on 2 to 6 H. P.	532	Fuel Reservoir Overflow Pipe and Union.
136 137	Fuel Pump Bushing (0) 50 77	569	Cylinder Oiler Piping.
133A 139A	Fuel Pump Can Can (2 to 6 H. P.) (2).	571	Base Drain Piping.
132A	Fuel Pump Plunger	572	Exhaust Silencer Piping.
131A 130A	-C Fuel Pump Link Complete Cotters (2).	574	Air Suction Damper.
	Fuel Pump Body to Engine Cap Screws (2).	575	Priming Cup (6, 9 and 12 H.P.).
	144-C. Fuel Reservoir (2 to 6 H. P.) Fuel Reservoir Body always fitted with:		577-C. Evaporator Tank.
144	576 Fuel Reservoir Cover.	577	Evaporator Tank
	Fuel Reservoir Brass Pipe Plug.	578	Evaporator Tank to Engine Studs (2). Evaporator Tank Piping.
146 149	Fuel Reservoir Throttle Valve.	579	Base Vent Piping (6, 9 and 12 H.P.).
	- 201 to Engine Cap Screws (2).	580	Gear Shaft Grease Cups (2).
144	144-C. Fuel Reservoir (9 and 12 H. P.) Fuel Reservoir Body fitted with Brass Tube Nozzles and 520 Brass Bi	581	Wrench for Connecting Rod Bolts (2 to 6 H.P.).
141	Fuel Reservoir Packing N.	582	Main Bearing Oiler Piping (9 and 12 H. P.)(2).
142 146	Fuel Reservoir Packing Gland. Fuel Reservoir Throttle Valve.		
143			Exhaust Pot.
150 532	Fuel Reservoir Vary Di		Exhaust Pot, fitted with Pipe Plug on 6, 9 and 12 H. P.
334	Fuel Reservoir Overflow Pipe and Union. Fuel Reservoir to 151 Cap Screws (2).		Exhaust Pot Cover, fitted with Studs (2) for Gland on 6, 9 and 12 H. P.
151	I-C. Air Suction Pining (A and to T. P.)		Nuts (2) for Gland Studs (6, 9 and 12 H.P.). Exhaust Pot to Cover Machine Bolts and
151	Air Suction Piping (9 and 12 H. P.) Air Suction Ell with 1 Pipe Plug. Air Suction Lll to Engine Con Server (2)		
574	Air Suction Ell to Engine Cap Screws (2). Air Suction Damper.		Exhaust Pot to Cover Asbestos Gasket. Exhaust Pot Gland (6, 9 and 12 H.P.).
505	Main Bearing Grease Cups (2 to 6 H. P.) (2).		(6. 9 and 12 H P)
505	Main Bearing Oilers (9 and 12 H.P.) (2).		Exhaust Pot Pipe Flange (6, 9 and 12 H. P.) Exhaust Pot Pipe Flange Gasket (6, 9 and 12 H. P.)
510	Cylinder Head Gasket.		H.P.). Exhaust Pot Pipe Flange Cap Screws (6, 9 and 12 H.P.).
511	Igniter Asbestos Gasket.		and 12 H. P.) (2).
511B			Complete Set of Springs.
01110	Igniter Copper Asbestos Gasket.	61 67	Spring for Suction Valve. Spring for Exhaust Valve.
515	515-C. Exhaust Silencer. Exhaust Silencer Base.	23 42	Opring for Starter Cronl- Down
516	Exhaust Silencer Con	49	Spring for Governor Weights (2).
527	Exhaust Silencer Cap to Base Bolts (2). Cylinder Oiler.	60 447	Spring for Suction Valve Lock (4 to 12 H.P.).
30	Fuel Pining from Pump to B	93E 97E	Spring for Movable Electrode Pawl.
31	Fuel Pump Suction Fitting	103B 127A 149	Spring for Fuel Pump Link. Spring for Fuel Reservoir Throttle Velve (2)
			to 6 H.P.).

INDEX OF REPAIR NUMBERS AND GROUPS

Repair	Group				
No.	No.	Name of Part	Repair	Group	
1	1-C	Cylinder.	No.	No.	Name of Part
2 3 4 7	7-C 7-C 7-C	Bearing Plate. Main Bearing Bushing. Hand Hole Plate.	25A	$\left\{ egin{array}{l} 25 { m A-C} \ 26 { m A-C} \ 29 { m A-C} \end{array} ight.$	Connecting Rod.
7 9	7-C 9-C	Crank Base. Cylinder Head.	26A	$\left\{\begin{array}{c} 25\text{A-C} \\ 26\text{A-C} \end{array}\right.$	Connecting Rod Crank Pin Bushing—Cap Half.
12B 13	12B-C 12B-C	Crankshaft.	26B	25A-C 26A-C	Connecting Rod Crank Pin Bush-
13B	12B-C	Fly-wheel (opposite Governor Side).	27A {	25A-C 26A-C	ing—Rod Half. Connecting Rod Cap.
14 15B	14-C 15B-C	Pulley. Starter Crank.	28A {	25A-C 26A-C	Connecting Rod Bolt.
16A 17A	15B-C 15B-C	Starter Crank Pawl	29A {	25A-C 29A-C	Connecting Rod Piston Pin Bushing,
21 22	12B-C	Fly-wheel Key	30 31		Piston. Piston Pin.
23 24	15B-C	Fly-wheel Clamp Bolt. Starter Crank Pawl Spring.	33 36	30-C	Piston Ring.
		Connecting Rod Oil Splasher.	38		Lower Base. Governor Detent Roller Pin.

Repair No.

39

40 42

43 44 45

46 47

49

71

72

84B

85E

87E

88E

89E 90E

91E 92E 93E

94E

97E

99B

100B

100D

101B

102B

103B

104

105

106

108

109

110

110A

115

101

98

86

No.

44-C

45-C

45-C

54K-C

54-C 57-C 57-C 57-C

77A-C 7-C

100B-C

1-C 9-C

85E-C 85E-C

85E-C

100B-C 100D-C

100B-C

100D-C

100D-C

100B-C

100B-C 100D-C

100B-C

100B-C

100B-C

100D-C

100B-C

100D-C

108-C

108-C

108-C

120-C

100D-C

Name of Part Governor Weight, Governor Weight Fulcrum Pin.

Governor Detent Roller. Governor Detent Rocker Fulcrum

Governor Spring.

Pin.

Pin.

Exhaust Rod.

Stop Spring. Igniter Body.

Igniter Stud.

Spring.
Igniter Rod.

Igniter Slide.

Igniter Slide Pawl.

Igniter Slide Stud.

Block.

tion Block.

Governor Gear.

Igniter Slide. Igniter Slide Pawl Pin.

Suction Valve.

Suction Valve Nut. Suction Valve Cover.

Suction Valve Lock. Suction Valve Lock Pin.
Suction Valve Lock Spring.
Suction Valve Spring.
Exhaust Valve.

Governor Spring Eyebolt. Governor Sleeve. Governor Detent Rocker.

Governor Detent Spring.

Detent Spring Lyescrew.

Governor Detent Blade.

Suction Valve Lock Nut. Suction Valve.

Exhaust Valve Nut.
Exhaust Valve Spring.
Exhaust Rocker Lever Bracket. Exhaust Rocker Lever Fulcrum

Exhaust Rocker Arm Roller.

Exhaust Rocker Arm Roller Pin. Exhaust Rocker Arm Roller Pin.

Exhaust Rocker Arm Pin. Exhaust Rocker Arm Pin Collar. Exhaust Rocker Arm Pin Collar

Exhaust Rod End Pin. Igniter Slide Pawl Eccentric Pin

Igniter Fixed Electrode Thumb

Nut.
Igniter Fixed Electrode Collar.
Igniter Fixed Electrode Small
Mica Insulation.
Igniter Movable Electrode.
Igniter Movable Electrode Pawl.
Igniter Movable Electrode Pawl
Return Spring.
Igniter Movable Electrode Pawl
Return Spring.

Return Spring Pin.
Igniter Movable Electrode Collar.
Igniter Movable Electrode Collar

Igniter Slide Pawl Eccentric Pin.

Igniter Slide Pawl Stop Stud.

Igniter Slide Pawl Spring.

Igniter Slide Stud Bushing.

Igniter Slide Stud Washer.

Circuit Breaker Contact Arm.

Circuit Breaker Thumb Nut.

Circuit Breaker Top Insulation

Circuit Breaker Bottom Insula-

Exhaust Rocker Lever.

Exhaust Rocker Arm.

Igniter Fixed Electrode.

Exhaust Rocker Arm.

Exhaust Rod End.


Tors	е туре	"I" Gasoline Engines	
Repa			1
No		Name of Part	
116 116B	115-C 115-C	Exhaust Cam. Relief Cam.	
117	120-C	Governor Gear Shaft.	
118	12B-C	Governor Gear Shaft. Pinion on Crankshaft.	
119 120	12B-C 120-C	Pinion Pin in Fly-wheel. Governor Gear Shaft Collar.	
121	120-(;	Governor Gear Shaft Collar Pin.	
122 124	115-C 120-C	Gear Shaft Pump Pin Washer.	
127A	1304-0	Governor Gear Screw Key.	
128A	130A-C	Fuel Pump Link and Lever Pin.	
129A 130A	130A-C 130A-C	Fuel Pump Link	
131A	134B-C	Fuel Pump Plunger Pin.	
132A 133A	134B-C 134B-C	Governor Gear Screw Key. Fuel Pump Link Spring. Fuel Pump Link and Lever Pin. Fuel Pump Link. Fuel Pump Link. Fuel Pump Plunger Pin. Fuel Pump Plunger. Fuel Pump Can	
134B	134B-C	Fuel Pump Cap. Fuel Pump Body. Fuel Pump Bushing. Fuel Pump Ball Valve. Fuel Pump Packing Gland. Fuel Pump Packing Nut	
136	134B-C	Fuel Pump Bushing.	
137 139A	134B-C 134B-C	Fuel Pump Ball Valve.	
141	144-C	Fuel Reservoir Packing Nut.	
142	144-C	Fuel Reservoir Packing Nut. Fuel Reservoir Packing Gland.	
143	144-C	Fuel Reservoir Throttle Valve Pointer.	
144	144-C	Fuel Reservoir Body. Fuel Reservoir Throttle Valve.	
146 149	144-C 144-C	Fuel Reservoir Throttle Valve. Fuel Reservoir Throttle Valve	
	111-0	Spring.	
150 150	144-C 144-C	Fuel Reservoir Cover (2 to 6 H.P.).	
100	144-0	Fuel Reservoir Vent Pipe (9 and 12 H.P.).	
151	151-C	Air Suction Ell.	
204E 206E	85E-C 85E-C	Igniter Electrode Contact Point. Igniter Movable Electrode Stop	
		Pin.	
207E	85E-C	Igniter Fixed Electrode Large	
208E	85E-C	Mica Insulation. Igniter Fixed Electrode Nut.	
285 286	7-C 7-C	Main Bearing Cap.	4
400	1-0	Main Bearing Bushing—Upper Half.	
287	7-C	Half. Main Bearing Bushing—Lower Half.	
288	7-C	Hall. Main Bearing Rushing Ring	
289	7-C	Main Bearing Bushing Ring. Main Bearing Bushing FeltWasher. Moin Bearing Bushing FeltWasher.	
290 445	7-C 77A-C	Main Bearing BushingSteelWasher.	
147	77A-C	Relief Cam Lever Spring.	
148	77A-C	Relief Cam Lever Stop Pin.	
149 505	77A-C	Main Bearing Grease Cun (2 to 6	
		Main Bearing Bushing SteelWasher. Relief Cam Lever. Relief Cam Lever Spring. Relief Cam Lever Stop Pin. Relief Cam Lever Collar. Main Bearing Grease Cup (2 to 6 H.P.).	
505 506A	54K-C	main Dearing Oner (9 and 12 n.F.).	
507	120-C	Suction Valve Washer. Governor Gear Shaft Pump Pin.	
510		Governor Gear Shaft Pump Pin. Cylinder Head Gasket.	
511 511B		Igniter Asbestos Gasket. Igniter Copper Asbestos Gasket. Exhaust Silencer Base.	
515	515-C	Exhaust Silencer Base.	
16 27	515-C	Exhaust Silencer Cap. Cylinder Oiler.	
29	/134B-C		
30	(144-C)	"Brass Pipe Plug.	
		Fuel Piping from Pump to Reservoir.	
31		Fuel Pump Suction Fittings as	
32	144-C	attached to Pump. Fuel Reservoir Overflow Pipe and	
00		Union. Patent Plate.	
66 69	1-C	Patent Plate. Cylinder Oiler Piping.	
71		Base Drain Piping.	
72 74	151.C	Exhaust Silencer Piping.	
75	151-C	Air Suction Damper. Priming Cup.	
76 77	144-C	Fuel Reservoir Cover Pin.	
78	577-C 577-C	Evaporator Tank. Evaporator Tank Piping.	
79		Base Vent Piping.	
80		Gear Shaft Grease Cup.	
81 82		Wrench for Connecting Rod Bolts.	1
10	∫ 25A-C \	Main Bearing Oiler Piping.	1
LU	1 00+ 01	Connecting Rod Shim	STREET, SQUARE,

26A-C Connecting Rod Shim.


85E-C Duplex Wire Connector.

623E


Instructions—Fairbanks-Morse Type "T" Gasoline Engines 2072M




Pitman Rod End. Lower. 626 Platform Complete with Upright. 255 256 258 259 260 261 262 268 269 273 Pitman Rod End. Upper. 626A Platform Complete less Upright. Upright Brace. Rod Connecting Engine and Base. Gear. Rod Connecting Engine and Base Nuts. Pinion Gear Shaft.
Gear Shaft Bearing.
Gear Shaft Collar and Set Screw.
Wrist Pin and Nut.
Pump Connecting Strap. Walking Beam Pin. Short. 280 284 294 296 Walking Beam Pin. Long. Walking Beam Fulcrum Pin. Walking Beam. Upright Brace at End.



4 H. P. Walking Beam Parts CHART NO. 570GP Gear Shaft Collar and Set Screw. GP453A Pitman Rod End. Upper. Walking Beam Fulcrum Pin Box. Wrist Pin and Nut. Pitman Rod End. Lower. Walking Beam Fulcrum Pin Box Cap. Walking Beam Bushing. Gear Shaft Bearing. Walking Beam Plates. Pitman Rod End Pin. GP444B Gear Shaft Bearing Cap. GP457A **GP458** GP445 Gear Shaft. Pinion-3 H. GP459 Walking Beam Fulcrum Pin. GP451A Pinion-4 H. P GP460A Pitman Rod. GP465A Walking Beam. GP452 Gear.








CHART 215ND7

To get the above setting it may be necessary to lengthen or shorten the exhaust rod, which may be done Exhaust 1 by turning the ear joint which is fastened to the rocker arm on the cylinder head,

Electric Igniter, Mechanically Operated. See page 8.

The casting (85E) is provided with a gasket (511B), acting as a packing between the igniter and head. The fixed electrode (87E) is held between mica washers (90E) placed on each end—a nut clamps this electrode firmly in position. The nut should be kept set tight to prevent the electrode from turning. Special metal Action of contact points (204E) are used in igniter. When the electrode (87E) is in its proper position the point on this Igniter electrode and also on the movable electrode (91E) will be in such a position that as the movable electrode is brought into position by the operating mechanism, the two points are brought together and as the catches release outside of the engine, the points inside of the engine also separate, and a spark is formed between them.

The movable electrode (91E) is in circuit with the engine. Contact is made by means of circuit breaker placed on the cylinder head and acted upon by the exhaust rocker. The movement of the rocker is such that the circuit is completed previous to the closing of points and is held closed sufficiently long to permit the points to separate and form the spark, when the circuit is again opened by a movement of the exhaust rocker. The circuit breaker spring (108) should be kept clean and in such position to form an electrical connection with the engine as above described.


Fig. VE1618

The Movement.

The movement of the loose catch (92E) on the movable electrode is about one-fourth of an inch, sufficient to bring the points together inside of the engine and hold them for a short period, permitting the current to start to flow, and then by continued motion of the rod (98), the igniter pawl (99B), which is carried in the arm, snaps off, allowing the movable electrode (91E) to be returned to its normal position by means of the spring (93E). As this movement takes place and at the instant the points separate, the spark is produced. Motion is given to the igniter rod (98) by means of a crank pin in the end of gear shaft (117).

On 6,9 and 12 H.P. engines the time of ignition, or the separating of the electrode points, which produces the ignition, can be varied by merel y turning the eccentric pin (101B) by means of the flattened handle with thumb and finger. The turning of this pin so as to bring the spring (84B) into the notch provided, which brings the letter "E" into most prominent view, has the effect of making the ignition earlier, and when the letter "L" shows, it has the effect of making the ignition later. This device is used in starting and when the handle of the pin shows the

letter "L," the ignition is so set that it will not spark until the engine is past dead center, and thus avoids the possibility of the engine suddenly turning backward, as it may otherwise do, because of an early ignition, when being slowly turned forward. Be sure to turn the handle to show the letter "E" for an early spark, as soon as the engine speeds up. If this is forgotten, the ignition will be too late, causing loss of power and waste of fuel. The time of ignition can be permanently changed by moving the nuts on the stud (102B).



Parts Used for 3 and 4 H.P. Type "T" Geared Base with Eccentric Gear Shift.

NOS. DESCRIPTION. 4 Base. 8 Eccentric Shaft Box Caps.	
Base 1" Pipe Plug. Eccentric Shaft Box Oil Cup Cover.	
Boothile bhait box off cup cover.	
Gear Shart for Eccentric.	
c D do m	
Gear Shart for Stroke Gear Plate.	
OA Pinion—22 Tooth. 39 Stroke Gear—42 Tooth—9 0 10" Stroke	q
Finion Ney. 39A Stroke Gear—84 Tooth—16 20 24" Strok	700
Gear Shaft Box Cap. 42 Pinion on Gear Shaft for Facentric 15 T	looth
Gear Shaft Box Cap Oil Cup Cover. 60 Stroke Gear Crank Pin and Nut.	00011.

INSTRUCTIONS FOR ADJUSTING, OPERATING AND CLEANING

Instructions for Setting Governor Gear.

Approximate

The approximate setting of the governor gear can most readily be secured by setting engine with crank in horizontal position and toward the exhaust side of the engine. This position may be noted by noticing key. way for fly-wheel, which is in line with the crank and on the same side. Then place the governor gear so that the cam also stands in the same relative position as the crank and mesh the gear and pinion.

Exhaust Valve Opens

A more accurate setting can be obtained by taking note of the following points: The crank shaft of the engine and the gear cam should be in such positions relative to each other that when the crank AB is in the position as shown in Fig. 1 of the Chart 215 ND7, the cam will just begin to open the exhaust valve. The cam should close the exhaust valve when the crank is just above the dead center on the in-stroke, or in about the position as shown on Fig. 2 of the cut. The instant the valve is free from its seat (begins to open), or is seated (closed), Exhaust Valve may be accurately ascertained by rotating the valve slightly with the fingers, grasping the spring collar at the top of the valve stem. The ease of rotation when valve is open or closed is very evident.

Instructions for Setting Electric Igniter. See page 8.

In setting the electric igniter, the igniter pawl (99B) on the sliding block (100B or D) on the side of the cylinder should begin to press against the catch (92E) carried on the movable electrode of the igniter when the crank is Contact horizontal and coming up. This is the position at which the points of the electric igniter should be brought into contact. The igniter should "snap" or spark when the crank is before the dead center coming up and in about Snap Off the position shown on Fig. 3 of the cut (page 15).

The Igniting Point.

Igniting Point

Points

It is easy to determine at what point the ignition takes place by turning the engine slowly in the direction in which it runs and noting the position of the crank (the key is on the same side of shaft and in line with crank) at the moment the pawl (99B) snaps off from the loose catch (92E) on the movable electrode (91E). If corectly set, the position of the crank will be slightly before upper dead center.

The word "spark," stamped on face of fly-wheel, should be opposite the point where it passes the exhaust rod (71) when igniter snaps, while engine is turned over by hand. This is about the best running position. For starting 6, 9 and 12 H. P. set the igniter to snap late, as above.

Renewing

If by continued use the points of contact become worn or corroded, and a good spark cannot be obtained the old plugs containing the points can easily be removed by first filing off the riveted portion of the plugs and then driving them out. New plugs with new contact points can readily be replaced and the plugs lightly riveted over in the electrodes.

Testing Electric Circuit.

To test the electric circuit, turn the engine to a point slightly before the ignition should occur, leaving the igniter pawl (99B) in a position which has brought the contact points (204E) together and thus closed the circuit; then loosen the wire from the insulated electrode (87E) and by striking same on the binding nut (88E) a spark should be produced, thus showing that the current passes through the timer spring (108) and through the engine returning through the insulated electrode (87E). Turn the engine in the direction in which it runs until the pawl (99B) snaps off, then again strike the wire on the nut, and no sparks should occur; but if the wire is struck on any part of the engine, a spark should take place, showing that the current is still passing through the timer spring (108) which does not separate from the exhaust rocker until the engine has turned a considerable distance after the ignition should occur. The switch in the battery box should be closed when testing circuit or when the engine is running, but open at all times when the engine is not running.

Keep Igniter Clean.

To Remove

The igniter will require cleaning from time to time. The conditions will vary this period. Ordinarily, we would say that cleaning would be required each thirty days. In order to remove the Igniter for cleaning remove the pin (101 or 101B) which holds the igniter pawl (99B), thus allowing the pawl to be taken out. Then by loosening the two nuts retaining the igniter body (85E) to the engine cylinder, the igniter can be withdrawn for cleaning. All carbon or corrosion which would interfere with the proper contact of the igniter points should be removed, and any deposit on the mica washers should be brushed off and washers separated and thoroughly washed with gasoline. The hole or opening through the cylinder head will require scraping to remove the deposit of carbon at the inner end, thus preventing short circuiting due to carbon.

The Electric Battery and Connections.

One binding post of the first cell should be connected with the binding post on spark coil, which is packed in the end of the box. The other post on the spark coil has a long conductor wire attached, which should lead to the insulated fixed electrode (87E) of the igniter, at the cylinder head, and from the binding post of the last cell in the battery the wire should lead to the switch attached to the battery box, and the second long conductor wire should lead from the other binding post of the switch to the binding post (109) on the timer spring (108). Always see that the binding posts are clean and thumb nuts turned tight, so as to hold the conductor wires firmly in position, and that no foreign material of any kind gets between the wires and metal of binding posts and nuts. If the above directions have been carefully followed, the arrangement is such that battery is required to operate only at such times as the engine requires ignition, while at all other times the circuit is broken and the battery is at rest, thus adding to its durability and perfect operation.

Inside the battery box will be found a small switch box with lever for opening and closing the circuit. When the switch is open, no current can pass. Care should be taken when the engine is at rest for any length of time to open the switch in battery box, so that in case the engine has stopped at the point where the electric circuit is closed, it will be broken by opening the switch, thereby saving the drain on the battery while the engine is idle.

Test Battery.

The long conductor wires between the battery and engine may be safely handled by the insulation, but avoid touching the bare copper. Having all connections made, close the switch, hold one of the long conductor wires in each hand and strike their ends together. The efficiency with which the battery is working will be indicated by intensity of the spark produced when the wires are separated quickly. If no spark is produced, either the connections are not perfect or short circuit is caused at some point by dirt or foreign material, or the cell is not right. Ascertain the cause and remove it.

If the engine stops for any cause, test the battery immediately to see if you are still getting a good spark. When the battery is nearly exhausted it soon ceases to give a spark after the engine is started and should be renewed.

Instructions for Setting and Connecting the Jack of All Trades with Walking Beam.

This engine is sent out complete, ready to run, it being only necessary to supply gasoline to the gasoline tank, fill the water tank with water, the grease cups with grease and the oil cups with oil; also connect battery wires to igniter and timer spring. Close switch when ready to start.

1st. If the engine is to rest upon the ground, level off same in order to form an even bearing for the base or foundation box to rest upon.

Instructions—Fairbanks-Morse Type "T" Gasoline Engines 2072M

2nd. To obtain the distance above the ground at which to place the platform carrying the engine, raise the pump plunger or sucker rod to the center of the cylinder, or half of the up-stroke; then make measurement from the bolt hole in the pump rod, to which you are to connect the links of the walking beam, down to the ground. The distance from the strap on the walking beam to the bottom side of the engine platform is three feet. Any extra height of the pump over that to the center of links on walking beam must be made up with framework of timbers, or a plank box can be arranged of the proper height, as obtained from the difference between the measurement so made and the three feet as given. This box should be filled with sand or stone. By this means a solid foundation upon which to bolt the platform of the engine will be made. Use five bolts to bolt platform to box or foundation.

3rd. In locating the box, the end of the walking beam, to which the straps are attached, used for driving windmill ar the pump, should be placed directly over the pump rod. The beam must stand in its center or horizontal Engine

4th. If pump is to be worked by windmill, in connection with gasoline engine, the walking beam can be disconnected and swung out of the way, when windmill pole can then be connected in the usual manner to the pump rod. After engine has been placed in proper position in relation to pump, the same should be secured.

Before starting, carefully read all directions contained in this book for standard vertical engines.























(INCORPORATED)

Chicago, Ill.

Atlanta, Ga.
Baltimore, Md.
Boston, Mass.
Buenos Aires
Cincinnati, Ohio
Cleveland, Ohio
Dallas, Tex.
Denver, Colo.
Des Moines, Ia.
Detroit, Mich.
Indianapolis, Ind.
Jacksonville, Fla.
Kansas City, Mo.
London



Los Angeles, Cal.
Louisville, Ky.
Milwaukee, Wis.
Minneapolis, Minn.
New Orleans, La.
New York, N. Y.
Omaha, Neb.
Portland, Ore.
Salt Lake City, Utah
San Francisco, Cal.
Seattle, Wash.
Spokane, Wash.
St. Louis, Mo.
St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited

Calgary
Edmonton
Hamilton
Montreal

Ottawa Quebec Saskatoon St. John, N. B. Toronto Vancouver Victoria Winnipeg Fifth Edition


091701

Instructions No. 2417D

FOR SETTING UP AND OPERATING

Fairbanks-Morse 3 H.P. "Z" 6 H.P. Throttling Governor Oil Engine

This book should be carefully read before attempting to do anything with the engine



6 H. P. Type "Z" Oil Engine

FAIRBANKS, MORSE & CO.

(INCORPORATED)

(Copyright, 1917, Fairbanks, Morse & Co.)

For Setting Up and Operating Fairbanks-Morse 3 and 6 H. P. Type "Z" Oil Engines

INSTRUCTIONS No. 2417D

1. Remove engine from crate, being very careful to avoid damage. In the bundle of parts is the cylinder oil cup which is to be placed on the cylinder is Received. oil pipe (on the "Closed Jacket" Engines a nipple is included which is to be screwed into the cylinder). Put the pulley on the side opposite the governor using the bolts sent. With the Steel Pulleys small clips are furnished to catch inside the rim so the bolts will hold fast. When it is desired to place the pulley on the governor side, it will be necessary to reverse the small dog in the starter crank so as to use it on the other side, the direction of motion always being as shown in Fig. 3375, page 3.

2. If engine is to be located on a foundation, follow the regular foundation plans, Foundation leaving two or three feet of room all round.

3. If the engine is installed in a building the silencer (270A, page 3) may be removed and the exhaust pipe attached and carried outside. It should be short and a Building. with few bends. Water may collect in long exhaust pipes so a small hole or other drain should be provided at the lowest place. When the pipe is long (20 feet) or has several elbows (4) the pipe should be increased in size and better results will be observed if a cast iron exhaust pot is installed near the engine.

4. These engines can use as fuel, Gasoline, Motor Spirits, Kerosene and some Fuel. varieties of Power Distillate. In this book we will call the fuel "oil fuel."

5. Read the tags on the engine but do not remove them until you are familiar Read Tags. with its operation.

Filler Tube, 51

Filler

Filler

Opening



6. Fill fuel tank with the oil fuel to be used regularly, using the tube (51 at the left) and funnel that is packed in the crate. Remove funnel and tube after filling tank.


7. Put water in hopper Cooling Wa but only enough at first to cover top of cylinder. This can be seen through the hole in top of hopper. In cold weather hot water will make the engine easier to start.

8. Fill oil cup (527, Oiling. page 3) with good Gas Engine Oil (we recommend Hytest), and adjust oiler to feed 12 drops per minute on 3 H. P., 20 drops per minute on 6 H. P. Gradually cut down the amount as the engine becomes worn in until in a month one-half the above quantities are


Fill the four grease cups. Two (505, page 3) are on main bearings, a small one is on the cam gear hub (506, page 3). These should be screwed down one or two turns until grease is forced freely into bearings. The fourth one (509, page 3) is on the crank pin bearing. This has a spring plunger that is drawn up to the top by a wing nut on a screw. After filling this cup the wing nut must be screwed back to bring the spring plunger against the grease so that the grease will feed out gradually.

9. With a hand oil can go over the engine and oil the governor and all other Oil by Han places where there are oil holes, and where one part moves against another.

10. Drain the oil fuel from the fuel reservoir (4A, page 2) by unscrewing the over-yvalve (105, page 2) one or two turns, until the oil fuel runs back to tank. Onen flow valve (105, page 2) one or two turns, until the oil fuel runs back to tank. Open



6 H. P. Closed Jacket Type "Z" Engine



6 H. P. Type "Z" Engine Belted to No. 1 Type "G" Feed Grinder

2417D

used.

cover to see when it is drained. When empty close the overflow valve tightly. Fill the reservoir with gasoline for starting and throw the fuel pump out of action by Lock-Out pushing the pump lever (66, below) back away from its driving screw on the exhaust Lever. rod, by means of the lock out lever (75, below). This is located on the cylinder head side of the fuel reservoir.


Fuel Valve.

- 11. Open needle valve (76A, page 9) about one turn.
- 12. Set the "Early and Late" pin (333, page 3) with the mark "L" up, indicating late ignition.

TO START ENGINE.

Starting.

13. Holding the suction or upper valve open with the left hand, with the starter crank spin the engine. After getting the engine in motion, release the suction valve and half close the air inlet opening in bottom of reservoir with fingers of left hand for one revolution only, and then remove fingers while still continuing to crank. If held longer too much fuel will be drawn in. The mixture will not ignite if there is too much fuel in it, and the fuel must be forced out by cranking.



AFTER ENGINE IS STARTED.

14. After the engine takes its first impulse remove the starter crank; after the engine is running nicely adjust the throttle valve. The position at final test on distillate was with the mark straight down, but it should be adjusted to give as little fuel as the engine will run on. The position varies with the fuel and the temperature.

Running on

15. The engine will usually run on oil fuel after using one reservoir full of gasoline. When engine is warm enough to run on oil fuel the fuel pump should be thrown into action by throwing out lock-out lever (75 above). The igniter should be set on running position with the mark E up-this is the point of early ignition. The throttle should be again adjusted to give as little fuel as the engine will run on.

Water Spray.


16. The water throttle valve (219A above) on cylinder head should not be opened except to quiet hard explosions which may be noticed when engine is on heavy continuous load, and only enough to serve the purpose. This valve must be closed a few minutes before stopping engine so that the interior of the cylinder will be dry.

Fill Hopper.

17. Fill water hopper two-thirds full and replenish this water as it evaporates. It is expected to boil away.

TO STOP ENGINE.


18. To stop engine, first close water throttle valve (219A), then close throttle valve (76), then close cylinder oiler (527, page 3), and in freezing weather, drain out the water.




DESCRIPTION OF PARTS OF ENGINE AND MANNER OF ADJUSTMENT.

19. The cam gear is marked with two center punch marks on face of tooth. The pinion (29 above) on crank shaft has one tooth with two center punch marks. This tooth should come between the two marked ones on the large gear. (28 above.)

If engine is taken apart and the marks on gears cannot be found, or if old gear is replaced by a new one, the engine should be timed as follows:



At this position of the crank on the exhaust stroke, the exhaust valve begins to open.



At this position of the crank on the suction stroke, the exhaust valve closes.

Setting Gears.

Place the crank (25A page 3) in a vertical position and pointing up. Then set the cam gear with the nose of the cam straight up. Next see that there is about 1/16" clearance between end of exhaust rod and adjusting screw in the valve rocker arm. Such a setting should bring the valve timing very nearly as described in paragraph 20 below.

Valve Timing.

20. The cam should begin to open the exhaust valve 30° to 35° before outer dead center (Fig. 1833GN). The cam should close the exhaust valve when the crank AB is in the position shown in Fig. 1834GN, or about 5° above the inner dead center. The valve can be turned with the fingers the instant it is lifted from its seat.

Temperature of Cooling

21. While operating engine the hopper should not be filled more than threefourths full of water, otherwise water will splash out more or less when it boils. The water should never be allowed to fall as low as the top of the cylinder wall, as the cylinder will then get too hot. It is to be expected that the water will boil under heavy load and the engine will work properly when the water is boiling. Put in more water as it evaporates.

Engine Jacket

22. The engine jacket is liable to be broken by freezing if water is left in during cold weather unless non-freezing solution is used.

Non-Freezing Solution.

23. A non-freezing mixture of calcium chloride and water may be used in the jacket. Three pounds of calcium chloride to each gallon of water will not freeze solid at zero Fahrenheit. It is advisable, however to drain the jacket in freezing weather when the engine is not in use.

24. Each engine is regularly equipped with a cast iron sub-base (62A, page 3) Fuel Supply. containing a galvanized steel fuel tank (15A, page 8) which is sent out piped up complete. The filler opening (page 1) in tank is on side of engine opposite governor. In filling, use the tin funnel and filler tube (51, page 1) supplied with engine. Replace cap (49, page 1) after filling to prevent water and foreign matter entering and keep small vent hole in cap open. Water will separate from the oil fuel and remain at the bottom, so the tank should be drained occasionally to remove the water.

Suction Valve.

25. The suction valve (9, page 3) is an ordinary check valve, automatic in its action and has a lift of about three-eights of an inch. The lift is limited by means of a spring (310, page 8) on the valve stem. This valve is also fitted with a friction spring (120, page 3) causing a friction on the suction valve spring collar (121, page 3) thus retarding the rapid motion of the valve and preventing noise.

Exhaust

26. The exhaust valve (10, page 3) like the suction valve, lies in a horizontal position with the stem extending through a guide in the cylinder head. A spring held under compression by a washer and pin on both the suction and exhaust valves holds these valves to their seats. If valve stem shows tendency to stick, squirt a little kerosene on the stem and work it back and forth.

27. Should the engine at any time on starting turn too easily or have lost its Lost compression, it is evident that a leak is taking place, and the suction valve as well as exhaust valve should be examined; they may not seat properly. If they do seat properly examine piston (see paragraph 34 below).

28. If it is necessary to reseat the suction or exhaust valve the cylinder head (3, page 3) must be removed and the valve ground with fine abrasive, such as ground glass or emery and oil. Revolve valve on its seat in alternate directions, lifting Valves. from its seat frequently to distribute the abrasive. Carefully clean both valve and seat with gasoline before replacing.

29. Asbestos gaskets hold better if covered with linseed or lubricating oil when Gaskets. applied. After putting on new gasket (190, page 3) the nuts should be tightened again when engine is hot.

30. The governor located on the side of the engine base driven from the cam Action of gear (28, page 3), controls the movement of the butterfly valve (203, page 3) located in the suction passage in the cylinder head.

31. If it is necessary for any reason to reset the butterfly crank arm (206, page 3) it will be well to remove the reservoir first so that the butterfly (203) can be seen. Valve. Pull one governor weight (82, page 3) out as far as it will go and then put a wedge under it to hold it in that position. Take cotter pin out of butterfly crank end of governor rod (205, page 3) remove end of governor rod (205) from crank (206, page 3). Slightly loosen clamp screw of crank (206). Close butterfly with finger and set crank so that governor rod lacks 1/16" from dropping in hole of crank. Next tighten clamp screw of crank (206) and reassemble parts removed. Be sure to remove the wedge from under the governor weight. If the above instructions are followed the engine can under no conditions run away.

32. The governor normally holds the engine at its rated speed, but each engine Decreasing is provided with a speed regulator which decreases the speed by screwing the knurled Engine Spee head screw (224, page 3) in.

REMOVING FUEL PIPING.

33. If it should be necessary to remove fuel piping, be careful in swinging reservoir Piping. and piping out for removal or in replacing same be careful not to bend the fuel nozzle (223, page 2) on the reservoir. The engine would not run properly if the relative position of this nozzle with the governing butterfly valve were changed.

CLEANING PISTON AND RINGS.

34. After some months of use the piston may be removed to clean the rings. To Remove To do this take off oil shield and unbolt crank bearings. Turn crank to extreme Piston. out position. The piston may now be withdrawn. Replace piston in its original position, and all parts in the reverse order from which they were removed. The piston may be cleaned with kerosene or a hot solution of lye and water, the rings loosened and the grooves cleaned. Oil piston well before replacing.

The rings can be removed from piston by taking three strips of tin about one-half inch wide and six inches long, slip one piece of tin under the middle of the ring and over the ring groove, then with the help of a screw driver the other strips can be slipped

under the ends and the rings in turn slipped off the piston.

Cleaning an

Repair Parts List—Fairbanks-Morse Type "Z" Oil Engines

7 2417D

REPAIR PARTS LIST

For Fairbanks-Morse 3 and 6 H. P. Throttling Governor Type "Z" Oil Engines

This list covers 3 H.P. engines after No. 268918 and 6 H.P. engines after No. 267230.

When ordering parts, always give the size, type and **Shop Number** of the engine. The Number is **very important**. It is stamped on the top of the cylinder and cylinder head flanges. **Do not fail to give it**.

Parts may be ordered individually or in groups.

A GROUP NUMBER printed in **HEAVY TYPE**, followed by the letter "C," such as "3-C" covers all items in that paragraph down to the first horizontal line, thus——. An ordinary repair number printed in light type (such as "3"), covers that one part only.

A group may be ordered less certain specified parts, for example "3-C less Nos. 9-C and 10-C."

Any part without a repair number is listed directly after the numbered part with which it is used.

For repairs on 3 H. P. engines previous to No. 185864 and 6 H. P. engines previous to No. 185978, see repair parts and price list No. 9417.


For repairs on 3 H. P. engines between 185864 and 268918, and 6 H. P. engines between 185978 and 267250 see Instructions 2417C.

Repair Nos. Ar- ranged Numer- ically	The of parts	Group Number in heavy type, when shown at the head of a group s, includes all items mentioned in that group.	Included in Group Number	No. of Pieces used for 3 or 6 H. P.
1-C	1 327 328 301 312 313 12 126 195	I-C Cylinder and Base. Cylinder drain plug. Base drain plug. Igniter clamp stud (1). Cylinder to head long stud (1). Cylinder to head short studs (3). Main bearing caps (2). Main bearing cap eap screws (4). Main bearing cap cap screw lock washers (4). Main bearing shims (set of 8). Name plate. Name plate trusber washers (2). Name plate brass machine screws (2).	1-C	1
	22 23	Name plate brass machine screws (2). Main bearing upper liners. Main bearing lower liners. Cylinder to Sub-base Cap Screw.		$\frac{2}{4}$
3-C 3	9-C 10-C 217-C	3-C Cylinder Head. Cylinder head—always fitted with. Butterfly valve. Butterfly valve shaft. Butterfly valve shaft screws (2). Butterfly valve shaft screw lock washers (2). Suction valve—complete. Exhaust valve—complete. Water throttle fitting—complete.	3-C	1 1
4A-C 4A	$\begin{cases} 4A \\ 223 \\ 60 \\ 314 \\ 65-C \\ 66 \\ 67 \\ 75 \\ 76A \\ 311 \\ 105 \\ 302 \\ 300 \\ \end{cases}$	AA-C Combination Fuel Reservoir Reservoir body, always fitted with Reservoir nozzle and bushing. Reservoir opipe plug Reservoir cotter (through boss for 75 lockout lever) Reservoir cover spring. Reservoir fuel pump plunger complete. Reservoir fuel pump plunger lever Reservoir fuel pump plunger lever fulcrum pin with cotter. Reservoir fuel pump plunger lever fulcrum pin with cotter. Reservoir needle valve. Reservoir needle valve spring. Reservoir pump valve Reservoir pump valve Reservoir pump valve Reservoir pump valve Reservoir plunger spring	4A-C	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Repair Nos. Ar- ranged Numer- ically	The of parts	Group Number in heavy type, when shown at the head of a group s, includes all items mentioned in that group.	Included in Group Number	No. of Pieces used for 3 or 6 H. P.
		Reservoir pipe plug Reservoir to cylinder head short cap screw Reservoir to cylinder head long cap screw	4A-C	1 1 1 1
5-C 5 6 7	{ 5 6 7 71 72	5-C Piston. Piston, always fitted with. Piston rings stop pins (3) (not furnished separately). Piston rings. Piston pin taper lock pin. Piston pin taper lock pin. Piston pin taper lock pin serew. Piston pin taper lock pin lock washer.	5-C 5-C	1 1 3 1 1 1 1
9-C 9	9 120 121 88 310	9-C Suction Valve. Suction valve. Suction valve friction spring. Suction valve spring collar. Suction valve spring collar pin. Suction valve spring collar pin. Suction valve spring collar pin tie wire. Suction valve spring.	9-C	1 1 1 1 1 1 1
10-C 10 11	10 11 309 317	10-C Exhaust Valve. Exhaust valve Exhaust valve spring washer Exhaust valve spring washer pin. Exhaust valve spring		1 1 1 1 1
12		Main bearing cap. Main bearing cap cap screw. Main bearing cap cap screw lock washer.	1-C 1-C 1-C	2 4 4
13	{ 13	Flywheel (opposite governor side), always fitted with	}	1
13A	13A 316	Flywheel (governor side), always fitted with. Flywheel clamp bolt. Crankshaft pinion drive pin.	}	1
		Flywheel clamp bolt	13 and 13A	2
14-C 14	14 265 266 267		14-C	1 1 1 1 1
15A	{ 15A 49	Fuel tank always fitted with. Fuel tank Filler cap. Fuel tank drain pipe plug.	}	1
16 17		Oil shield	18-C	1 1 1 1
18-C 18 20	$\left\{\begin{array}{c} 18\\17\\20\\176\\110\\150\\151\end{array}\right.$	Connecting for ordina pin boaring birting (box or roar)	} 18-C 18-C	1 1 1 2 1 set 2 2
21 22 23 24 25A		Fuel return pipe reservoir to tank complete. Main bearing upper liner. Main bearing lower liner Fuel suction pipe pump to tank complete Crank shaft.	1-C 1-C	1 2 2 1 1
28 29		Cam gear Crank shaft pinion		1 1

Repair Nos. Ar- ranged Numer- ically	of parts	Group Number in heavy type, when shown at the head of a groups, includes all items mentioned in that group.	Included in Group Number	No. of Pieces used for 3 or 6 H. P.	•		0	Repair Nos. Ar- ranged Numer- ically	Th of part	ne Group Number in heavy type, when shown at the head of a group ts, includes all items mentioned in that group.	Included in Group Number	No. of Pieces used for 3 or 6 H. P.
30-C 30	30	30-C Cam Gear Pin. Cam gear pin Cam gear pin nut. Cam gear pin lock washer.	30-C 30-C	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		84		66 67 69 71 72		Fuel pump plunger lever. Fuel pump plunger lever fulcrum pin, with cotter. Fuel pump plunger cap. Piston pin taper lock pin. Piston pin taper lock pin.	4A-C 65-C 5-C 5-C	1 1 1 1 1 1 1
33 34 35		Governor weight friction spring. Exhaust rod rocker roller Exhaust rod rocker roller pin, with cotter.	50-C	1 1 1		91		75 76A 79 80 81 82		Piston pin taper lock pin lock washer. Fuel pump plunger lever lockout lever. Fuel reservoir needle valve Governor weight fulcrum pin, with (two) cotters each. Governor plunger pin. Governor hub. Governor weight.	4A-C 4A-C 92-C 92-C 92-C 92-C 92-C	1 1 2 1 1 2 2
36	$\begin{cases} 36\\318\end{cases}$	Exhaust rod, always fitted with. Fuel pump plunger lever drive screw. Fuel pump plunger lever drive screw lock washer.	}	1		*		81 82 83 85 88		Governor lever Governor lever fulcrum pin, with (two) cotters Suction valve spring collar pin	92-C 92-C	1 1 1
39C 39	39 55 329	39-C Exhaust Valve Rccker Arm Exhaust valve rocker arm adjusting screw. Exhaust valve rocker arm adjusting screw nut. Exhaust valve rocker arm adjusting screw lock washer. Exhaust valve rocker arm return spring.		1				92-C 92	92 80 81 82 79 33 321	92-C Governor Governor bracket. Governor plunger pin. Governor hub. Governor weights. Governor weight fulcrum pins, with (two) cotters each. Governor weight friction spring. Governor weight friction spring adjusting screw, with lock nut.	92-C	1 2 2 1
40 41 42 48 49		Exhaust valve rocker arm fulcrum pin. Exhaust valve rocker arm fulcrum pin nut. Exhaust valve rocker arm bracket. Exhaust valve rocker arm bracket screw dowel. Governor gear Fuel tank filler cap.	92-C	1					308 156 48 83 85 209-C 325	Governor weight spring adjusting screw. Governor gear. Governor lever Governor lever fulcrum pin, with (two) cotters. Governor speed regulator. Governor speed regulator fulcrum pin.		1 1 1 1 1
50-C 50	50 58-C 34 35	50-C Exhaust Rod Rocker. Exhaust rod rocker. Exhaust rod rocker fulcrum pin—complete. Exhaust rod rocker roller. Exhaust rod rocker roller pin, with cotter.		1				104 105 106 110 117		Governor bracket to base cap screw. Governor bracket to base cap screw lock washer. Fuel tank strap. Fuel tank strap to base carriage bolt. Fuel reservoir overflow valve. Pulley clips for 3 H. P. Connecting rod crank pin bearing shims (set of four) Pulley.	4A-C 18-C	2 1 2 1
51 52-C		Fuel tank filler tube. 52-C. Plugoscillator Trip Carrier		1				120 121 126		Pulley to flywheel machine bolt. Suction valve friction spring. Suction valve friction spring collar. Main bearing shims (set of eight).	9-C 9-C	3 1 1 1 set
52	\$\begin{cases} 52 \\ 333 \\ 334 \\ 324 \end{cases}\$	52-C Plugoscillator Trip Carrier Plugoscillator trip carrier—always fitted with Plugoscillator trip fulcrum pin. Plugoscillator trip fulcrum pin ring. Plugoscillator trip spring. Plugoscillator trip spring.		1 1 1 1 1		60		139 150 151 156		Igniter clamp. Connecting rod bolt, with cotter only. Connecting rod bolt castle nut. Governor spring adjusting nut.	18-C 92-C	2
55		Exhaust valve rocker arm adjusting screw. Exhaust valve rocker arm adjusting screw nut. Exhaust valve rocker arm adjusting screw lock washer.	39-C 39-C 39-C	1 1 1	物.			157 160 176 190 192 195		Flywheel keys. Opposite governor flywheel to bearing thrust washer. Connecting rod crank pin bearing (halves). Cylinder head gasket. Reservoir to cylinder head gasket. Name plate.	18-C	2 1 2 1 1 1 1 1
58-C 58	58	58-C Exhaust Rod Rocker Fulcrum Pin. Exhaust rod rocker fulcrum pin, with cotter.	58-C	1				100		Name plate rubber washer. Name plate brass machine screw.	1-C 1-C	2 2
	63	Exhaust rod rocker fulcrum pin nut. Exhaust rod rocker fulcrum pin washers (set of five)	58-C	1 1 set				201 203 204		Butterfly valve shaft washer. Butterfly valve Butterfly valve shaft	3-C	1
60 62A 63	144	Reservoir cover. Engine sub-base. Exhaust rod rocker fulcrum pin washers (set of five)	4A-C 58-C	1 1 1set				205 206		Governor lever link with (two) cotters. Butterfly valve shaft lever. Butterfly valve shaft lever clamp screw.		. 1
65-C 65	65 302 69	65-C Fuel Pump Plunger Fuel pump plunger Fuel pump plunger ball valve Fuel pump plunger cap.		1 1 1 1				209-C 209	{209 {222 224	209-C Governor Speed Regulator. Governor speed regulator lever, always fitted with	} 209-C	1 1 1

Repair Nos. Ar- ranged Numer- ically	The Group Number in heavy type, when shown at the head of a group of parts, includes all items mentioned in that group.	Included in Group Number	No. of Pieces used for 3 or 6 H. P.
217-C	217-C Water Throttle Fitting	3-C	1
217	217 Water throttle fitting	217-C	1
218	217 Water throttle fitting. [218 Water throttle tube packing ring always fitted with. [220 Water throttle tube (not furnished separately)	} 217-C	1
219A	311 Water throttle valve spring. 219A Water throttle valve		1 1
220 222 223 224 225	Water throttle tube (not furnished separately). Governor speed regulator leaf spring (not furnished separately). Fuel reservoir nozzle and bushing. Governor speed regulator lever screw. Gear guard.	209-C	1 1 1
226 265 266 267 270-A 271	Exhaust rocker return spring collar and set screw. Starter crank pawl. Starter Crank Pawl Fulcrum pin with (2) cotters. Starter crank pawl spring. Silencer complete with nipple.	14-C 14-C 14-C	1 1 1 1 1
271	Cylinder oiler pipe.		1
300 301	Fuel pump plunger spring. Igniter clamp stud. Igniter clamp stud nut.	4A-C 1-C	1 1 1
302	Fuel pump ball valve.		} 2
308 309 310	Governor weight spring Exhaust valve pin Suction valve spring.	65-C 92-C 10-C 9-C 4A-C	1 1 1
311 312 313	Needle valve spring for either fuel or water valve. Cylinder to head long stud. Cylinder to head short stud. Cylinder to head stud nut.	and 217-C 1-C 1-C 1-C	2 1 3
314 316 317	Fuel reservoir cover spring Flywheel crankshaft pinion drive pin Exhaust valve spring. Fuel pump plunger lever drive screw lock washer	4-C 13A 10-C 36	1 1 1
319 320 321	Exhaust rod return spring. Exhaust valve rocker adjusting screw clamp screw. Governor weight friction spring adjusting screw.	39-C 92-C	1 1 1
324 325	Plugoscillator trip spring	52-C	1
326 327 328 333	Plugoseillator trip spring. Governor speed regulator lever fulcrum pin. Butterfly Valve shaft torsion spring. Cylinder drain plug. Base drain plug. Plugoseillator trip fulcrum pin (not furnished separately).	52-C	1 1 1 1 1
334 505 506 509 510	Plugoscillator trip fulcrum pin ring. Main bearing grease cup. Cam gear grease cup. Connecting rod grease cub. Exhaust valve rocker arm grease cup.		1 1 1 1
527 695 696	Plugoscillator—Complete (for separate repairs on this see Instruction Book No. 2479). Magneto—Complete (for separate repairs on this see Instruction Book No.		1
	2479)		1
	Adjustable wrench. Tin funnel. Hand oiler.		1 1 1



Repair Parts List Model "C" Plugoscillator

For 3 and 6 H. P. Type "Z" Engines

20609 Trip finger.

Always mention the direction of rotation and the serial number when ordering repairs.

	20601	Body only.
-	20604	Trip and break lever.
	20621	Trip and break lever fulcrum pin.
	20603	Magneto crank arm.
	20610	Moveable electrode and point.
	20607	Moveable electrode arm.
	20618	Spring roller pin, long.
	20620	Spring roller pin, short.
1	20602	Spring roller.
	20612	Trip and break lever spring.
	20630	Starting lever.
	20619	Moveable electrode seating spring.
	20615	Moveable electrode arm spring.
	20616	Stationary electrode.
	23288	Spring roller stud spring ring.
	20605	Stationary electrode insulating bushing.
	20608	Stationary electrode special nut.
	20617	Stationary electrode copper gasket (not shown).
W	20800-C	Magneto complete.
•	20624	Magneto fastening screw lock washer.
	20634	Magneto terminal and wire.
	20622	Magneto fastening screw.

Moveable electrode nut.

Moveable electrode woodruff key.

20606 Igniter points.

nown).

20623 Moveable electrode nut lock washer.

20627 Early and late eccentric.
20614 Early and late eccentric plunger spring.
20611 Early and late eccentric plunger.

Model "C" Plugoscillator Used on 3 and 6 H. P. Type "Z" Oil Engines

Trouble Chart—Fairbanks-Morse Type "Z" Oil Engines

15 2417**D**

TROUBLE CHART

	100000	TROODIE OF		
Trouble	Po	essible Cause	Remedy	See Para- graph
Engine Will Not Start	Instruction	s not followed.	Read and follow instructions.	1 to 13
	No fuel in t	ank.	Fill tank.	6
	Water in ga	soline used in starting.	Strain gasoline.	
	Water in ex	saine evlinden	Water will work out if engine is turned over slowly.	13
	water in er	ngine cylinder.	Close water throttle valve before engine stops.	16
			See that gasket is unbroken	29
	Engine Floo	oded	Open suction valve and crank Engine.	13
		Valve leaks.	Grind valve.	28
	Poor Compression	Head gasket leaks.	Put on new gasket.	29
	Compression	Piston blows.	Remove rings and clean.	34
	Engine very	7 cold.	Put but little water (preferably hot water) in hopper.	2
	Igniter Sho	ort Circuited	Take out igniter, clean points.	Inst. 2479
	Igniter Sho	Tr Officialed	See that wire from magneto is not grounded.	Inst. 2479
Engine Misses Fire After	Ignition	Magneto out of time.	Correct.	Inst. 2479
Being Started		Short Circuit.	Clean. See that insulation on wire is good.	Inst. 2479
		el collects in bottom of and fuel tank.	Drain water from reservoir through plug in bottom.	
			Drain water out of tank.	24
Engine Knocks	Hard Explo	sion.	Remove head and clean carbon.	29
			Open water spray.	16
	Loose crank	pin bearing.	Take up bearing.	

	to—Fairballes-Morse Type		24171
Trouble	Possible Cause	Remedy	See Paragraph
Engine Runs Irregularly	Governor stuck.	See that governor parts are free. Use kerosene to loosen. Adjust (33) spring.	
	Weak exhaust valve spring.	Put washer under spring till new spring can be obtained.	
Engine tends To Run Away	Butterfly may not close.	Adjust butterfly crank and governor travel.	31
Engine Will	Exhaust valve setting off.	Reset.	19-20
Not Carry Load	Poor Compression.	See "Engine will not start"	28-29-34
	Late ignition.	Correct.	Inst. 2479
	Too rich mixture.	Close throttle.	14
	Carbon in combustion space.	Remove head and clean.	
	Silencer clogged.	Clean out.	
	Butterfly moved.	Reset.	31
Engine Uses	Throttle open too far.	Close.	14
Too Much Fue	Poor Compression.	See "Engine will not start"	28-29-34
	Late ignition.	Time correctly.	Inst. 2479
	Exhaust valve setting off.	Reset.	19–20
	Exhaust pipe or silencer choked.	Clean.	
	Suction valve friction spring too weak causing oil fuel to drip from suction pipe.	Bend spring or put on new one.	
Carbon forms	Too much fuel	Close throttle.	14
	Too much lubricating oil.	Adjust lubricator.	8
	Engine too cold.	See that engine is hot be- fore turning on oil fuel.	15
Water Boils	Mixture too rich.	Close throttle.	14
Away Too Rapidly	Late ignition.	Correct.	Inst. 2479
		Never let the water get below top of cylinder.	17


Instructions No. 2494

FOR STARTING AND OPERATING

Fairbanks-Morse Type "Z" Horizontal Oil Engines

10 H. P. and Larger

This pamphlet, together with Instructions 2479, covering the magneto should be carefully read before attempting to do anything with the engine



(3396G)

10 H. P. Type "Z" Oil Engine showing Built-in Oscillating Magneto and Throttling Governor

FAIRBANKS, MORSE & CO

(INCORPORATED)

(Copyright, 1918, Fairbanks, Morse & Co.)

FAIRBANKS, MORSE & CO.

(INCORPORATED)

Chicago, Ill.

Atlanta, Ga.
Baltimore, Md.
Boston, Mass.
Buenos Aires
Cincinnati, Ohio
Cleveland, Ohio
Dallas, Tex.
Denver, Colo.
Des Moines, Ia.
Detroit, Mich.
Indianapolis, Ind.
Jacksonville, Fla.
Kansas City, Mo.
London




Los Angeles, Cal.
Louisville, Ky.
Milwaukee, Wis.
Minneapolis, Minn.
New Orleans, La.
New York. N. Y.
Omaha, Neb.
Portland, Ore.
Salt Lake City, Utah
San Francisco, Cal.
Seattle, Wash.
Spokane, Wash.
St. Louis, Mo.
St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited


Calgary
Edmonton
Hamilton
Montreal

Ottawa Quebec Saskatoon St. John, N. B.

Toronto
Vancouver
Victoria
Winnipeg



10 H. P. Type "Z" Portable Oil Engine, showing the Hopper Cooler and Friction Clutch Pulley



15 H. P. Type "Z" Portable Oil Engine, 1918 Pattern, with Screen Cooler

INSTRUCTIONS No. 2494 For Setting up and Operating Fairbanks-Morse Type "Z" Oil Engines

1. Remove engine from crate, being very careful to avoid damage. In the bundle of parts is the cylinder oil cup, which is to be placed on the cylinder. Put the pulley on the side opposite the governor, using the bolts sent. Remove the plugs from the openings in the cylinder and head. Clean all parts.

See that the governor parts are free from dirt or paint.

Oil all moving parts and turn the flywheel over by hand slowly to see that all parts are free.

2. The foundation should be prepared in accordance with foundation plan for Foundation the engine. This drawing gives the location of driving belts and all outside dimensions. A sufficient space, at least two feet, should be allowed on all sizes for easy Leave Space access by the attendant.

Depth of foundation shown is for firm footing and good concrete only. Fairbanks, Morse & Co. will not be responsible for solidity of foundation.

The foundation being prepared, with bolts firmly imbedded and projecting the proper distance, the engine should be set over them and leveled with four wedges. A thin grout of cement and sand should be poured over the top of the foundation, a Level the dam of wet sand around the engine base serving to retain the grout. When thoroughly Engine set, the nuts on the foundation bolts may be tightened. Extreme care must be taken to keep the engine level on the foundation.

3. If the engine is installed in a building the silencer (26A, page 5) may be If Located in removed and the exhaust pipe attached and carried outside. It should be short and with few bends. The silencer must be attached to end of the pipe. Water may collect in long exhaust pipes, so a small hole or other drain should be provided at the lowest place. When the pipe is long (20 feet) or has several elbows (4) the pipe should be increased in size and better results will be observed if a cast-iron exhaust pot is installed near the engine.

4. These engines can use as fuel Gasoline, Motor Spirits, Kerosene and some Fuel varieties of Power Distillate. In this book we will call the fuel "oil fuel."

5. Read the tags on the engine but do not remove them until you are familiar Read Tags with its operation.

6. The usual arrangement for cooling with running water is shown by Chart Cooling by 1844GN. The water supply pipe (2) is connected to the opening in the side of cylinder,

(1844GN)


the cock (4) being provided to regulate the supply to the cylinder jacket.

The water outlet from this jacket is at the top Overflow of the cylinder as shown, the water rising in the pipe (6) and flowing out freely through the overflow pipe (7). The funnel (10) is provided so that the amount and flow of water can readily be seen.

Through the plug (11) the cooling water Drain can be drained from the engine. All water should always be drained, after each run of the engine, when there is even the remotest danger of frost, otherwise a frozen water jacket and cracked cylinder may result.

When Engine

7. Chart 1842GN shows the connection when cooling tank is Cooling used without the use of circulating pump. The water circulation will be much better if the cooling tank can be elevated at least enough to bring the bottom opening of the tank level with the water opening in the engine cylinder. We advise doing this where possible. If the tank is not set close to the engine, one size larger pipe should be used between the tank and the engine. The inlet pipe (2) connecting the opening in the side of cylinder jacket and the lower opening in the tank, should be connected up as shown. Flexible couplings (9) are furnished and should be used in pipe lines (2) and (3). The outlet pipe (3) should be connected up as shown. When tank used is of our standard dimensions, the temperature will regulate itself under ordinary conditions. If conditions should be such that all water is



Pipe Connections for Tank Cooling—Type "Z" Oil Engine (Fig. 1842GN)

Temperature

heated above 180 degrees, the temperature should be lowered by adding cold water to tank. The tank should not be covered, as the water should have exposure to the atmosphere and so arranged that the water can be drained from cylinder and con-Drain necting pipes, to prevent freezing. Plug (11) is provided so that engine cylinder can be drained.


The water in the tank must Height of be above the top of opening in the tank, otherwise the water cannot circulate.

Circulating

8. When a tank is used for Cooling Tank cooling with centrifugal pump for circulating, the connections should be made according to Chart 1843GN. In this case the suction of the centrifugal pump (1) is connected to the bottom of the cooling tank. The pump is attached directly to the engine cylinder and is driven by means of a belt from a pulley on the flywheel. The overflow pipe from the cylinder head is connected to the top opening of the tank.

Temperature

9. When running the engine, Outlet the jacket water supply should be regulated so that the temperature is from 160 degrees to 180 degrees Fahrenheit. The most favorable temperature will be different for




Pipe Connections: Cooling Tank with Circulating Pump— Type "Z" Oil Engine (Fig. 1843GN)

different fuels and some care should be taken to note the temperature at which the operation is best, and an effort made to keep the outlet reasonably close to that

10. The cylinder, tank, pump and piping should be carefully drained, if there is the slightest danger of frost.

Fuel Tank

11. A galvanized iron fuel tank having a capacity of a barrel or more is furnished with each engine, and should be connected as shown on Chart 1845GN.



Fuel Piping-Type "Z" Oil Engine (Fig. 1845GN)

11. The fuel tank may be located outside of the building, as shown, and should be Fuel Tank placed in a horizontal position and sufficiently lower than the engine so that the fuel will flow toward the tank from the engine. Any amount of fall, from six to twentyfour inches, will do. With this tank are furnished the proper connections for outlet and return pipe, which are carefully marked before shipping. Use the size pipe Size of Oil furnished. In connecting the fuel tank with the engine, care must be taken to wash Piping out every piece of pipe or joint with gasoline or kerosene. This removes all scale and loose matter, which, if left in the pipes, would interfere with the proper working of valves. Extra care must be taken in making all water and fuel pipe connections so that they do not leak. Soap or shellac should be used in joints of fuel pipes and white lead in joints of water pipes.

12. When an engine is installed in a basement, or in case the engineroom floor is below the general level from which the fuel tank will be filled, care should be taken to have the top of the fuel tank slightly below the level of the engineroom floor. In case the filling pipe connected to the fuel tank is extended to a point higher than the fuel reservoir on the engine, the fuel tank should be fitted with a reliable float device which will close the filling pipe before the tank is completely full. This float device will give warning so that the fuel will not overflow into the engineroom in case there are any loose joints. Fuel tanks fitted with this float device will be furnished on special orders only.

Installed in

13. Care should be taken to see that the cap on the fuel tank filler pipe is not screwed down so far as to cover the vent hole in the side of the filler pipe. If this vent is covered, the air cannot enter the tank and maintain atmospheric pressure on the fuel.

14. To the bottom of the fuel pump is connected the suction pipe from the supply Fuel Piping tank.

The engine is shipped with a union attached to the lower end of the overflow pipe from the fuel reservoir, and to this union the return pipe is to be connected and carried down to the floor or through the floor, as required, and back to the fuel tank, with a gradual descent, to assist the free flow of surplus fuel back to the fuel tank.

15. The filler pipe is provided with a screen to prevent dirt getting into the tank; see that the screen is cleaned out occasionally.

The fuel suction pipe in the tank is also provided with a screen.

If water collects in the fuel tank, it can be pumped out through the filler pipe opening.

Instructions—Fairbanks-Morse Type "Z" Oil Engines

2494

WHAT TO DO BEFORE STARTING.

Fill Fuel Tank

16. Fill fuel tank with the oil fuel to be used regularly, using funnel that is packed in the crate. Remove funnel after filling tank. Put on cap of filler pipe so vent is

Tighten Nuts

17. Tighten cylinder head nuts.


18. The machine to be driven must be detached from the engine, either by Clutch Pulley shifting of the belt to a loose pulley, by slacking of belt by means of tightener or by friction clutch pulley. This is not necessary with special electric engines.

19. In hopper cooled engine put water in hopper but only enough at first to cover top of cylinder. This can be seen through the hole in top of hopper. In cold weather hot water will make the engine easier to start. For closed jacket engine see that cylinder jacket is full of water before trying to start engine, and there is a supply of running water (paragraph 6), or that cooling tank is filled (paragraph 7). Adjust the water cock on the water inlet pipe so that a small amount of water will circulate through the cylinder jacket, causing the engine to heat up quickly after it is started.

20. Fill oil cup (527, page 6) with good Gas Engine Oil (we recommend Hytest), oiling and adjust oiler to feed 25 drops per minute on 10 H. P., 35 drops per minute on 15 H. P. See that the plug in the filling opening is provided with good gasket and screwed in tight, to prevent the oil being blown back. Gradually cut down the amount as the engine becomes worn in, until in a month one-half the above quantities are used. Fill the five grease cups. Two (505, page 6) are on main bearings; small ones are on the cam gear (506, page 6) and governor bracket (507, page 6). These should be screwed down one or two turns until grease is forced freely into bearings. The fifth one (509, page 6) is on the crank pin bearing. This has a spring plunger that is drawn up to the top by a wing nut on a screw. After filling this cup the wing nut must be screwed back to bring the spring plunger against the grease so that the grease will feed out gradually.

Oil By Hand

21. With a hand oil can go over the engine and oil the governor and all other places where there are oil holes, and where one part moves against another.



(Fig. 3402G)

22. Close oil throttle (76A), open cover (60), fill gasoline compartment with Gasoline for Starting gasoline.

Air Damper

23. Close air damper (61).

24. Open gasoline needle valve (76B, page 9) about one turn.

Fuel Valve

25. Set the "Early and Late" pin (333, page 6) with the mark "L" up, indicating late ignition.

26. Make sure that igniter is properly timed. Read carefully Instructions 2479 Igniter

before attempting to start engine.

TO START ENGINE.

27. Turn nose of cam down. Set crank just above inner dead center. Fill priming cup full of gasoline and open the cock admitting this fuel into the cylinder. Priming Cup While the priming cup is still open, turn the flywheels in the direction they run, thus drawing air into the cylinder, making an explosive mixture. Turn the flywheels in the direction they run and when the igniter snaps the first impulse will take place. . The force of this impulse will keep the engine in motion until the next charge is drawn in through the starting valve.

ANOTHER METHOD OF STARTING ENGINE.

28. Turn nose of cam up. Set crank just above inner dead center. Cock the igniter or magneto with hand firing lever. Fill priming cup full of gasoline and open the cock admitting this fuel into the cylinder. While the priming cup is still open turn the flywheels in the direction they run one-half revolution, thus drawing air into the cylinder, making an explosive mixture. Close priming cup. Turn engine backward as strongly as possible, compressing the mixture and at the same moment, when the flywheels are stopped by the compression, trip the igniter by pushing the hand lever toward the head. A strong explosion will result if a good mixture and considerable compression have been obtained. This method requires more skill than the preceding method, and there is danger of injury if one does not let go of the flywheels just before tripping the igniter.

29. Too much fuel used in starting (particularly with a hot engine) will flood Flooded the engine. When flooded relieve the compression by holding suction valve open with the finger and turn the flywheel over a number of revolutions in order to blow out the excess fuel.

AFTER THE ENGINE IS STARTED.

30. Open air damper.

Air Damper

31. Turn early and late pin so that the letter (E) is up, indicating the early or Early and L running position.

32. Close the priming cup on side of cylinder.

Cock

33. Adjust the gasoline throttle valve until the engine runs smoothly.

Gasoline


34. When the circulating water has reached the temperature of about 120 to 140 degrees F., gradually open the oil throttle valve and close the gasoline valve until the engine is hot enough to run well on the oil fuel alone. It is well to have the gasoline throttle slightly open. The handle of the oil fuel throttle valve is marked at the factory when the engine is tested. The mark should generally point to the center of the gasoline throttle valve when the engine is in operation. But depending upon various influences, the engine may operate best with slightly different setting. After closing gasoline throttle, the oil throttle valve should again be adjusted until the engine operates smoothly.

35. The water throttle valve (185) should not be opened until the engine is about up to full load and then care should be taken not to admit too much water. With a Water Sprag little practice the operator can readily determine the amount of water required by the operation of the engine.

TO STOP ENGINE.

To Stop

36. To stop engine, first close water throttle valve (185), then close throttle valve (76A), then close cylinder oiler (527), and in freezing weather drain out the water. Turn the engine over until the exhaust valve is closed. This is a precaution against the formation of rust on the cylinder walls and exhaust valves in case the engine stands idle for some time.



(3401G)

DESCRIPTION OF PARTS OF ENGINE AND MANNER OF ADJUSTMENT.

Suction Valve

37. The suction valve (9A) is an ordinary check valve, automatic in its action and has a lift of about three-eights of an inch. The lift is limited by means of a spring (310) on the valve stem. This valve is also fitted with a drag spring (120), causing a friction on the suction valve spring collar (121), thus retarding the rapid. motion of the valve and preventing noise. Oil friction spring and collar.

Exhaust Valve

38. The exhaust valve (10A), like the suction valve, lies in a horizontal position with the stem extending through a guide in the cylinder head. A spring held under compression by a washer and pin on both the suction and exhaust valves holds these valves to their seats. If valve stem shows tendency to stick, squirt a little kerosene on the stem and work it back and forth. Then oil with lubricating oil.

Compression

39. Should the engine at any time on starting turn too easily or have lost its compression, it is evident that a leak is taking place, and the suction valve as well as exhaust valve should be examined; they may not seat properly. If they do seat properly, examine piston (see paragraph 42).

40. If it is necessary to reseat the suction or exhaust valve the cylinder head (3A) must be removed and the valve ground with fine abrasive, such as ground glass or Regrinding emery and oil. Revolve valve on its seat in alternate directions, lifting from its seat frequently to distribute the abrasive. Carefully clean both valve and seat with gasoline before replacing.

41. Asbestos gaskets hold better if covered with linseed or lubricating oil when applied. Before applying gasket scrape off all traces of old gasket. After putting on new gasket (190) the nuts should be tightened again when engine is hot.

unbolt crank bearings. Turn crank to extreme out position. To Remove Piston

moved to clean the rings. To do this take off oil shield and The piston may now be withdrawn. Replace piston in its original position, and all parts in the reverse order from which they were removed. The piston may be cleaned with kerosene or a hot solution of lye and water, the rings loosened and the grooves cleaned. Oil piston well before replacing. In replacing piston turn it bottom side up so that the piston ring stop pins can be seen, otherwise the rings may be

(3383G)

broken. Be sure to turn it right side up before connecting up connecting rod, otherwise the pin will get no oil. The rings can be removed from piston by taking three strips of tin about one-half inch wide and six inches long, slip one piece of tin under the middle of the ring and over the ring groove, then with the help of a screw driver the other strips can be slipped under the ends and the rings in

42. After some months of use the piston may be re-

43. To remove piston pin (7A) use screw driver to take out taper dowel pin screw (72A). Force out taper dowel pin (71) from Piston Pin inside of hollow pin. This allows the pin to be driven out. In returning parts be sure to put the lock pin lock washer in between the lock pin and screw.

44. The piston pin is hollow, of hardened steel and ground to exact size, and will wear very little. Its bearing is of special phosphor bronze. After long use, if Piston Pin necessary, it can be replaced by driving out the bushing, then inserting a new one Renewal furnished to exact dimensions. After the connecting rod and piston pin are replaced in the piston, care should be taken to see that the oil tube leading from the top of the piston is directly over oil hole in connecting rod.

turn slipped off the piston.

Speed regulator adjusting screw 224 Speed regulator 209 Grease adjusting screw 321 vernor weight drag spring 3 pin 80A Governor weight fulcrum pin 79A Governor weight 82A (3413G)

45. The governor, located on the side of the engine base, Governor driven from the cam gear (28), controls the movement of the butterfly valve (203), located in the suction passage on the cylinder head. The governor is fitted with Drag spring a drag spring (33), the purpose of which is to steady the governor action. The force of the spring can be easily adjusted by small screw (312). If there is too much tension the governor will be slow to respond to change in load. If not enough tension, the engine will race.

Action of Governor The grease cup (507) lubricates the governor hub, and should be filled occasionally. The governor weight pins (79A) requires oiling with hand oil can.


Butterfl;

46. If it is necessary for any reason to reset the butterfly crank arm (206A), it will be well to remove the reservoir first so that the butterfly (203) can be seen. Take cotter pin out of butterfly crank end of the governor rod (205) remove end of governor rod (205) from crank (206A). Pull one governor weight (82A) out as far as it will go and then put a wedge under it to hold it in that position. Slightly loosen clamp screw of crank (206A). Close butterfly with finger and set crank so that governor rod lacks 1/16" from dropping in hole of crank. Tighten clamp screw of crank (206A) remove wedge from under governor weight and reassemble parts removed. If the above instructions are followed the engine can, under no condition, run away.

Decreasing Engine Speed 47. The governor normally holds the engine at its rated speed, but each engine is provided with a speed regulator (209) which decreases the speed by screwing the knurled head screw (224) in. It is not intended that the engine be run continually at a slow speed.

Water Reservoir

48. The water reservoir Fig. 3414G is bolted to the cylinder head and is for the purpose of allowing a fine spray of water to be Machine drawn in with the mixture. The water enters the reservoir from an opening in the cylinder head. A screen (187) prevents entrance of sediment. A float valve (181) controls the flow of water into reservoir. The water enters the suction passage through nozzle (186). The amount of water is regulated by the throttle valve (185). This throttle valve should not be opened until the engine has been running some time and until the load calls for it. Set the valve so that no more water is used than will make engine run



nicely. The effect of the water spray is to moderate the force of the explosion. Too much water will reduce the power.

The water throttle valve should be closed a few minutes before stopping the engine so as to have the interior surface of the cylinder dry and clean. The water spray is only of service when the engine is running at about full load. When the engine load falls to about one-half of its power, or below, the water should be entirely cut off to prevent the suction valve from rusting and also to prevent sediment from being deposited upon the points of the igniter. This can be done by pressing down float valve (181) and swinging lock (179) over top of stem. The reservoir can be drained by removing plug (330).

Rain Water

49. In some cases the water from this reservoir causes a troublesome deposit, particularly about the exhaust valve. In such cases rain water may be used, or some simple arrangement may be made for distilling enough water for this use, by using the heat from the exhaust pipe.

(Continued on page 19)

PEPAIR PARTS LIST

For Fairbanks-Morse Type "Z" Horizontal Oil Engines 10 H. P. and Larger—1918 Pattern

This List covers 10 H.P. engines after No. 315526 and 15 H.P. engines after No. 318933. When ordering parts, always give the size or horsepower, type and shop number of the engine. The number is very important. It is stamped on the top of the base and cylinder. Do not fail to give it.

Parts may be ordered in groups, or individually, except where noted.

A Group Number printed in heavy type, followed by the letter "C," such as "3A-C Cylinder Head," covers all items in that paragraph down to the first horizontal line.

An ordinary repair number printed in light type (such as "33") covers that part only, including any parts which are "always fitted" to it. For example: In Group 92A-C, No. 33, 321 or 83, covers one part only, but "33" covers the part No. 33 and all parts "always fitted" to it.

A group may be ordered, less certain specified parts. For example: "92A-C, less Nos. 33 and 83."

Any part without a repair number is listed directly after the numbered part with which it is used.

For engines before No. 315526, see Instruction Book 2410C.

Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
1A	1A-C Cylinder. Cylinder, always fitted with head studs, base studs, igniter clamp stud (301), drain plug (327), name plate (195), name plate screws and rubber washers. Piston (5A-C).	1	
	Cylinder to head long studs. Cylinder to head short studs. Cylinder to head stud nuts. Cylinder to base studs. Cylinder to base stud nuts.	1 4 5 6 6	1A-C 1A-C
2Å	2A-C Base. Base, always fitted with drain plug (328), main bearing caps (12A), main bearing cap, cap screws and lock washers, main bearing shims (126 B and C), exhaust rocker fulcrum pin (58A). Main bearing liners (23).	1	
3A	3A-C Cylinder Head	1 1	
	Cylinder head to reservoir studs	2 2	3A-C
4A	4A-C Fuel Reservoir	1	


Before ordering parts, read the instructions above.

10 2494	Repair Parts List—Fairbanks-Morse Type "Z	' Oil	Engines	
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.	1
5A	Piston, always fitted with ring stop pins. Piston rings (6), piston pin (7A), dowel pin (71), dowel pin screw (72A), lock washer.	1	1A-C	
6 7A	Piston rings. Piston pin.	3 1	5A-C 5A-C	
9A	Suction valve. Suction valve drag spring (120), spring collar (121), spring collar lock (122), suction valve spring (310).	1 1	3A-C	
10A	Exhaust valve. Exhaust valve spring collar (11A), spring collar lock (122), exhaust valve spring (317).	1 1	3A-C	
11A 12A	Exhaust valve spring collar. Main bearing cap. Main bearing cap, cap screws. Main bearing cap, cap screw lock washers.	1 2 4 4	10A-C 2A-C 2A-C 2A-C	
13	Flywheel (opposite governor side), always fitted with clamp stud (400) and nuts, flywheel key (158)	1		
13A	Flywheel (governor side), always fitted with clamp stud (400) and nuts, flywheel key (157)	1		
14 16A 17A	Pulley (on standard engines only) Pulley to flywheel machine bolts Oil shield Oil shield to base cap screw. Connecting rod piston pin bushing.	1 6 1 1 1 1 1 1	18-C	N.
18	18-C Connecting Rod. Connecting rod, always fitted with piston pin bushing (17A), crank pin liner dowel (19), cap (20) bolts (32) with nuts (151) and cotters, shims (110 and 110A). Connecting rod crank pin liner halves (176).	1		
19 20 23	Crankpin liner dowel Connecting rod cap Main bearing liner half	1 1 4	18-C 18-C 2A-C	
25	25A-C Crank Shaft	1 1		
26A	Silencer complete (for 10 H. P. only)	1		
26	Silencer base Silencer cover (27A) nipple (98) and bolts with nuts.	1 1		
27A 28 29A	Silencer cover to silencer base bolts with nuts	3 1 1 1 1 1	26-C 26-C	
30A	30A-C Cam Gear Stud	1 1.		0
	ordering parts, read the instructions on page 9.			

Repair Parts List—Fairbanks-Morse Type "Z" Oil Engines

11 2494

248			
Included in Group No.	Number Pieces Used	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Repair Nos. Arranged Numerically
30A-0 30A-0 50A-0	1 1 1 1	Cam Gear Stud Nut. Cam gear stud lockwasher. Exhaust roller pin washer. Exhaust rod rocker fulcrum pin washer.	31 31A
18-C 18-C 92A-C 50A-C	2 2 1 1 1 1	Connecting rod bolt. Connecting rod bolt cotters. Governor weight drag spring. Exhaust roller. Exhaust roller pin. Exhaust rod.	32 33 34A 35A 36
	1 1	39A-C Exhaust Valve Rocker Arm Exhaust valve rocker arm Exhaust valve rocker arm adjusting screw (55) with jam nut and lockwasher, return spring (329).	39A
	1 1	40-C Exhaust Valve Rocker Arm Pin Exhaust valve rocker arm pin Exhaust valve rocker arm pin nut and lockwasher.	40
40-C 40-C	1 1	Exhaust valve rocker arm pin nut. Exhaust valve rocker arm pin lockwasher.	
92A-C	1	Governor gear	48A
	1 1	Exhaust rod rocker always fitted with clamp screw	50A
50A-C	1	Exhaust rocker clamp screw.	
	1	52-C Oscillator Trip Carrier Oscillator trip carrier always fitted with clamp screw, fulcrum pin (333) and cotters. Oscillator trip spring (324).	52
52-C 39A-C 39A-C 39A-C	1 1 1 1 1 1	Oscillator trip carrier clamp screw. Exhaust valve rocker arm adjusting screw. Exhaust valve rocker arm adjustable screw nut. Exhaust valve rocker arm adjustable screw lockwasher.	55
2 A -C	1 1	58A-C Exhaust Rod Rocker Fulcrum Pin Exhaust rod rocker fulcrum pin Exhaust rod rocker fulcrum pin washer (31A) and ring cotter (133A).	58A
4A-C 4A-C	1 1	Fuel reservoir cover	60 61
4A-C	1 1	Fuel pump plunger, always fitted with cap (69) Fuel pump plunger ball valve (302).	65
4A-C	1 1	66-C Fuel Pump Rocker Arm Fuel pump rocker arm Fuel pump rocker arm pin (67) with cotter.	66
66-C 66-C		Fuel pump rocker arm pin. Fuel pump rocker arm pin cotters.	67



14 2494	Repair Parts List—Fairbanks-Morse Type "Z	' Oil	Engines	
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.	1
69 71 72A 76A 76B 77 79A 80A 81A 82A 83 85	Fuel pump plunger cap. Piston pin dowel pin. Piston pin dowel pin screw. Piston pin dowel pin lockwasher. Fuel throttle valve. Gasoline throttle valve. Fuel pump rocker arm dog with set screw. Fuel pump rocker arm dog set screw. Governor weight pins, with 2 cotters each. Governor spindle. Governor weight. Governor lever. Governor lever pin, with 2 cotters.	1 1 1 1 1 1 2 1 1 2 1	65-C 5A-C 5A-C 5A-C 4A-C 4A-C 92A-C 92A-C 92A-C 92A-C 92A-C 92A-C	
92 A	92A-C Governor Governor bracket. Governor sleeve pin (80A), sleeve pin spring (308), spindle (81A), weights (82A), weight pins (79A) with cotters, drag spring (33), drag spring adjusting screw (321) with locknut, gear (48A), governor lever (83), lever pin (85) with cotters, sleeve pin spring adjusting screw (156A), speed regulator (209-C), speed regulator fulcrum pin (212).	1		
98	Governor bracket to base cap screw	$\frac{2}{2}$	92A-C 92A-C 26-C	
101A	101A-C Evaporator Cylinder (10 H. P. Only) Evaporator cylinder, always fitted with head studs and base studs, igniter clamp stud (301), drain plug (327), name plate (195), name plate screws and rubber washers, oil pipe with lock nut and leather gasket, oil pipe coupling Piston (5A-C).	1		N. Committee of the com
	Evaporator cylinder to head long stud. Evaporator cylinder to head short studs. Evaporator cylinder to head stud nuts. Evaporator cylinder to base studs. Evaporator cylinder to base stud nuts. Evaporator cylinder to base stud nuts. Evaporator cylinder oil pipe with lock nut and leather gasket	1 4 5 6 6 6 1	101A-C 101A-C 101A-C 101A-C	
110 110A 120 121 122 126B 126-C 133 133A 139	Evaporator cylinder oil pipe coupling. Connecting rod shims—thick. Connecting rod shims—thin. Suction valve drag spring. Suction valve spring collar. Suction and exhaust valve spring collar lock. Main bearing shims—thick. Main bearing shims—thin. Exhaust roller pin ring cotter. Exhaust rocker fulcrum pin ring cotter. Cylinder to oscillator clamp.	1 6 18 1 1 2 8 24 1 1 1	101A-C 18-C 18-C 9A-C 9A-C 9A-C 10A-C 2A-C 2A-C 50A-C	
151 156A 157 158 159 160 176	Connecting rod bolt castle nuts. Governor spring adjusting screw. Flywheel key—governor side. Flywheel key—opposite governor side. Crankshaft pinion key. End thrust washer. Connecting rod crank pin liner halves.	2 1 1 1 1 1 1 2	18-C 92A-C 13A 13 25A-C	

Before ordering parts, read the instructions on page 9.

Repair Parts List—Fairbanks-Morse Type "Z" Oil Engines

15 2494

Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
178	178-C Water Reservoir	1	
179	Water reservoir cover, always fitted with float valve lock and rivet. Water reservoir cover screw.	1 1	178-C 178-C
180	Water reservoir float, always fitted with lower lever, upper lever (183) and screw	1	178-C
181 183 185 186	Water reservoir float valve. Water reservoir float lever upper half. Water reservoir float lever machine screw. Water reservoir throttle valve. Water reservoir nozzle.	1 1 1 1 1	178-C 180-C 180-C 178-C 178-C
187 189 190 192 192 193 194	Water reservoir screen. Water reservoir float valve seat. Cylinder to head gasket. Cylinder head to butterfly valve casing gasket. Reservoir to butterfly valve casing gasket. Cylinder to base gasket. Cylinder to water reservoir gasket.	1 1 1 1 1 1	178-C
202A	202A-C Butterfly Valve Casing. Butterfly valve casing. Butterfly valve (203) with screws and lock washers, valve stem (204) with rivet, valve stem arm (206A) with clamp screw, valve stem arm spring (326).	1	
203 204 205 206A	Butterfly valve Butterfly valve stem with rivet. Governor pull rod, with 2 cotters. Butterfly valve stem arm, with clamp screw. Butterfly valve stem arm clamp screw.	1 1 1 1 1	202A- 202A- 202A-
209	209-C Speed Regulator	1 1	
212 222 223 224 225 226	Speed regulator lever pin. Speed regulator leaf spring (not furnished separately). Fuel nozzle with bushing. Speed regulator adjusting screw. Gear guard. Exhaust rod spring collar with set screw.	1 1 1 1 1 1	209-C 209-C 4A- 209-C
300 301	Exhaust rod spring collar set screw. Fuel pump plunger spring. Igniter clamp stud.	1 1 1	4A- 1A- 101A-
302	Fuel pump ball valve	1	4A- 65-C
308 310 311 317 319	Governor sleeve pin spring. Suction valve spring. Fuel or gasoline throttle valve spring. Exhaust valve spring. Exhaust rod return spring.	1 1 2 1	92A- 9A- 4A- 10A-
321	Governor weight drag spring adjusting screw. Governor weight drag spring adjusting lock nut.	1 1 1	92A- 92A-

16 2494	Repair Parts List—Fairbanks-Morse Type "Z'	' Oil	Engines	
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.	1
324 326 327	Oscillator trip spring. Butterfly valve stem arm spring. Cylinder drain plug.	1 1 1 1	52-C 202A-C 1A-C 101A-C	
328 329 330 331	Base drain plug. Exhaust valve rocker arm return spring. Water reservoir drain plug. Fuel reservoir drain plug.	1 1 1 1	2A-C 39A-C 178-C 4A-C	
332 333 400	Water reservoir float valve fulcrum pin. Oscillator trip fulcrum pin. Flywheel clamp stud with nuts.	1 1 2	178-C 52-C 13 13A	
505 506 507	Flywheel clamp stud nuts. Main bearing grease cup. Cam gear pin grease cup. Governor grease cup.	8 2 1 1	400	
509 521 527 528	Connecting rod compression grease cup. Air damper fulcrum plug. Cylinder oiler. Cylinder priming cup.	1 1 1	4A-C	
601	601A-C Circulating Pump. Circulating pump bearing plate. Circulating pump packing nut (602), packing, flange to body gasket (638), flange to body cap screws, pump body (603A) with drain plug, impeller (606), impeller shaft (604), with key, pulley (605) with set screw, nipple bracket (609), clamping nut (608), pump to cylinder gaskets (610).	1 1	A.	
602 603A 604	Circulating pump packing nut. Circulating pump body with drain plug. Circulating pump body drain plug. Circulating pump body to flange cap screw. Circulating pump shaft.	1 1 1 6 1	601A-C 601A-C 601A-C 601A-C 601A-C	N
605	Circulating pump impeller key. Circulating pump pulley, with set screw. Circulating pump pulley set screw. Circulating pump impeller.	1 1 1 1 1	601A-C 601A-C 601A-C 601A-C	
608	Circulating pump drive pulley, with 2 bolt and lock washers Circulating pump pulley bolts and lockwashers Circulating pump drive belt Circulating pump clamping nut.	$\begin{array}{c} 1 \\ 2 \\ 1 \\ 1 \end{array}$	601A-C	
609 610 638 683 695 696	Circulating pump nipple bracket. Circulating pump to cylinder gaskets. Circulating pump body to flange gasket. Circulating pump grease cups. Oscillator complete (for separate repairs on this, see page —. Magneto only—complete (for separate repairs on this, see	1 2 1 2 1	601A-C 601A-C 601A-C	
697	page 17)	1 1 1		
698 699 700A	Exhaust pot drain plug. Exhaust pot to cover machine bolts with 2 washers each. Exhaust pot cover, always fitted with gland studs. Exhaust pot cover gland studs. Exhaust pot cover gland stud nuts. Exhaust pot cover gasket. Exhaust pot outlet elbow.	1 9 1 2 2 1 1	697-C 697-C 697-C 697-C 697-C 697-C 697-C	3

Before ordering parts, read the instructions on page 9.

Repair Parts List—Fairbanks-Morse Type "Z" Oil Engines

17	
49	4
	-


Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
701 702	Exhaust pot outlet elbow capscrews. Exhaust pot outlet elbow gasket. Exhaust pot inlet packing gland.	1 1	697-C 697-C 697-C
703 821 855	Exhaust pot inlet pipe. Air damper fulcrum spring. Water throttle valve spring. Springs	1 1	4A-C 178-C
300 308 310 311	Fuel pump plunger spring. Governor sleeve pin spring. Suction valve spring. Fuel or gasoline throttle valve spring.	1 1 1	4A-C 92A-C 9A-C 4A-C
317 319 324	Exhaust valve spring. Exhaust rod return spring. Oscillator trip spring.	1 1 1	10A-C 52-C
326 329 821 855	Butterfly valve stem arm spring Exhaust valve rocker arm return spring Air damper fulcrum spring Water throttle valve spring	1	202A-C 39A-C 4A-C 178-C
190 192	Gaskets Cylinder to head gasket Cylinder head to butterfly valve casing or fuel reservoir gasket	2	
193 194 638 610 699 701	Cylinder to base gasket. Cylinder to water reservoir gasket. Circulating pump body to flange gasket. Circulating pump body to cylinder gasket. Exhaust pot cover gasket. Exhaust pot cover gasket.	2	601A-C 601A-C 697-C 697-C
701		1 1 1 1	091-0

Repair Parts List for Imp. Model 14 Magneto

Part No.	Name of Part	
20018	Ground brush assembly.	
20156	End plate screw.	20822 20883
20340	Magnet clamp.	20852
20346	Terminal end bearing plate.	20822 - 20852 20852 20340
20353	Oil well tube screw.	20750
20360	Drive end bearing plate.	20362 3-M
20362	Top plate assembly.	20346
20363	Oil wick assembly.	
20633.	Drive shaft lock washer.	5-E 20156
20816	Lock washer for end plate	20872 20360
	screw No. 20156.	
20819	Lock washer for magnet	
	clamp screw No. 20852.	
20822	Magnet (one only).	
20831	Frame assembly (Base and	
20040	two pole pieces).	
20843	Armature assembly.	
20852	Magnet clamp screw (with-	
00050	out seal).	
20858	Terminal cap screw (not	23322
00070	s hown).	20843
20872	Terminal cap assembly	20353 / 20888
20883	complete.	20831 20018
20888	Magnet band.	
23322	Drive shaft nut.	Fig. 674
20022	Drive shaft Woodruff key.	Parts of Sumter Imp. Model 14 Magneto

Always give serial number and state whether magneto has oil well bearing end plates.

Setting Gears



Repair Parts List Model "C" Oscillating Magneto

For 3 H. P. and Larger Type "Z" Engines

Always mention the direction of rotation and the serial number when ordering repairs.

oushing.
)

Movable electrode arm. 20608 Stationary electrode special nut. 20609 Trip finger.

20610 Movable electrode and point. 20611 Early and late eccentric plunger.

20612 Trip and break lever spring. 20613 Movable electrode nut.

20614 Early and late eccentric plunger spring.

20615 Movable electrode arm spring. 20616 Stationary electrode with point.

20617 Stationary electrode copper gasket (not shown).

20619 Movable electrode seating spring.

20622 Magneto fastening screw.

20623 Movable electrode nut lock washer.

Magneto fastening screw lock washer. 20624


Early and late eccentric. 20627

20630 Starting lever.

20634 Magneto terminal and wire. 20635 Trip finger assembly complete.

20800-C Magneto complete.

Spring roller stud spring ring. Movable electrode woodruff key.




Model "C" Oscillating Magneto Used on 3 H. P. and Larger Type "Z" Oil Engines

50. The fuel is pumped into the fuel reservoir (4, page 6), located on the side of the cylinder head, where a constant level is maintained, the overflow pipe carrying Fuel the surplus back to the supply tank. By means of a small nozzle (223, page 6) which terminates in the air suction passage, a small quantity of the fuel is drawn into the cylinder with the air on the intake stroke of the piston. The throttle valve adjustment determines positively the amount of fuel admitted into the cylinder for each charge. The location of the nozzle with respect to the butterfly valve (203, page 6) s of utmost importance and is such as to keep the mixture right, when the load changes.

51. The cam gear is marked with two center punch marks on face of tooth. The pinion (29A page 6) on crank shaft has one tooth with two center punch marks. This tooth should come between the two marked ones on the large gear. (28 page 6.)

If engine is taken apart and the marks on gears cannot be found, or if old gear s replaced by a new one, the engine should be timed as follows:




At this position of the crank on the exhaust stroke, the exhaust valve begins to open.

Place the crank (25A page 6) in a vertical position and pointing up. Then set the cam gear with the nose of the cam straight up. Next see that there is about 1/16" clearance between end of exhaust rod and adjusting screw in the valve rocker arm. Such a setting should bring the valve timing very nearly as described in paragraph 52 below. Adjust open and closing of valve by means of adjusting screw (55).

52. The cam should begin to open the exhaust valve 30° to 35° before outer dead center (Fig. 1840GN). The cam should close the exhaust valve when the crank AB is in the position shown in Fig. 1841GN, or about 5° above the inner dead center.

53. If it is found necessary at any time to remove the cam gear, remove the nut on the cam gear stud on the inside of base, and by lightly driving on the end of stud Removing it can be driven out through the gear. In replacing the cam gear be sure that the Cam Gear marked teeth mesh together, otherwise the engine will not be properly timed.

Valve Timing



At this position of the crank on the suction stroke, the exhaust valve closes

Magneto

54. Instructions No. 2479 cover fully the care and timing of the magneto and igniter.

Crank Pin

55. The crank pin bearing is adjustable by unscrewing the nuts on the connecting rod bolts and removing caps and liner. After removing the equal amount of shims from each side, liner and cap may be put on again, bolt nuts tightened and secured by means of the cotter pins.

Renewal

In a renewal of the crank pin bearing, the new liners should be carefully fitted into the connecting rod and its cap, and the shim faces filed to the general surface. The liners should then be tried on the crank pin by hand to note whether they have sufficient end play (about 1/64") and whether they spot up evenly on the surface. In any case, after new crank pin liners have been fitted to an engine it is well to inspect them after running the engine for five or ten minutes at no load, and again after that.

56. The main bearings are made large to distribute the wear and to make them durable. They are equipped with interchangeable, die cast, accurately fitted bushings, making replacement of bearings very easy.

Adjustment is necessary when excessive play in the bearings can be detected by applying a bar under the flywheel. Vibration of the flywheels when the engine is in operation, may also indicate a necessity for main bearing adjustment. This should be made in the following manner: First remove the bearing cap, then lift off the upper half of the bearing liner. After removing the shell one or more of the thin metal shims between it and the lower shell may be removed from each side of the bearing, after which the top half of the bearing may be replaced and the cap again clamped down securely. End play can be adjusted by means of the flywheels. The end adjustment should not be brought up closer than with a play of 1/64", which can be felt when moving the parts in question with a bar. After adjustments have been made and the engine is put into operation, the parts adjusted should be watched for a time to note whether the running temperature grows excessive.


Main Bearing

The main bearings may be completely renewed by first relieving the pressure of the crankshaft by means of a jack or bar under the flywheel, then proceeding as above and in addition, rolling out the lower half of the bearing liner or shell in the manner, which is self-evident on inspection. New liners which will interchange with those on the engines can be furnished from the factory.

57. Loosen bolt and drive wedges into the split on each side of arms, generally the wheel is then loosened so it can be easily pulled off. If not, drive it by placing Flywheel piece of hard wood against the inside hub of wheel. In replacing, tighten the bolt before driving the key.

58. The flywheels should be slightly set out from main bearings so that there Crank Shaft will be about 1/32" end play to the shaft.

59. While the deposit or scale varies in character in different localities it can usually be removed by draining the engine cylinder jacket, and fitting the jacket with a solution consisting of one part commercial sulphuric acid to ten parts water. Deposit And leaving it stand over night. Most of the deposit can be washed out by draining out the water and allow it to run half an hour before starting the engine.



TROUBLE CHART

Trouble	Trouble Possible Cause		Remedy	See Para- graph
Engine will not start.	Instructions r	not followed.	Read and follow instructions.	16–30
	No fuel in tar	ık.	Fill tank.	, 11–15
	Water in gaso	line used in starting.	Strain gasoline.	
	Water in engine cylinder.		Water will work out if engine is turned over slowly.	
			See that gasket is unbroken	41
	Engine floode	ed.	Open suction valve.	29
		(Valve leaks.	Grind valves.	40
	Poor compression.	Head gasket leaks.	Put on new gasket.	41
		Piston blows.	Remove rings and clean.	42
	Engine very cold.		Put but little water (preferably hot water) in hopper	19
		(Igniter dirty.	Take out igniter, clean points.	Inst. 2479
		Short circuit.	See that wire from magneto is not grounded.	Inst. 2479
	No Spark or Poor Spark.	Movable electrode sticking.	Remove and clean spring should hold points together.	Inst. 2479
		Oscillator.	Remove oscillator, trip with hand lever and note if spark occurs.	Inst. 2479
		Mechanism slug- gish.	Oil all parts well.	Inst. 2479
Engine misses fire after		Mechanism slug- gish.	Oil all parts.	Inst. 2479
being started.	Ignition.	Short circuit.	Clean. See that insulation on wire is good.	Inst. 2479
		Igniter dirty.	Clean.	Inst. 2479

Trouble	Possible Cause		Remedy	See Para- graph
Engine knocks.	Igniter dirty.		Clean.	Inst. 2479
	Water in fuel collects in bottom of reservoir and fuel tank.		Drain water from reservoir through plug in bottom.	
			Pump water out of tank.	
	Fuel.	Dirty.	Clean out tank piping, reservoir and nozzle tube.	
		Throttle adjustment.	Carefully set throttle.	34
	Engine cold.		Keep temperature of jacket water to 160°.	9
	Hard Explosion. Loose crank pin bearing. Loose flywheel.		Remove head and clean carbon.	41
			Open water throttle.	48
			Take up bearing. Tighten bolts.	55 57
	Roller jumps on pawl.		Adjust spring when rollers are on low cam spring should be $6\frac{1}{4}''$ long.	
	Scale formation in jacket causes engine to overheat.		Clean out scale.	59
Engine runs irreg- ularly.			See that governor parts are free. Use kerosene to loosen.	45
			Adjust (33) spring.	45
	Weak exhaust valve spring.		Put washer under spring till new spring can be obtained.	
Engine tends to run away.	Butterfly may not close.		Adjust butterfly crank and governor travel.	46
	Excessive fue hit and mis	el causes engine to	Carefully set throttle.	34
Engine will not	Exhaust valv	e setting off.	Reset.	51-52
carry load.	Poor compres	ssion.	See "Engine will not start"	
	Late ignition		Correct.	Inst. 2479
	Too rich mix	ture.	Adjust fuel throttle.	34
	Carbon in co	mbustion space.	Remove head and clean.	41
	Silencer clogs	ged.	Clean out.	
	Butterfly mo	ved.	Reset.	46

Trouble Chart—Fairbanks-Morse Type "Z" Oil Engines

Trouble	Possi	ble Cause	Remedy	See Para- graph
Engine uses	Throttle open too far.		Close.	34
too much fuel.	Poor compress	sion.	See "Engine will not start."	40, 41, 42
	Late Ignition.		Time correctly.	Inst. 2479
	Exhaust valve	e setting off.	Reset.	52
	Exhaust pipe	or silencer choked.	Clean.	
		(Weak suction valve spring.	Lengthen spring by stretching small coils.	
	Fuel drips from suction pipe.	Friction spring too weak or too strong.	Bend spring or put on new one.	
Carbon forms.	Too much fue	el.	Close throttle.	34
	Too much lubricating oil.		Adjust lubricator.	20
	Engine too co	ld.	See that engine is hot before turning on oil fuel.	34
			Keep temperature about 160°.	
Engine smokes.	Exhaust.	Too much lubricating oil.	Adjust lubricator.	20
		Too much fuel.	Adjust fuel throttle.	34
0 -	D: /	Oil thrown into piston by crank.	Open crank case, drain clean out crank case.	
	Piston.	Piston blows.	Remove piston, clean rings, may need new rings.	42
Cylinder oiler	Filler openin	g left open.	Screw in plug after filling.	20
will not feed properly.	Piston blows.		Clean piston and rings, may need new rings.	42
Water boils away	Mixture too r	ich.	Close throttle.	34
too rapidly.	Late ignition.		Correct.	Inst. 2479
			Never let the water get below top of cylinder.	

Instructions No. 2528

FOR SETTING UP AND OPERATING


Fairbanks-Morse

1½ H. P. Type "Z"

Throttling Governor Oil Engines

1919 Pattern

This book should be carefully read before attempting to do anything with the engine



(3430G)

FAIRBANKS, MORSE & CO.

(INCORPORATED)

INSTRUCTIONS No. 2528

For Setting Up and Operating Fairbanks-Morse 1½ H. P. Type "Z" Oil Engines

1. Remove engine from crate, being careful to avoid damage. Screw oil cup 527, on cylinder oil pipe. Bolt the pulley on the flywheel opposite the governor using the bolts sent. With the Steel Pulleys small clips are furnished to catch inside the rim. Clean all parts. See that the governor parts are free from dirt or paint. Oil all moving parts and turn the flywheel over by hand slowly to see that all parts

When Engine

2. If engine is to be put on a foundation, make this 4 feet long, 2 feet wide, 2 feet Foundation deep, setting 5/16" rods in position to match the bolt holes in the wood base under the engine.

3. If the engine is installed in a building the silencer (26A page 3), may be re- If Located in moved and an exhaust pipe attached and carried outside. It should be short and Building with few bends. When the pipe is long (20 feet) or has several elbows (4) the pipe should be increased in size. The silencer must be attached to the end of the pipe.

These engines can use as fuel, Gasoline, Motor Spirits, Kerosene and some Fuel Distillates.

5. Read the tags on the engine but do not remove them until you are familiar Read Tags with its operation.

WHAT TO DO BEFORE STARTING.

Fill fuel tank with the oil fuel.

Fill Fuel Tank Cooling Water

7. Put water in hopper, but only enough at first to cover top of cylinder. In cold weather hot water will make the engine easier to start.

Oiling

Fill oil cup (527, page 3), with good Gas Engine oil (we recommend Hytest) and adjust oiler to feed about eight drops per minute. See that the plug in the filling opening on the oil cup is provided with a good gasket and screwed in tight to prevent the oil being blown back. Gradually cut down oil feed as the engine becomes worn in until in a month, one-half the above quantities will do. Fill the three grease cups. Two (505, page 3) are on main bearings, and one (509A, page 3), is on the crank pin bearing. These should be screwed down one or two turns until grease is forced freely into bearings.

9. With a hand oil can go over the engine and oil the governor and all other places where there are oil holes, and where one part moves against another. In Oil by hand freezing weather squirt a little oil on piston until engine heats up.

TO START ENGINE.


10. Fill reservoir (114) with gasoline.

Gasoline for Starting

11. Close oil throttle (76A), open gasoline throttle valve (376, page 2) about Fuel Valve one turn. If the engine is run on gasoline, throttle valve 76A may be used for starting as well as running.

12. Holding the suction or upper valve open with the left hand, with the starter Starting crank spin the engine. After getting the engine in motion, release the suction valve and close the air inlet opening in end of air suction fitting with fingers of left hand for one revolution only, and then remove fingers while still continuing to crank. If held longer, too much fuel will be drawn in. The mixture will not ignite if there is too much fuel in it.

13. Too much fuel used in starting (particularly with a hot engine) will flood Flooded the engine. When flooded close the fuel throttle, relieve the compression by holding suction valve open with the finger and turn the flywheel over a number of revolutions in order to work out the excess fuel



AFTER THE ENGINE IS STARTED.

14. After the engine takes its first impulse, remove the starter crank; adjust the gasoline throttle valve to the point where engine runs best.

Running on Oil Fuel 15. The engine will usually run on oil fuel after using one reservoir full of gasoline. When engine is warm enough gradually open the oil throttle valve (76A) and close gasoline throttle valve (376). It is well to have the gasoline throttle valve slightly open until the engine is hot enough to run well on the oil fuel alone. After closing gasoline throttle the oil fuel throttle should again be adjusted to give as little fuel as the engine will run on and operate smoothly. The handle of the oil fuel throttle is marked at the factory when the engine is tested and should generally point down when the engine is in operation.

Fill Hopper Tighten Nuts

- 16. Fill water hopper two-thirds full and replenish this water as it boils away.
- 17. Tighten cylinder head nuts after engine has been run and warmed up.

TO STOP ENGINE.

To Stop

18. To stop engine close throttle valve (76A), then close cylinder oiler (527, page 3) and in freezing weather, drain out the water.


DESCRIPTION OF PARTS OF ENGINE AND MANNER OF ADJUSTMENT

Valves 19. If either exhaust or suction valve sticks, squirt kerosene on the stem and work free.

Lost Compression 20. Should the engine at any time on starting turn too easily, it has lost compression because some leak is taking place. The suction valve as well as exhaust valve should be examined. If they seat tightly, examine piston (see paragraph 23).

Cleaning and Regrinding Valves 21. If it is necessary to grind suction or exhaust valve, the cylinder head (3) must be removed and the valves ground in with ground glass or fine emery and oil. Carefully clean both valve and seat with gasoline before replacing.

Gaskets 22. Asbestos gaskets hold better if covered with linseed or lubricating oil when applied. Before applying new gasket scrape off all of old one. After putting on new



gasket (190) the nuts should be tightened again when engine is hot. Gasket material should be long fibre asbestos 3/64" thick.



and unbolt the rod. Turn crank to out position. The piston may now be withdrawn. Clean with gasoline or a hot solution of lye and water. Loosen the rings and clean the grooves. Oil the piston well before replacing. In replacing piston turn it bottom side up so that the stop pins can be seen, otherwise the rings may be broken. Be sure to turn it right side up before connecting up rings can be removed from piston by taking three strips of tin about one-half inch wide and six inches long, slip

23. After some months of use the piston may be To Remove removed to clean the rings. To do this take off shield Piston

one piece of tin under the middle of the ring and over the ring groove, then with the help of a screw driver the other strips can be slipped under the ends and the rings in turn slipped off the piston.

To Remove Piston Rings

24. To remove piston pin (7A) use screw driver to take out taper dowel pin screw (72). Force out taper dowel pin (71) from inside of hollow pin. This allows the pin to be driven out. In returning parts be sure to put the lock washer in between the lock pin and screw.

Removing Piston Pin

25. The governor is fitted with a friction spring (33, page 8), the purpose of which is to steady the governor action. The force of the spring can be adjusted by small screw. If there is too much tension the governor will be slow to respond to change in load. If not enough tension, the engine will run irregularly.

Action of Governor

If it is necessary for any reason to reset the butterfly crank arm (206, page 3) remove the air suction fitting first so that the butterfly (203) can be seen. Take cotter pin out of butterfly crank end of governor rod (205, page 3), remove end of governor rod (205) from crank (206, page 3), Pull one governor weight (82) out as far as it will go and then put a wedge under it to hold it in that position. Slightly loosen clamp screw of crank (206). Close butterfly with finger and set crank (206) pointing up so that governor rod lacks 1/16" from going in hole of crank. Remove wedge from under governor weight. Tighten clamp screw of crank (206) and reassemble parts removed. If these instructions are followed the engine cannot run away.

Butterfly



Decreasing Engine Speed 27. The governor normally holds the engine at its rated speed, but each engine is provided with a speed regulator which decreases the speed by turning the head screw (224, page 3).

Suction Feed

28. Fuel is lifted from the tank into the air suction fitting (196) by suction. If the engine should miss fire or back fire in the air suction or show lack of power with plenty of fuel in the tank, examine the check valve (89, page 9). This is supplied with a fine wire screen in the lower end which may be clogged. The auxiliary air suction valve is at the inlet of the air suction fitting (196). It should work freely at all times.


Piping

29. If it should be necessary to remove fuel piping and check valve from fuel tank, unscrew the cap (47) and take out the two screws, holding the air suction fitting (196) to butterfly valve easing (202). The air suction fitting together with the fuel tube and check valve can then be removed.

Draining Fuel Tank 30. If water collects in bottom of fuel tank this can be taken out by first taking off the air suction fitting with fuel tube (see paragraph 29). Then loosen the clamp bolts holding tank, and take it out.

Setting Gears

31. The cam gear is marked with center punch marks on face of two teeth. The pinion (29A page 3) on crank shaft has one tooth with two center punch marks. This tooth should come between the two marked ones on the large gear (28A, page 3). If engine is taken apart and the marks on gears cannot be found, or if old gear is replaced by a new one, the engine should be timed as follows:



Valve Timing


- 32. Turn the engine to where the crank (25A, page 9) is straight up and pointing up. Then set the cam gear with the nose of the cam straight up. Next see that there is about 1/16" clearance between end of exhaust rod and the valve rocker arm. Adjust to this clearance by the two nuts on rocker bracket stud (42A). Such a setting should bring the valve timing very nearly as described in paragraph 33.
- 33. The cam should begin to open the exhaust valve 30° to 35° before outer dead center (40ZA). The cam should close the exhaust valve when the crank is in position shown in Fig. (41ZA) or about 5° above the inner dead center. The valve can be turned with the fingers, when it is lifted from its seat.





34. In order to remove the cam gear first take off the igniter, then take out the two screws holding cam gear bracket to base. All parts attached to bracket can then be inspected. In replacing, take care to properly mesh the teeth of cam gear and crankshaft pinion (paragraph 31).

Removing Cam Gear



35. Crank shaft bearings can be adjusted by unbolting parts and removing one Bearing or two of the thin shims provided. In reassembling, the bolts must be drawn up Adjustment tight and the shaft must turn perfectly free.

36. These bearings all have removable linings which may be renewed. A little Renewals fitting and scraping of the new linings may be needed to make them fit the shaft nicely.

37. The water should never be allowed to fall as low as the top of the cylinder Temperature wall, as the cylinder will get too hot. It is expected that the water will boil under Water heavy load. Put in more water as it boils away.

38. The engine jacket is liable to be broken by freezing if water is left in during Engine Jacket cold weather unless non-freezing solution is used.

Broken by Freezing

39. A non-freezing mixture of calcium chloride and water may be used in the jacket. Three pounds of calcium chloride to each gallon of water will not freeze solid at Zero Fahrenheit. It is advisable, however, to drain the jacket in freezing weather when the engine is not in use.

Non-freezing Solution

40. While the deposit or scale varies in character in different localities it can Removing usually be removed by draining the engine cylinder jacket, and filling the jacket with a solution consisting of one part commercial sulphuric acid to ten parts water. Allow to stand over night and then wash out with fresh water.

41. Instructions No. 2530 cover the care and timing of the magneto and igniter. Magneto

REPAIR PARTS LIST

For Fairbanks-Morse 1½ H. P. Throttling Governor Type "Z" Oil Engine

When ordering parts, always give the size or horsepower type and shop number of the engine. The number is very important. It is stamped on the top of the base and cylinder. Do not fail to give it.

Parts may be ordered in groups or individually, except where noted.


A Group Number printed in heavy type, followed by the letter C, such as "3A-C Cylinder Head," covers all items in that paragraph down to the first horizontal line.

An ordinary repair number printed in light type (such as 52) covers that part only, including any parts which are "always fitted" to fit. For example: In group 52-C No. 334, 324, 694, covers one part only, but, "52 covers the part No. 52 and all parts" always fitted to it.

A group may be ordered, less certain specified parts. For example: "52-C less Nos. 334 and 634."

Any part without a repair number is listed directly after the numbered part with which it is used.


Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
1A	1A-C Cylinder and Base. Cylinder and base, always fitted with head studs, main bearing cap (12), with cap screws and lock washers, main bearing shims (126 and 126A). Main bearing liners (23A).		
	Cylinder to head studs. Cylinder to head stud nuts. Cylinder to subbase bolts. Cylinder to subbase bolt nuts. Cylinder to subbase washers.	4 4 4 4 4	1A-C
3	3-A Cylinder Head Cylinder head, always fitted with oscillating magneto studs, exhaust valve rocker bracket stud (42A), suction valve (9A-C), exhaust valve (10A-C), drain plug (327A)		
	Cylinder head to oscillating magneto studs Cylinder head to oscillating magneto stud nuts. Exhaust valve rocker bracket stud nut. Exhaust valve rocker bracket stud jam nut.	2	3-C 3-C 3-C 3-C
3	3A-C Cylinder Head. Cylinder head, always fitted with oscillating magneto studs, exhaust valve rocker bracket stud (42A), suction valve (9A-C), exhaust valve (10A-C), drain plug (327A) Butterfly valve casing (202-C).		




7 2528

6	P	1
1		1
->		9
	354	

-topun -	ares hist rangamics more rapporary		2528
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head'of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
3	3B-C Cylinder Head	1	
3	3C-C Cylinder Head Cylinder head, always fitted with oscillating magneto studs, exhaust valve rocker bracket stud (42A), suction valve (9A-C), exhaust valve (10A-C), drain plug (327A) Butterfly valve casing (202-C). Exhaust valve rocker bracket (41-C). Oscillating Magneto (Z-2600).	1	
5	Fiston, always fitted with ring stop pins. Piston rings (6), piston pin (7), piston pin taper lock pin (71), lock pin screw (72), lock pin screw lock washer.	1 1	
6 7	Piston rings. Piston pin.	3	5-C 5-C
9A	9A-C Suction Valve. Suction valve with cotter. Suction valve spring (310).	1 1	3-C
10A	Exhaust valve. Exhaust valve spring (317), spring collar (11A), spring collar lock (122).	1 1	3-C
11A 12	Exhaust valve spring collar. Main bearing caps. Main bearing cap cap screws. Main bearing cap cap screw lock washers.	1 2 4 4	10A-C 1A-C 1A-C 1A-C
13B	Flywheel, always fitted with clamp bolt	2	
	Flywheel clamp bolt	$\frac{2}{1}$	13B
14A	Subbase, always fitted with engine fill-up pieces (234), subbase spacer (233), spacer bolts, end bolts, name plate (195A) Fuel tank (15B), fuel tank elips (104), fuel tank elip bolts.		
15B	15-B Fuel Tank. Fuel tank, always fitted with filler opening cap (44)	1 1	
16A	Oil shield, always fitted with oil shield brackets	1 1	
17	Piston pin bushing.	1	18-C
18	Connecting rod, always fitted with connecting rod cap (20) piston pin bushing (17). Connecting rod shims (110-110A), connecting rod bolts (150) connecting rod bolts nuts (151), connecting rod bolt cotters connecting rod crank pin liners (176).	, 1	
	- Jains south mood the implementions on mous E		





Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
20 23A 24A	Connecting rod cap (not furnished separately). Main bearing liner (halves). Fuel suction tube.	1 4 1	18-C 1A-C 89-C
25A	25A Crankshaft	1	
26A	Exhaust silencer.	1	
28A	28A Cam Gear. Cam gear, always fitted with cam shaft (30A), cam (128) and cam gear to shaft screw.	1	
29A 30A 33 34A 35A	Crankshaft pinion Crankshaft pinion key Cam shaft (not furnished separately). Governor weight drag spring Exhaust roller Exhaust roller pin Exhaust roller pin nut.	1 1 1 1 1 1 1	25A 25A 28A 81-C 36A-C 36A-C
36A	36A-C Exhaust Rod. Exhaust rod. Exhaust roller (34A), exhaust roller pin (35A), exhaust roller pin nut, exhaust roller pin washer (38A), oscillating magneto trip carrier (52-C), trip carrier cap screw, washer and lock washer.		
37A	37A-C Cam Gear Bracket. Cam gear bracket (94) with screws, governor lever (83), governor lever pin, governor lever bracket (93) with screws, cam gear (28A), exhaust rod (36A-C), governor spindle (81-C), speed regulator (209-C).	1 1	
38A 39A 40A	Exhaust roller pin washer Exhaust valve rocker Exhaust valve rocker fulcrum pin Exhaust valve rocker fulcrum pin nut.	1	36A-C 41-C 41-C 41-C
41	41-C Exhaust Valve Rocker Bracket. Exhaust valve rocker bracket. Exhaust valve rocker (39A), exhaust valve rocker fulcrum pin (40A) and exhaust valve rocker fulcrum pin nut.	1	3B-C
42A 43A 44 47 48	Exhaust valve rocker bracket stud. Starter crank handle. Fuel tank filler opening cap. Fuel tank suction cap. Governor gear.	1 1	3-C 728 15-A 89-C 81-C
52	52-C Oscillating Magneto Trip Carrier Oscillating magneto trip carrier, always fitted with trip fulcrum pin (333) Trip fulcrum pin ring (334), trip finger spring (324), trip finger (694).	1	36A-C



			2528
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
	Trip carrier cap screw washer. Trip carrier cap screw lock washer.	1 1 1	
71 72	Piston pin taper lock pin. Piston pin taper lock pin screw. Piston pin taper lock pin lock washer.	1 1 1	5-C 5-C 5-C
76A	Fuel throttle valve.	1	196-C
79	Governor weight pins	2	81-C
80	Governor sleeve pin	1	81-C
01	81-C Governor Spindle	1	37A-C
81	Governor spindle	1	
	weight spring (308), governor weight spring adjusting screw		
	(156), governor weight drag spring (33), drag spring adjust-		
	ing screw and nut, governor gear (48), governor weight pins (79).		
82	Governor weights	2	81-C
83	Governor lever	1	37A-C
85	Governor lever fulcrum pin	1	37A-C
	89-C Fuel Check Valve	1	
89	Fuel check valve body, always fitted with strainer (91), fuel		
	suction tube (24A), suction tube connection (95), check valve ball (90A).		
90A	Fuel check valve ball	1	89-C
91	Fuel check valve strainer (not furnished separately).	1	89-C
93	Governor lever bracket	1	37A-C
	Governor lever screw lock washer.	1 1	37A-0
94	Speed regulator bracket	1	37A-C
	Speed regulator bracket screws	2	37A-C
95	Speed regulator bracket screw lock washers Fuel suction tube connection	2	37A-C
104	Fuel tank clips	$\begin{bmatrix} 1 \\ 2 \end{bmatrix}$	89-C 232-C
	Fuel tank clip bolts with nuts	2	232-C
106	Pulley clips	3	
	Pulley clips to flywheel bolts. Pulley clip to flywheel bolt nuts.	3 3	
110	Connecting rod shims (thick)	2	18-C
110A	Connecting rod shims (thin)	6	18-C
114 115	Starting reservoir (not furnished separately). Starting reservoir cover.	1 1	196-C 196-C
117	Pulley	1	190-0
122	Exhaust valve spring collar lock	1	10A-0
124 126	Starting fuel suction tube (not furnished separately)	1	196-C
126A	Main bearing shims (thick) Main bearing shims (thin)	$\begin{array}{c c}4\\12\end{array}$	1A-0
128	Cam (not furnished separately)	1	28A-C
150	Connecting rod bolt with cotter only	2	18-C
151 156	Connecting rod bolt nut.	2	18-C 81-C
157	Governor spring adjusting screw. Flywheel keys	$\begin{bmatrix} 1 \\ 2 \end{bmatrix}$	91-C
159	Crank shaft pinion key	1	
160	End thrust washer (opposite governor)	1	
160 176	End thrust washer (governor side). Connecting rod crank pin bearing (halves)	2	25-A 18-C
110	Connecting rod crank pin bearing (naives)	2	19-C
	Cylinder to head gasket.		
190 192 195A	Cylinder to head gasket. Head to butterfly valve casing gasket. Name plate.	1 1 1	232-C

2528			
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
196	196-C Air Suction Fitting. Air suction fitting, always fitted with throttle valve seats (197), starting reservoir (114), starting reservoir cover (115), starting reservoir cover spring (314), starting fuel tube (124), starting reservoir cover pin (335). Fuel throttle (76A), starting fuel throttle (376), fuel tank suction opening cap (47), fuel suction tube (89-C), auxiliary air valve seat (198-C).	1	
197	Fuel throttle valve seat (not furnished separately)	2	196-C
198	Auxiliary air valve seat, always fitted with air valve guide (200). Auxiliary air valve (199), air valve spring (336), air valve guide, cotter.	1	196-C
199 200	Auxiliary air valve seat to air suction fitting screws. Auxiliary air valve. Auxiliary air valve guide (not furnished separately). Auxiliary air valve guide cotter.	1 1	198-C 198-C
202	Butterfly valve casing. Butterfly valve casing. Butterfly valve (203), butterfly valve stem (204), butterfly valve to stem screw and lock washer, butterfly valve stem arm (206), butterfly valve stem arm screw, butterfly valve spring (326).	1	
203 204 205 206	Butterfly valve casing to air suction fitting screws. Butterfly valve casing to head cap screws. Butterfly valve stem. Butterfly valve stem screw. Butterfly valve stem lock washer. Governor pull rod with 2 cotters. Butterfly valve stem arm with clamp screw. Butterfly valve stem arm clamp screw.		202-C 202-C 202-C 202-C 202-C 202-C
209	209-C Speed Regulator Lever. Speed regulator lever, always fitted with speed regulator least spring (222). Speed regulator adjusting screw (224), adjusting screw spring (230).	f	
212 222 224 230	Speed regulator lever fulcrum pin. Speed regulator leaf spring (not furnished separately). Speed regulator adjusting screw. Speed regulator adjusting screw spring.		209-C 209-C 209-C



Repair Nos. Arranged Numerically	a Group of Parts, includes all items mentioned in that Group.	Number Pieces Used	Included in Group No.
233 234	Subbase spacers Subbase spacer bolts Subbase spacer bolt nuts Subbase spacer bolt washers Subbase to engine fill-up pieces Subbase end bolts Subbase end bolt nuts Subbase end bolt washers	2 2 2 2 2 4 4 4	14A-C 14A-C 14A-C 14A-C 14A-C 14A-C 14A-C 14A-C
249 250 265A 271A 301 308 310 311 313 314	Air suction fitting gasket. Oscillating magneto to head gasket. Starter crank pawl. Cylinder oiler pipe. Oscillating magneto studs. Governor weight spring. Suction valve spring. Fuel throttle valve spring. Cylinder head studs. Starting reservoir cover spring.	1 1 1 2 1 1 1 4 1	728 3-C 81-C 9A-C 196-C 1-C 196-C 10A-C
319 321 324 326 327A 333 334 335 336 505 509A 527 694 Z-2600	Exhaust valve spring. Exhaust rod return spring. Governor weight drag spring adjusting screw. Oscillating magneto trip torsion spring. Butterfly valve shaft torsion spring. Cylinder head drain plug. Oscillating magneto trip fulcrum pin (not furnished separately) Oscillating magneto trip fulcrum pin ring. Starting reservoir cover pin. Auxiliary air valve spring. Main bearing grease cup. Connecting rod grease cup. Cylinder oiler. Oscillating magneto trip finger. Oscillating magneto trip finger. Oscillating magneto unit, complete, less magneto. (For separate repairs on this, see Instruction Book No. 2530).	1 1 1 1 1 1 1 1 1 2 1 1	81-C 52-C 202-C 3-C 52-C 196-C 198-C
20800-C 	Magneto only, complete. (For separate repairs on this, see Instruction Book No. 2530)	1	
308 310 311 314 317 319 324 326 336	Springs Governor weight spring. Suction valve spring. Throttle valve springs. Starting reservoir cover spring. Exhaust valve spring. Exhaust rod spring. Oscillating magneto trip torsion spring. Butterfly valve torsion spring. Auxiliary air valve spring.	1 1 2 1 1 1 1 1	81-C 9A-C 196-C 196-C 10A-C 52-C 202-C 198-C
190 192 249 250	Gaskets Cylinder head gasket Cylinder head to butterfly valve casing gasket. Air suction fitting gasket. Oscillating magneto gasket.	1 1 1 1	
	Tools Large wrench Small wrench	1 1	

TROUBLE CHART


Trouble	Possib	ole Cause		See Para- graph
Engine will not start.	Instructions were not followed.		Read and follow instructions.	6-13
	No fuel in tank	ς.	Fill tank.	6
	Water in gasol	ine used in starting.	Separate water.	
	Water in engir	ne cylinder.	Water will work out if engine is turned over slowly several times.	
			See that gasket is unbroken.	22
	Engine flooded	d.	Close fuel throttle and crank engine.	13
		(Valve leaks.	Grind valves.	21
	Poor compression.	Head gasket leaks.	Put on new gasket.	22
		Piston blows.	Remove rings and clean.	23
130	Engine very cold.		Put little water in hopper (preferably hot water).	7
		Oscillator.	Remove oscillator; trip with hand lever and note if spark occurs.	Inst. 2530
		Mechanism sluggish.	Oil all parts well and loosen with kerosene.	Inst. 2530
	No spark or poor spark.	Igniter dirty.	Take out igniter; clean points.	Inst. 2530
		Short circuit.	Clean insulated electrode.	Inst. 2530
		Movable electrod sticking.	e Remove and clean. Spring should hold points together.	Inst. 2530
Engine misses fire after		(Mechanism sluggish.	Oil all parts.	Inst. 2530
being started	Ignition.	Short circuit.	Clean. See that insulation on wire is good.	Inst. 2530
	Igniter dirty.		Clean.	Inst. 2530
Engine uses	Throttle ope	en too far.	Close partly.	15
too much fue	l. Poor compre	ession.	See "Engine will not start."	21, 22, 2
	Late ignition.		Time correctly.	Inst. 2530

Trouble Chart—Fairbanks-Morse Type "Z" Oil Engines

Trouble	Possi	ble Cause	Remedy	See Para- graph
Engine uses too			Reset.	33
(continued)	Exhaust pipe or silencer choked.		Clean.	
	Fuel drips from suc- tion pipe.	Weak suction valve spring.	Lengthen spring by stretching. Order new spring.	
Carbon forms.	Too much fuel		Close throttle partly.	15
	Too much lub	ricating oil.	Adjust lubricator.	8
	Engine too col	d.	See that engine is hot before turning on oil fuel.	15
Engine smokes.	Exhaust.	Too much lubricating oil.	Adjust lubricator.	8
		Too much fuel.	Adjust fuel throttle.	15
	Piston.	Piston blows.	Remove piston; clean rings; may need new rings.	23
Cylinder oiler does not feed	Filler opening left open.		Screw in plug after filling.	8
properly.	Piston blows.		Clean piston and rings; may need new rings.	23
Water boils	Mixture too ri	ch.	Close throttle.	15
rapidly.	Late ignition.		Correct.	Inst. 2530
			Never let the water get below top of cylinder.	
Engine misses fire after	Igniter dirty.		Clean.	Inst. 2530
being started.			Remove water from tank.	30
	Fuel	Dirty.	Clean out tank, check valve	31
		Throttle adjust- ment.	Carefully set throttle.	15
	Engine cold.		Use less water.	7
Engine knocks.	Hard explosion	n.	Remove head and clean carbon.	21
	Loose crank p	in bearing.	Take up bearing.	36
	Roller jumps of	on cam.	See that rod slides freely.	
	Scale formation engine to ov		Clean out scale.	40
	Engine uses too much fuel. (continued) Carbon forms. Engine smokes. Cylinder oiler does not feed properly. Water boils away too rapidly. Engine misses fire after being started.	Engine uses too much fuel. (continued) Exhaust pipe of from suction pipe. Carbon forms. Too much lub. Engine too col. Engine smokes. Exhaust. Piston. Cylinder oiler does not feed properly. Water boils away too rapidly. Engine misses fire after being started. Engine knocks. Exhaust. Water in fuel of fuel tank. Fuel. Engine cold. Engine cold. Engine knocks. Hard explosion Scale formatic	Engine uses too much fuel. (continued) Exhaust pipe or silencer choked. Fuel drips from suction pipe. Weak suction valve spring. Carbon forms. Too much fuel. Too much lubricating oil. Engine smokes. Exhaust. Too much lubricating oil. Engine smokes. Exhaust. Filter opening left open. Piston blows. Cylinder oiler does not feed properly. Piston blows. Water boils away too rapidly. Engine misses fire after being started. Engine misses fire after being started. Engine knocks. Exhaust. Dirty. Throttle adjustment. Engine knocks. Hard explosion. Loose crank pin bearing. Roller jumps on cam. Scale formation in jacket causes	Engine uses too much fuel. (continued) Exhaust pipe or silencer choked. Exhaust pipe or silencer choked. Exhaust pipe or silencer choked. Fuel drips from suction pipe. Weak suction valve spring. Carbon forms. Too much fuel. Engine too cold. Engine too cold. Engine smokes. Exhaust. Too much lubricating oil. Engine smokes. Exhaust. Too much fuel. Piston. Piston. Piston See that engine is hot before turning on oil fuel. Adjust lubricator. Adjust lubricator. Remove piston; clean rings; may need new rings. Remove piston; clean rings; may need new rings. Piston blows. Clean piston and rings; may need new rings. Mixture too rich. Late ignition. Correct. Never let the water get below top of cylinder. Engine misses fire after being started. Water in fuel collects in bottom of fuel tank. Fuel. Dirty. Throttle adjust-ment. Engine cold. Engine cold. Use less water. Engine knocks. Hard explosion. Engive cold. Exhaust valve setting off. Clean out tank, check valve carefully set throttle. Take up bearing. Roller jumps on cam. See that rod slides freely. Scale formation in jacket causes Clean out scale.

Trouble Chart—Fairbanks-Morse Type "Z" Oil Engines

Trouble	Possible Cause	Remedy	See Para- graph
Engine runs irregularly.	Governor stuck.	See that governor parts are free. Use kerosene to loosen.	
		Adjust (33) spring.	25
	Weak exhaust valve spring.	Put washer under spring till new spring can be obtained.	
	Auxiliary air valve.	See that valve moves freely and spring is not broken.	
Engine tends to run away.	Butterfly may not close.	Adjust butterfly crank and governor travel.	-26
Engine will not	Exhaust valve setting off.	Reset.	32, 33
carry load.	Poor compression.	See"Engine will not start."	21, 22, 23
	Late ignition.	Correct.	Inst. 2530
	Too rich mixture.	Adjust fuel throttle.	15
	Carbon in combustion space.	Remove head and clean.	21
- 学生	Silencer clogged.	Clean out.	
	Butterfly moved.	Reset.	26
	Scale formation in jacket causes engine to overheat.	Clean out scale.	40



INSTRUCTIONS No. 2532 FOR STARTING 1½ H. P. THROTTLING GOVERNOR TYPE "Z" ENGINE


(2) FILL OIL CUP AND ADJUST FLOW

(3) PUT WATER IN HOPPER to just cover cylinder, using hot water in winter. When engine has run awhile fill two-thirds full and add more as water boils away. Never let it get below top of cylinder.

(4) FILL OIL FUEL TANK

(5) FILL GASOLINE RESERVOIR

(6) OPEN GASOLINE THROTTLE about one turn. As soon as engine starts set this where engine runs best.



(7) HOLD SUCTION VALVE OPEN and spin engine with starter crank. Release valve after one or two turns, then close air suction with fingers for one suction, then remove fingers continuing to crank. Engine will be flooded if suction is closed too long.


(9) AS ENGINE HEATS UP, gradually open oil fuel throttle and close gasoline throttle. Adjust to point where engine runs best.

(8) REMOVE STARTER CRANK

FAIRBANKS, MORSE & CO.

(INCORPORATED)

Fairbanks-Morse Type "Z" Oil Engines



FAIRBANKS, MORSE & CO.

CHICAGO, ILL.

Atlanta, Ga.
Baltimore, Md.
Boston, Mass.
Buenos Aires
Cincinnati, Ohio
Cleveland, Ohio
Dallas, Tex.

Denver, Colo.
Des Moines, Ia.
Detroit, Mich.
Indianapolis, Ind.
Jacksonville, Fla.
Kansas City, Mo.



Los Angeles, Cal.
Louisville, Ky.
Milwaukee, Wis.
Minneapolis, Minn.
New Orleans, La.
New York, N.Y.
Omaha, Neb.

Portland, Oregon
Salt Lake City, Utah
San Francisco, Cal.
Spokane, Wash.
St. Louis, Mo.
St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited

Toronto Montreal Vancouver

Hamilton Victoria

Calgary Ottawa St. John, N. B. Winnipeg Hamilton Victoria Quebec Edmo Edmonton

INSTRUCTIONS No. 2548A

FOR SETTING UP AND OPERATING


Fairbanks-Morse

1½, 3 and 6 H. P. "Z"

Throttling Governor Engines

Model "ZA"


This book should be carefully read before attempting to do anything with the engine




(3509G)

FAIRBANKS, MORSE & CO.

(Copyright, 1919, by Fairbanks, Morse & Co.)





INSTRUCTIONS No. 2548A

For Setting Up and Operating Fairbanks-Morse 1½, 3 and 6 H. P. "Z" Oil Engines (MODEL "ZA")

bolts sent. With steel pulleys larger than 4 in catch inside the curled rim and take the bolts. 1. Remove engine from crate, being careful to avoid damage. Screw oil cup 527, on cylinder oil pipe. Bolt the pulley on the flywheel opposite the governor using the bolts sent. With steel pulleys larger than 4 inch 3 bent, steel clips are furnished, to

When Engine is Received

2. When it is desired to place the pulley on the governor side, it will be necessary to reverse to the small dog in the starter crank so as to use it on the other side, the direction of motion always being as shown in Fig. 40ZAA.

Clean All Parts.

See That the Governor Parts Are Free From Dirt or Paint

parts are free. Oil all moving parts and turn the flywheel over by hand slowly to see that all

will be furnished free on request. Leave two or three feet of room all around the engine. If engine is to be located on a foundation, follow the foundation plans, which Foundation

pipes so a small hole or other drain should be provided where water might collect. When the pipe is long (20 feet), or has several elbows (4), the pipe should be increased in size and better results will be obtained if an exhaust pot is installed near the engine. 7. If the engine is installed in a building the exhaust should be piped outside. This pipe should be short and with few bends. Water may collect in long exhaust Water may collect in long exhaust

8. These engines can use as fuel, Gasoline, Motor Spirits, Kerosene and some varieties of Power Distillate. In this book the fuel will be called "Oil Fuel".

Fuel

If Located in a Building

familiar with its operation. Read the Tags on the Engine But Do Not Remove Them Until you are Read Tags

WHAT TO DO BEFORE STARTING

10. Fill the oil fuel tank.

11. Put water in hopper, but only enough at first to cover top of cylinder. cold weather hot water will make the engine easier to start. In

Tighten Cylinder Head Nuts.

13. Fill oil cup (527, page 3), with good Gas Engine oil (we recommend Hytest), and adjust oiler to feed 8 drops per minute on $1\frac{1}{2}$ H. P., 12 drops per minute on 3 H. P., 20 drops per minute on 6 H. P. Gradually cut down the amount as the engine becomes worn in, until in a month one-half the above quantities are used.

Oiling

Cooling Water

Tighten Nuts

turns until grease is forced freely into bearings. on the crank pin bearing 509A, page 3). Fill the three grease cups. Two (505, page 3), are on main bearings. The other is the crank pin bearing 509A, page 3). They should be screwed down one or two

14. With a hand oil can go over the engine and oil the governor and all other places where there are oil holes, and where one part moves against another. In freezing weather, squirt a little oil on piston where end comes out of cylinder. The cylinder oiler may not feed until it is warmed up.

Oil by Hand

TO START ENGINE

Fill reservoir (4B) with gasoline.

ing as well as running. Close oil throttle (76B), open gasoline throttle valve (376A, page 2), about ... If the engine is run on gasoline, throttle valve 76B may be used for start-

crank spin the engine. Holding the suction or upper valve open with the left hand, with the starter pin the engine. After getting the engine in motion, release the suction valve


Fuel Valve Gasoline for Starting

Starting

and close the air inlet opening in end of air suction fitting with fingers of left hand for one revolution only, and then remove fingers while still continuing to crank. If held longer, too much fuel will be drawn in. The mixture will not ignite if there is too much fuel in it.

the engine. 18. Too much fuel used in starting (particularly with a hot engine) will "**FLOOD**" the engine. When flooded, close the fuel throttle, relieve the compression by holding suction valve open with the finger and turn the flywheel over a number of revolutions in order to work out the excess fuel.

Flooded Engine



AFTER THE ENGINE IS STARTED

gasoline throttle valve to the point where engine runs best. After the engine takes its first impulse, remove the starter crank; adjust the

Running on Oil Fuel to run well on the fuel oil alone. After closing gasoline throttle, the oil fuel throttle should again be adjusted to give as little fuel as the engine will run on smoothly. In cold weather it may require two fillings. When engine is warm enough gradually open the oil throttle valve (76B), and close gasoline throttle valve (376A). It is well to have the gasoline throttle valve slightly open until the engine is hot enough and should generally point down when the engine is in operation. The handle of the oil fuel throttle is marked at the factory when the engine is tested The engine will usually run on oil fuel after using one reservoir full of gasoline

21. Fill water hopper two-thirds full and replenish this water as it boils away.

Attention to this matter will prevent the blowing out of cylinder head gaskets Tighten Cylinder Head Nuts after engine has been run and warmed up


Tighten Nuts

Fill Hopper

TO STOP ENGINE

24. To stop engine, first close oil fuel throttle valve (76-B), then close cylinder oiler (527), and in freezing weather drain out the water from cylinder jacket through plug (327A) provided.

To Stop



DESCRIPTION OF PARTS OF ENGINE AND MANNER OF ADJUSTMENT

25. Should the engine on starting turn too easily, it has lost compression because some leak is taking place. The suction valve as well as exhaust valve should be examined. If they seat tightly, examine piston (see paragraph 30).

Lost'Com-pression

Suction Valve

friction spring (120), (patented), causing a friction on the suction valve spring collar and has a lift of about three-eights of an inch. (121), and prevents chattering. Oil this occasionally and has a lift of about three-eights of an inch. The lift is limited by means of a spring (310), on the valve stem. This valve on 3 and 6 H. P. engines is also fitted with a The suction valve (9B), is an ordinary check valve, automatic in its action

27. The exhaust valve (10A), like the suction valve is in the cylinder head with spring and stem outside in plain sight. If it sticks, use kerosene, work it by hand, then put on some lubricating oil

fully clean both valve and seat before replacing. 28. If it is necessary to grind suction or exhaust valve, the cylinder head may be removed and the valves ground in with ground glass or fine emery and oil. Care-


Cleaning and Regrinding Valves

Exhaust Valve

Carbon Head Gaskets

28½. Carbon may best be cleaned out by taking off the cylinder head

applied. Before applying gasket scrape off all traces of old gasket. Gasket material should be long fiber asbestos sheet about 3/64" inch thick. After putting on new gasket (190) the nuts should be tightened and again when engine is hot. Asbestos gaskets hold better if covered with linseed or lubricating oil when



(3883G) then with the help of a screw driver the other strips can be slipped one piece of tin under the middle of the ring and over the ring groove pin will get no oil. The rings can be removed from piston by taking three strips of tin about one-half inch wide and six inches long, slip it right side up before bolting on connecting rod cap otherwise under the ends and the rings in turn slipped off the piston scrape off all carbon found inside. solution of lye and water. placing. In replacing piston, turn it bottom side up so that the stop pins can be seen, otherwise the rings may be broken. Be sure to turn 30. The piston may be taken out without unbolting cylinder head. Take off shield and unbolt the rod. Turn crank to out position. The piston may now be withdrawn. Loosen the rings and clean the grooves, Oil the piston well before re-Clean with gasoline or a hot

Paton

Picton Rings

Removing Piston Pin

31. To remove piston pin (7) use screw driver to take out taper dowel pin screw (72). Force out taper dowel pin (71) from inside of hollow pin. This allows the pin to be driven out. In returning parts be sure to put the lock washer in between the lock pin and screw.

of which is to steady the governor action. The force of the spring can be adjust by small screw (321). If there is too much tension the governor will be slow will jump at each explosion. respond to change in load. If not enough tension, the governor rod (205A, page 3) The governor is fitted with a friction drag spring (33B, page 9), the purpose is to steady the governor action. The force of the spring can be adjusted

Butterfly Valve remove end of governor rod (205A) from arm (206B, page 9). Pull one governor weight (82A) out as far as it will go and then put a wedge under it to hold it in that position. Slightly loosen clamp screw of arm (206B). Close butterfly by turning shaft in clockwise direction with fingers and set arm (206B) pointing up so that governor rod lacks 1/16" from going in hole of arm. Remove wedge from under governor weight. Tighten clamp screw of arm (206B) and reassemble parts removed. If these instructions are followed the engine cannot run away. page 9), take cotter pin out of butterfly arm end of go remove end of governor rod (205A) from arm (206B, page 9). 33. If it is necessary for any reason to reset the butterfly crank arm governor rod (205A)

34. The governor normally holds the engine at its rated speed, but each engine is provided with a speed regulator which decreaess the speed by turning the head screw (224A, page 3). The engine should not be run continually at low speed.

Engine Speed

Suction Feed plenty of fuel in the tank, examine the check valve (89, page 9). This has a fine wire screen in the lower end which may be clogged. The auxiliary air valve is at the air inlet of the reservoir (4B). It should work freely at all times. engine should miss fire or back fire in the air suction or show lack of power with planty of fuel in the tank, examine the check valve (89, page 9). This has a fine Fuel is lifted from the tank into the reservoir (4B) by suction. If the


Piping together with the fuel tube and check valve can then be removed. cap (47) and take out the two screws that hold the air suction fitting. This fitting together with the fuel tube and check valve can then be removed. On 3 and 6 H. P. take out the two screws that hold valve seat clamp (297); this fitting together with fuel tube and check valve can then be removed. 36. To remove fuel piping and check valve from fuel tank on 1½ H.P., unscrew

This tank is provided with a drain closed by a pipe plug

Fuel Tank

Setting Gears The pinion (29A, page 3), on crank shaft has one tooth with two center punch marks. This tooth should come between the two marked ones on the large gear (28B, page 3). If engine is taken apart and the marks on gears cannot be found, or if old gear is replaced by a new one, the engine should be timed as follows: 40. The cam gear is marked with center punch marks on face of two teeth

Valve Timing set the cam gear with the nose of the cam straight up. this clearance by the two nuts on exhaust rod. Such a setting should bring the alve timing very nearly as described in paragraph 42 /32" clearance between end of exhaust rod and the valve rocker arm. Turn the engine to where the crank (25B, page 8), is straight up. Then am gear with the nose of the cam straight up. Next see that there is about Adjust to



Instructions—Fairbanks-Morse "Z" Oil Engines

42. The cam should begin to open the exhaust valve 30 degrees to 35 degrees before outer dead center (40-ZAA) of crank. The cam should close the exhaust valve when the crank is in position shown in Fig. (41-ZAA) or about 5 degrees above the inner dead center. The valve can be turned with the fingers as soon as it is lifted from its seat.

43. In order to remove the cam gear, take out the two screws holding cam gear bracket to base. All parts attached to bracket can then be inspected. In replacing, take care to properly mesh the teeth of cam gear and crankshaft pinion (paragraph 40.)

Removing Cam Gear

(41ZAA)

can be drawn tight without clamping the shaft. 44. Crank shaft bearings can be adjusted by unbolting caps and removing one or two of the thin shims. In reassembling, the bolts must be drawn up tight and yet the shaft must turn perfectly free. If not free, shims should be put back until bolts

Bearing Adjustment

of new linings may be needed to make them fit perfectly. These bearings all have removable linings. A little fitting and scraping Renewals

46. THE WATER SHOULD NEVER BE ALLOWED TO FALL AS LOW AS THE TOP OF THE CYLINDER WALL, as the cylinder will get too hot. It is expected that the water will boil under heavy load. Put in more water as it boils away. It is Cooling

IF water is left in during cold weather unless non-freezing solution is used. THE ENGINE JACKET IS LIABLE TO BE BROKEN BY FREEZING

48. A non-freezing mixture of calcium chloride and water may be used in the jacket. Three pounds of calcium chloride to each gallon of water will not freeze solid at Zero Fahrenheit. It is better, however, to drain the jacket in freezing weather when the engine is not in use.

49. While the deposit or scale varies in character in different localities it can usually be removed by draining the engine cylinder jacket, and filling the jacket with a solution of one part commercial sulphuric acid to ten parts water. Allow to stand over night and then wash out with fresh water.

Removing Scale or Deposit

Non-Freezing Solution

Broken by

50. Loosen bolt and drive wedges into the split on each side of arms, generally the wheel is then loosened so it can be easily pulled off. If not, drive it by placing piece of hard wood against the inside hub of wheel. In replacing, tighten the bolt before driving the key.

will be about 1/32" end play to the shaft. The flywheels should be slightly set out from main bearings so that there


Flywheel

End Play

Instructions 2550 cover the care of the magneto and spark plug.

Magneto

Repair Parts List—Fairbanks-Morse "Z" Oil Engines



REPAIR PARTS LIST

For Fairbanks-Morse 11/2, 3 and 6 H. P. Throttling Governor "Z" Oil Engine

When ordering parts, always give the size, the type and shop number of the engine. The number is very important. It is stamped on the top of the cylinder and cylinder head flanges. Do not fail to give it.

Parts may be ordered individually or in groups.

A Group Number printed in heavy type, followed by the letter C, such as "3D-C" covers all items in that paragraph down to the first horizontal line, thus.

An ordinary repair number printed in light type (such as "3D"), covers that one part only

it is used. Any part without a repair number is listed directly after the numbered part with which

For repairs on 11/2 H. P. with rotary magneto, see instructions 2407D.

For repairs on 11/2 H. P. with Sumter oscillating magneto, see instructions 2528.

For repairs on 3 H. P. engines previous to No. 185864 and 6 H. P. engines previous to No. 185978, see repair parts and price list No. 9417.


For repairs on 3 H. P. engines between 185864 and 268918, and 6 H. P. engines between 185978 and 267250, see instructions 2417C.

For repairs on 3 H. P. and 6 H. P. engines with Sumter oscillating magneto, see instructions 2417D.

4B	3D		1B	Repair Nos. Arranged Numerically
AB-C Reservoir (1 1/2 H.P.)	SD-C Cylinder Head	Cylinder to head studs, short Cylinder to head studs, long. Cylinder to head stud nuts. Cylinder to subbase bolts Cylinder to subbase bolt nuts Cylinder to subbase washers Cylinder to subbase washers Cylinder to subbase cap screws.	Cylinder and base, always fitted with head studs, main bearing caps (12) with cap screws and lock washers, main bearing shims (126 and 126A). Main bearing liners (23A). Hopper (502), hopper bolts, nuts and washers, hopper gasket (191)—(3 & 6 H. P.).	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.
1 1		81444	1 1	No. Us 11/2 H.P.
Ada Maria		ω H 4 · · · · 4	1	No. Pieces Used $11/2 \mid 3 \text{ or } 6$ I.P. $\mid \text{H.P.}$
		1B-C		Included in Group

13 H. P. "Z" Throttling Governor Kerosene Engine on Hand Truck

Before ordering parts, read the instructions above



0	
54	10
8A	0
-	

Repair Parts List-Fairbanks-Morse "Z" Oil Engines

Refere ordering party read the instructions on page 7	(20A), piston pin bushing 17. Connecting rod shims (110-110A), connecting rod bolts (150), connecting rod bolt nuts (151), connecting rod bolt cotters, connecting rod grank pin liners (176)			Fuel tank, always fitted with filler cap (44), drain fitting with plug	Subbase	14A Subbase, always fitted with engine fill-up pieces (234), spacers (233), spacer bolts, and end bolts Fuel tank (15C)	Flywheel clamp bolt	13B Flywheel, always fitted with clamp bolt	11A Exhaust valve spring collar	10A Exhaust valve	9B-C Suction Valve (3 or 6 H. P) Suction valve Suction spring (120), spring collar (121), spring collar lock (122), suction valve spring (310)	9B Suction valve with cotter Suction valve spring (310)	6 Piston rings	5A Piston always fitted with ring stop pins	4B-C Reservoir (3 or 6 H.P.)	Repair Nos. Arranged Numerically The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group. I
-	<u>Q</u> <u>v</u> . 7	1	1), 1	2	2	4421	 			μω	7 景: :	vv.	11/2 H.P.
	Р	1	-	-			2	2	4421	1			1 3		, , ,	Used 1/2 3 or 6 1.P. H.P.
			18A-C	14A-C					10A-C 1B-C 1B-C 1B-C	3D-C	3D-C	3Д-С	5A-C 5A-C			Included in Group No.
	0									. (Ü

Before ordering parts, read the instructions on page 7.

Repair Parts List-Fairbanks-Morse "Z" Oil Engines

2	1	
548	1	-
8		

)
55A 55A 58A 60B 63A 771 72 78B 79A 80A	47 48A 50A	41A	40A-C	39B	37B	36B	29A 30B 33B 34B 35B	28B	28B	· 26A	25B	20A 23A 24A	Arranged Numerically	Ranair Nos
Exhaust rod end. Exhaust roller rocker fulcrum pin with cotter. Exhaust roller rocker fulcrum pin with cotter. Exhaust roller rocker fulcrum pin washer. Exhaust roller rocker fulcrum pin washer. Exhaust roller rock pin. Piston pin taper lock pin. Piston pin taper lock pin screw. Piston pin taper lock pin lock washer. Fuel throttle valve. Governor weight pins.	Fuel tank suction opening cap	41A-C Exhaust Valve Rocker Bracket Exhaust valve rocker bracket Exhaust valve rocker (39B), exhaust valve rocker fulcrum pin (40A-C). Fuel tank filler opening cap	40A-C Exhaust Valve Rocker Fulcrum Pin. Exhaust valve rocker fulcrum pin, always fitted with oil cup 741. Exhaust valve rocker fulcrum pin nut. Exhaust valve rocker fulcrum pin lock washer.	Exhaust valve rocker always fitted with oil cup (741)	37B-C Cam Gear Bracket	Exhaust RodExhaust rod end (55A), exhaust rod end nut (355).	Crankshaft pinion	28B-C Cam Gear 3 or 6 H. P	28B Cam Gear 1½ H. P. Cam Gear, always fitted with cam shaft 30B, cam 128A, cam shaft to gear screw, magneto trip pin (337)	Exhaust silencer	Crankshaft, always fitted with crankshaft pinion (29A) and pinion key 159 (and thrust washer (160) $1\frac{1}{2}$ H. P.	Connecting rod cap (not furnished separately) Main bearing liner (halves) Fuel suction tube (not furnished separately)	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	
- 5 :				-	н н					1	1	141	11/2 H.P.	No. Pieces
- 0 0		-		1	<i>—</i> —			н н		1	1	141	3 or 6 H.P.	ieces
36B 37B 4B-C 37B-C 5A-C 5A-C 5A-C 5A-C 5A-C	89-C 81A-C 37B-C	15-C	41A-C	41A-C			25B 28B-C 81A-C 50A-C	37B-C	37B-C			18A-C 1B-C 89-C	in Group	Included

Before ordering parts, read the instructions on page 7.

2	-
48	20
A	

Repair Parts List—Fairbanks-Morse "Z" Oil Engines

81A-C 81A-C 81A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 93A-C 89-C 14A-C 93-C 14A-C 93-C 14A-C 93-C 14A-C 93-C	2 :		(308A), governor weight spring adjusting (156A), governor weight pins (79A). Grovernor gadjusting screw and nut, governor (33B), f spring adjusting screw and nut, governor lever fulcrum pin and check valve ball. Governor lever fulcrum pin ball. Fuel check valve ball (90A), suction tube connection check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve ball (90A), throttle valve seat (197 and check valve strainer (not furnished separate ball the check valve strainer (197 and check valve spring collar lock (197 and check	89 89 89 89 89 89 80 80 80 80 80 80 80 80 80 80
37B-C	P.P.	μн	Governor spindle Governor sleeve pui	81A
Included in Group No.	No. Pieces Used 1/2 3 or 6 H.P. H.P.	No. 1 Us 11/2 H.P.	The Group Number in Heavy Type when shown at the Head of a group of Parts, includes all items mentioned in that Group.	Repair Nos. Arranged Numerically
EDIT STITE	CIL	1	W TO THE CONTRACT OF THE CO.	2548A

Before ordering parts, read the instructions on page 7.

Repair Parts List-Fairbanks-Morse "Z" Oil Engines

13 2548A

			1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Defens
81 A-C 9B-C		<u></u>	Governor weight spring.	308A 310
4B-C		1	r oiler	271A 297
728 A-C		<u> </u>	Starter crank pawl fulcrum pin	266A 267
728 A-C		<u></u>	ir gasi crank	249A 265B
14A-C 4B-C	· :	4	end	247
14A-C		44	Subbase end bolts Subbase end bolts Subbase end bolt nuts	TO4
14A-C		000		924
		100	spacers	233
209 A-C		э 	Speed regulator leaf spring (not furnished separately) Speed regulator adjusting screw	222A 224A
	-	1	Speed regulator lever fulcrum pin	212A
93A-C			209A-C Speed Regulator Lever Speed regulator lever always fitted with speed regulator leaf spring (222A)	209A
203B-C			Governor pull rod with two cotters	205A 206B
203B-C 203B-C 203B-C			Butterfly valve screwsButterfly valve screw lock washersButterfly valve stem	204B
			Butterfly valve stem (204B), valve screws and lock washers, butterfly valve stem arm (206B), butterfly valve stem arm screw, butterfly valve stem spring (326B).	Ű
202A-C 1½ H.P. 4B-C (3&6H.P.		μн	7e	203B
			202A-C Butterfly Valve Casing (1½ H.P.) Butterfly valve casing Butterfly valve (203B-C).	202-A
4B-C 4B-C 198-C 198-C		22	Air valve seat to reservoir screws Air valve seat to reservoir lock washers Air valve Air valve guide Air valve guide Air valve guide cotter	199 200A
			198-C Air Valve Seat	198
4B-C	1212121	2221	Name plate. Name plate screws. Name plate washers. Name plate washers. Name plate washers. Name plate washers.	195B 197
1 B -C		· -	Cylinder to head gasket	190
in Group	3 or 6 HP.	11/2 H.P.	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	Arranged Numerically
Included	ieces ed	No. Pieces Used	The state of the s	Repair Nos.

Before ordering parts, read the instructions on page 7.

C		
Ž		_
8	H	A
Ď		

Repair Parts List-Fairbanks-Morse "Z" Oil Engines

Refore orderi	273A Magn Magn Magn	Magnet Large w Small w Funnel.	190 Cylin 191 Cylin 192 Butte 247 Air v 249 Reser	311A Thro 317 Exha 326B Butte 336 Auxil 314A Reser		741 Exha 742 Early		A	505 509A Conn 527 Cylii	376A Star 484 Pulle 502 Hopp Hopp Hopp			38A 38A		Arranged In Numerically	
no norte read the instructions on name	with	Toco tripping handle renchrench	749A-C Complete Set of Gaskets. Cylinder head gasket. Cylinder to hopper gasket. Butterfly valve casing gasket Air valve seat gasket. Reservoir gasket.	Suction valve spring. Throttle valve springs. Exhaust valve spring. Butterfly valve torsion spring. Auxiliary air valve spring. Reservoir cover spring.	748A-C Complete Set of Springs.	Exhaust valve rocker oil cup	Spark plug cover Spark plug nut Spark plug nut Spark plug nut Spark plug nut Magneto cable conduit	728A-C Starter Crank Starter crank—always fitted with Starter crank pawl (265B), starter crank pawl pin (266A), starter crank pawl spring (267)	bearing grease cup	Starting fuel throttle. Pulley bolts, 1½ H. P. Hopper Hopper to cylinder bolts. Hopper to cylinder bolts. Hopper to cylinder bolts. Hopper to cylinder bolts.	Early and late wight (338), with pin (742). Exhaust rod end nut. Grease cup support.	Magneto trip pin Magneto trip nut. Magneto early and late weight 339-C Early and Late	Governor weight friction spring adjusting screw. Butterfly valve stem torsion spring. Cylinder head drain plug. Base drain plug. Auxiliary air valve spring	Fuel throttle valve spring	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all items mentioned in that Group.	
-			н н н		- 1-	2	<u> </u>	1	1					2	11/2 H.P.	No. J
1				2-	11	2			112	1 1 4 or 6 4 or 6				112	3 or 6 H.P.	No. Pieces Used
				9B-C 4B-C 10A-C 203B-C 198A-C 4B-C	81A-C	339-C	50A-C		1B-C	4B-C	36B-C	28B-C 28B-C 339-C 28B-C	81A-C 203B-C 3B 1B 198-C	4B-C	in Group	Included
	-							0						1		9

Before ordering parts, read the instructions on page 7.

Trouble Chart—Fairbanks-Morse "Z" Oil Engines


15 2548A

TROUBLE CHART

Engine tends to run away.			Engine runs irregularly.		Engine misses fire after being started.					'										Engine will not start.	Trouble
Butterfly may not close	Auxiliary air valve	Weak exhaust valve spring	Governor stuck		Ignition.			or poor spark.			Engine very cold		Poor compression.		Engine flooded	maner m engane of muce.	Water in engin	Water in gasoli	No fuel in tank	Instructions not followed.	Possik
not close.	dve.	alve spring.		Wire grounded.	Spark plug dirty. Spark plug grounded.	Mechanism slug- gish cold weather.	Oscillator	Gap too wide.	Grounded.	Spark plug dirty.	ld.	Piston blows.	Head gasket leaks.	Valve leaks.	flooded with fuel.	C CY IMMACL.	e evlinder	Water in gasoline used in starting.		t followed.	Possible Cause
Adjust butterfly crank and governor travel.	See that valve moves freely and spring is not broken.	Put washer under spring till new spring can be obtained.	See that governor parts are free. Use kerosene to loosen. Adjust (33B) spring.	See that wire from magneto is not grounded.	Take out and clean. Porcelain broken in plug.	0	Remove spark plug, trip oscillator with hand lever, note if spark occurs.	Set spark plug gap to thickness of a smooth dime.	See that wire from magneto is not grounded.	Take out and clean.	Put but little water (preferably hot water), in hopper.	Remove rings and clean.	Put on new gasket.	Grind valves.	Close fuel needle valve, open suction valve and crank engine.	See that gasket is un- broken.	Spin engine by hand, holding suction valve open.	Drain out water.	Fill tank.	Read and follow instructions.	Remedy
33	35		32								11	30	29	28	18	29	18		10	1-18	See Para- graph

Trouble Chart—Fairbanks-Morse "Z" Oil Engines

away too rapidly. Should use 1 gallon per horse-power hour.	Water boils			Carbon forms.		Cylinder oiler does not feed properly.				too much fuel.	Engine uses			smokes.	Engine			Engine knocks.					carry mad.	Engine will not	Trouble
	Mixture too rich.	Engine too cold.	Too much lubricating oil.	Too much fuel.	No vent in shank of oiler.	Piston blows.	Fuel drips from suction suction pipe. Weak suction valve spring.	Exhaust pipe or silencer choked.	Exhaust valve setting off.	Poor compression.	Throttle open too far.	Piston blows.	Piston. Oil thrown into piston by crank.	Exhaust. { ing oil. { Too much fuel.		Scale formation in jacket.	Loose drank pin bearing.	Hard explosion.	Butterfly moved.	Silencer clogged.	Carbon in combustion space.	Too rich mixture.	Poor compression.	Exhaust valve setting off.	Possible Cause
Never let the water get below top of cylinder.	Close throttle.	See that engine is hot before turning on oil fuel.	Adjust cylinder oiler.	Close throttle partly.	Drill 3/16" hole into the oil feed pipe below oiler.	Clean piston and rings; may need new rings.	Lengthen spring by stretching. Order new spring.	Clean.	Re-set.	See "Engine will not start."	Close partly.	Remove piston, clean rings, may need new rings.	Drain and clean out crank case.	Adjust fuel throttle.	Adjust lubricator.	Clean out scale.	Take up bearing.	Remove head and clean carbon.	Re-set.	Clean out.	Remove head and clean.	Adjust fuel throttle.	See "Engine will not start."	Re-set.	Remedy
	20	20	13	20		30			41	28, 29, 30	20	30		20	13	49	50	$28\frac{1}{2}, 29$	333		$28\frac{1}{2}, 29$	20	28, 29, 30	41, 42	See Para- graph



FAIRBANKS-MORSE "Z" ENGINES

Fairbanks, Morse & Co.

Chicago, Ill.

Atlanta, Ga. Baltimore, Md. Boston, Mass. Buenos Aires Cincinnati, Ohio Cleveland. Ohio Dallas, Tex. Denver, Colo. Des Moines, Ia. Detroit, Mich. Indianapolis, Ind. Jacksonville, Fla. Kansas City, Mo. London



Los Angeles, Cal. Louisville, Ky. Milwaukee, Wis. Minneapolis, Minn. New Orleans, La. New York, N. Y. Omaha, Neb. Portland, Ore. Salt Lake City, Utah San Francisco, Cal. Seattle, Wash. Spokane, Wash. St. Louis, Mo. St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited

Halifax St. John, N. B. Quebec Montreal


Ottawa Toronto Hamilton Windsor Winnipeg Saskatoon Calgary Vancouver Victoria

INSTRUCTIONS No. 2498

FOR

Fairbanks-Morse

Type "Y" Horizontal Oil Engine Combined Pumpers



FAIRBANKS, MORSE & CO. (INCORPORATED) (Copyright, 1918, by Fairbanks, Morse & Co.)

FAIRBANKS, MORSE & CO.

(INCORPORATED)

Chicago, Ill.

Atlanta, Ga. Baltimore, Md. Boston, Mass. **Buenos Aires** Cincinnati, Ohio Cleveland, Ohio Dallas, Tex. Denver, Colo. Des Moines, Ia. Detroit, Mich. Indianapolis, Ind. Jacksonville, Fla. Kansas City, Mo. London



Los Angeles, Cal. Louisville, Ky. Milwaukee, Wis. Minneapolis, Minn. New Orleans, La. New York, N. Y. Omaha, Neb. Portland, Ore. Salt Lake City, Utah San Francisco, Cal. Seattle, Wash. Spokane, Wash. St. Louis, Mo. St. Paul, Minn.

The Canadian Fairbanks-Morse Co., Limited

Calgary Edmonton Hamilton Montreal

Ottawa Quebec Saskatoon St. John, N. B.

Toronto Vancouver Victoria Winnipeg

Instructions—Type "Y" Horizontal Oil Engine Combined Pumpers

INSTRUCTIONS No. 2498

Fairbanks-Morse Type "Y" Horizontal Oil Engine Combined Pumpers

To be used in connection with Engine Instruction Book.

The foundation should be prepared in accordance with the drawing furnished and

the instructions in the Engine Instruction Book.

The suction and discharge pipe sizes specified on the foundation plans are correct for moderate lengths. When the suction pipe is over 100 feet in length it is desirable to increase its diameter, as the friction head will add to the work done and must be

Suction Pipe

Foundation

Size of Piping

Care should be taken in making up the suction pipe to get it tight. A very small leak will cause trouble. The suction pipe should be laid from the pump on a grade, with the pump end the highest point, and without air pockets. Long sweep fittings are preferred. A drain may be provided below frost line to let out water in freezing weather.

Foot Valve

Where the suction pipe is over about 100 feet long, or the lift is more than 10 feet a foot valve is desirable enabling the pump to get water more quickly. This may however give some trouble by collecting refuse and should be located where it is accessible.

Vacuum

A vacuum chamber is always desirable and is necessary on suction lines of over about 50 feet, and when the suction lift is over about 10 feet. The chamber should located close to the pump where it will best absorb the shock when the valves close.

Discharge

The discharge pipe line should have a gate valve near the pump to shut off water Pipe from the pump when the pump is opened for inspection.

Air Chamber

An air chamber is regularly furnished. Where the pipe line is 2000 feet long or the pipe is small, a large additional air chamber may be needed. This can be made up out of pipe and fittings.

Relief Valves

In the case of a discharge pipe of over 2000 ft. or where there will be sudden changes in pressure (as when a railroad stand pipe is used) a relief valve will prevent damage. A relief valve on any power pump will prevent damage from accidental closure of the discharge line.

Drains

Whenever the pump stands idle exposed to freezing temperature, the water must be drained out of the cylinder, the chamber above the discharge valve, and the

Water Valves

The valves are of rubber and the seats are of brass. Sometimes, after the pump has been idle the valves may stick to their seats and may then have to be loosened.

Handholes are provided to give access to the valves.

Packing

The pump is regularly packed for cold water, with square flax packing both in the piston and in the piston rod stuffing box. This flax packing does not require

any allowance for expansion.

Hot Water

If hot water is to be pumped the valves should be of hard rubber in place of the standard medium grade. The packing in the piston should be square canvas packing instead of flax. In putting in the square canvas packing allowance must be made for the packing to swell about 1/4 to 3/8" in circumference at the joint between the ends of packing rings. For the piston rod use Garlocks or other packing specially made for hot water use.

Pumping Oil

When the pumper is to be used for pumping oil, the valves are of brass, the gaskets of heavy paper, and the regular flax packing is used on the piston and in the piston rod stuffing box.

Lubrication

The cross head and pins have sight feed oil cups. The clutch pinion has two spring top oilers which should be filled with oil from a hand oil can occasionally. The outer cone of the clutch has two oil holes. A little oil should be applied from an oil can occasionally. When shutting down the punper for a considerable period, some oil should be put on the clutch cone to prevent rusting. The several working joints of the clutch should be oiled by hand occasionally. The gear should be lubricated by the application of heavy grease.

The clutch should be so adjusted by means of the adjusting nuts (45P and 46P) that it can be readily thrown in by hand but tight enough so clutch will not slip.

If slipping occurs wear will be rapid. Operation

Before throwing in the pump clutch, be sure that the engine is running properly and that the gate valve in the discharge line is open, then gradually apply the load with the clutch lever. Before shutting the outfit down, throw the load off by releasing clutch.

Repair Parts List—Type "Y" Horiz'l Oil Engine Combined Pumpers 2498

REPAIR PARTS LIST

Fairbanks-Morse Type "Y" Horizontal Oil Engine Combined Pumpers

When ordering parts, always give the size or horsepower, type and shop number of the engine. The number is very important. It is stamped on the top of the cylinder and cylinder head flanges. Do not fail to give it. Parts may be ordered in groups, or individually, except where noted.

A GROUP NUMBER printed in HEAVY TYPE, followed by the letter "C", such as "15P-C Piston," covers all items in that paragraph down to the first horizontal line.

An ordinary repair number printed in light type (such as "15P"), covers that part only, including any parts which are "always fitted" to it. For example: In Group 15P-C, No. 16P, 17P or 18P, covers one part only, but "15P" covers the part No. 3 and all parts "always

A group may be ordered, less certain specified parts. For example: 15P-C, less Nos.

18P and 17P.

Any part without a repair number is listed directly after the numbered part with which

Note that the pumper parts as here listed have repair numbers followed by the letter "P." and these numbers should not be confused with repair numbers for engine parts, as shown in the engine instruction book, which do not have the letter "P" attached.

	The state of the s		
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included in Group No.
1P	1P-C Lower Base Lower base, always fitted with bearing studs, bearing dowels, engine frame studs, waterbox studs, bearing caps (2P), bearing shims (79P) and bearing stud nuts.	1	
	Bearing cap grease cups and bearing shells (91P).		
	Lower base bearing studs	8 16	
	Lower base bearing stud nuts. Lower base water box studs.	4	
	Towar base water box stud nuts	4 2	
	Lower base bearing shell dowels Lower base engine frame studs	4	
	Lower base engine frame stud nuts	4	
OD	Bearing caps, always fitted with bearing shell dowel	2	1P-C
2P	Rearing can shell dowels	2 2	1P-C
3P	Bearing cap grease cups.		-11-0
4P	Water box, always fitted with engine base stud, head studs bonnet studs, suction and blind flange studs, hand hole plate studs, stuffing box studs, removable cylinder studs priming plugs and valve seats (19PS and 19PD).		
	Drain plugs (93P), valves (21PS-C and 21PD-C), stuffing box (13P-C), stuffing box gasket (115P), stuffing box stud nuts head (7P-C), head gasket (116P), head stud nuts, hand hole plates (9P), hand hole plate gaskets (117P), hand hole plate stud nuts, bonnet (5P-C), bonnet gasket (118P) bonnet stud nuts, air chamber (6P-C), air chamber gasket	i	
)	(120P), air chamber stud nuts, suction flange (11P), suction flange gasket (119P), suction flange stud nuts, blind flange (12P), blind flange gasket (119P), blind flange stud nuts valves (21PS and 21PD), piston rod (23P-C), cross head (26P-C), cross head pin (29P-C), cross head shoe and cross head oiler (38P), cross head oiler nipple and elbow, enging base stud nut, removable cylinder and piston (8P-C), removable cylinder stud nuts and removable cylinder stud jam-nuts.	d s e e	

Before ordering parts, read the instructions above.

4 Repair Parts List—Type''Y''Horiz'l Oil Engine Combined Pumpers


Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included In Group No.
	Waterbox engine lower base stud Waterbox engine lower base stud nut Waterbox bonnet studs	$1 \\ 16, 20$	
	Waterbox bonnet stud nuts	or 30 16, 20 or 30	
	Waterbox suction flange studs. Waterbox suction flange stud nuts. Waterbox blind flange studs.	6 or 8	
	Waterbox blind flange stud nuts	6 or 8 6 or 8	
	Waterbox hand hole plate studs. Waterbox hand hole plate stud nuts. Waterbox stuffing box studs.	8 8	
	Waterbox stuffing box stud nuts	3 6 or 8	
	Waterbox removable cylinder stud nuts	6 or 8 6 or 8	
	Waterbox head studs Waterbox head stud nuts Waterbox priming plugs	12or14 12or14 2	
5P	5P-C Water Box Bonnet. Waterbox bonnet, always fitted with air chamber studs, hand hole plate studs and discharge flange studs.	1	4P-C
	Discharge flange (10P), discharge flange gasket (121P), discharge flange stud nut, hand hole plates (9P and 9PA), hand hole plate plug, hand hole plate gaskets (117P) and hand hole plate nuts.		
	Waterbox bonnet air chamber studs. Waterbox bonnet air chamber stud nuts. Waterbox bonnet hand hole plate studs. Waterbox bonnet hand hole plate stud nuts. Waterbox bonnet discharge flange studs. Waterbox bonnet discharge flange stud nuts.	4 or 6 4 or 6 8 8 6 6	
.6P	6P-C Air Chamber. Air chamber, always fitted with pipe plug (25HP standard and 10, 15 and 20 HP large waterbox also fitted with eye plug).	1 1	4P-C
	Air chamber name plate (82P) with screws and washers. 7P-C Water Box Head		
7P.	Waterbox head plate showing diameter of pump cylinder (89P) with screws and washers.	1	4P-C
8P	8P-C Removable Cylinder with Piston Removable cylinder (always give diameter and state whether	1	
	Piston 15P-C.	.1	
	Hand hole plates	3	4P-C
9PA	Hand hole plate with pipe plug. Hand hole plate pipe plug.	1	& 5P-C 5P-C
10P	Discharge flange. Suction flange.	1	

Before ordering parts, read the instructions on page 8.

Repair Parts List—Type"Y"Horiz'l Oil Engine Combined Pumpers 5

Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included in Group No.
13P	13P-C Stuffing Box	1	4P-C
	Stuffing box gland (14P), gland nut and packing (122P).	0	
	Stuffing box gland studsStuffing box gland stud nuts	$\begin{bmatrix} 2 \\ 2 \end{bmatrix}$	
14P	Stuffing box gland (state whether plain or brass bushed)	1	4P-C
15P	15P-C Piston (always give diameter and state whether iron or brass). Piston, always fitted with (except 7 and 7½ diam.) follower studs.	1	4P-C
	Piston follower (16P), piston ring (17P), packing (18P), follower stud nuts and follower stud jam nuts.		
	Piston follower studs	6 6	
16P 17P 18P 19PS 19PD 20PS 20PD	Piston follower (always give diameter and state whether of iron or brass)	8 or 12 8 or 12	ZIPS-
21PS	21PS-C Suction Valves	8 or 12 8 or 12	4P-C
21PD	21PD-C Discharge Valves Discharge valve rubbers Valve plates (74PD), springs (22PD) and stems (20PD)	8 or 12 8 or 12	4P-C
22PS 22PD	Suction valve springs. Discharge valve springs.	8 or 12 8 or 12	21PS- 21PD-
23P	Piston rod. Piston rod piston nut (24P), piston lock nut (25P) and cross-	1	4P-C
24P 25P	head check nut (28P). Piston rod piston nut	1 1	23P-0 23P-0
26P	26P-C Cross Head	1 1	
	Cross head shoe studs. Cross head shoe stud nuts. Cross head shoe stud jam nut.	2 2 2	
27P 28P	Cross head shoes	1	26P-0 23P-0
	29P-C Cross Head Pin Cross head pin	1	

Before ordering parts, read the instructions on page 3.



8 Repair Parts List—Type"Y"Horiz'l Oil Engine Combined Pumpers

*			
Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included In Group No.
30P	30P-C Connecting Rod	1	
	Connecting rod crosshead pin wedge set screw	1	
31P 32P 33P 34P 35P	Connecting rod crosshead end brass, long, always fitted with connecting rod crosshead end brass, short (32P)	1 1 1 1	
36P	36P-C Crank Pin Crank pin. Crank pin nut (102P) and bushing (37P)	1 1	
	Crank pin nut	1	
37P 38P 38P 38P	Crank pin bushing, always fitted with dowel. Crank pin bushing dowel. Connecting rod oiler. Crosshead shoe oiler. Crosshead pin oiler. Crosshead pin oiler nipple. Crosshead pin oiler elbow.	1 1 1 1 1 1 1	36P-C
39P	Gear Gear shaft (40P), gear shaft key, gear shaft end plate (41P), end plate stud and nut, and end plate dowel.	1	
40P 41P	Gear shaft. Gear shaft key. Gear shaft end plate with dowel. Gear shaft end plate dowel. Gear shaft end plate stud. Gear shaft end plate stud nut.	1 1 1 1 1 1	39P-C 39P-C 39P-C 39P-C 39P-C 39P-C
42P	42P-C Pinion Cone. Pinion cone, always fitted with bushing (103P) and screw dowels; (on 20 and 25 H. P. engines, pinion and cone are cast one piece; on 10 and 15 H. P. engines, pinion (104P) is separate and keyed into cone and the cone is always furnished with pinion). Oil hole cover (105P)	1 1 1 or 2	
43P	Gear guard Gear guard upper brace No. 1 (106P), upper brace No. 2 (107P), lower brace (72P) and rivets.	1 1	
	Gear guard brace rivets	4 2	

Before ordering parts, read the instructions on page 3.

Repair Parts List—Type"Y"Horiz'l Oil Engine Combined Pumpers 9 2498

)	Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included in Group No.
	44P	44P-C Friction Clutch Friction clutch inner cone adjusting nut (45P), lock nut (46P). toggle levers (50P), toggle lever pins (52P), toggle lever links (51P), toggle lever link pins (53P), shifter collar (69P). shifter collar yoke (67P) and friction cone yoke (68P)	1 1	
	45P 46P 50P 51P 52P 53P 54P 55P 56P	Friction clutch cone adjusting nut Friction clutch cone adjusting lock nut Friction clutch toggle levers Friction clutch toggle lever links Friction clutch toggle lever pins with cotters Friction clutch toggle lever pin cotters Friction clutch toggle lever link pin with cotters Friction clutch toggle lever link pin with cotters Friction clutch toggle lever link pin cotters Engine crankshaft extension stud Engine crankshaft cone key Engine crankshaft cone key Engine crankshaft cone key dowel	1 1 2 4 2 4 8 1 1 1 2	44P-C 44P-C 44P-C 44P-C 44P-C 44P-C 57P-C 57P-C
	57P	57P-C Engine Crankshaft	1	
,	58P 63P 64P 65P 65PA 66P 67P 68P	stop rings (165) and air stop ring springs (280) Friction clutch adjusting nut wrench. Friction clutch shifter lever lock. Friction clutch shifter lever fulcrum pin with cotter. Friction clutch shifter bracket, upper. Friction clutch shifter bracket, lower. Friction clutch shifter bracket, lower. Friction clutch guard. Friction clutch shifter collar yoke, always two halves furnished with screws, nuts and cotters. Friction clutch shifter collar yoke screws. Friction clutch shifter collar yoke screw nuts. Friction clutch shifter collar yoke cotters. Friction clutch yoke, always two halves furnished with screws and nuts. Friction clutch yoke screws. Friction clutch yoke screws. Friction clutch yoke screws. Friction clutch shifter collar. Friction clutch shifter collar. Friction clutch shifter lever, short.	1 1 1 1 1 1 1 2 2 2 2 2 1 1 1	71P-C 71P-C 71P-C 71P-C 71P-C 71P-C
	71P	71P-C Friction Clutch Shifter Lever. Friction clutch shifter lever, long. Friction clutch shifter lever (70P), screws and nuts, shifter locks (63P), shifter lock screw, shifter lever brackets (65P and 65PA), bracket cap serews, shifter lever fulcrum pin (64P), shifter lever spreader (78P), shifter lever spreader screws with nuts, and clutch guard (66P).	1 1	
)	Posovo	Friction clutch shifter lever screw. Friction clutch shifter lever screw nut. Friction clutch shifter lock screw. Friction clutch bracket screw. Friction clutch shifter spreader screw. Friction clutch shifter spreader screw nuts.	2 2 1 2 2 2 2	

Before ordering parts, read instructions on page 3.

10 Repair Parts List—Type"Y"Horiz'l Oil Engine Combined Pumpers

Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included In Group No.
72P	Gear guard lower brace	2	43P-C
74PS 74PD	Gear guard lower brace screws. Suction valve plates. Discharge valve plates. Friction clutch lever spreader.	8 or 12 8 or 12	21PS-C 21PD-C 71P-C
78P 79P 82P	Lower base bearing cap shims. Air chamber name plate. Air chamber name plate screws.	4	1P-C 4P-C
85P 86P	Air chamber name plate screw washers Valve stem wrench Piston not socket wrench	1 1	
87P 88P 89P	Removable cylinder nut socket wrench. Piston eye bolt. Water boxhead pump diameter plate.	1 1	7P-C
90P	Water boxhead pump diameter plate screws. Water boxhead pump diameter plate washers. Connecting rod bolts with nuts, jam nuts and cotters. Connecting rod bolt nuts.	$\begin{bmatrix} 2\\2 \end{bmatrix}$	30P-C
91P	Connecting rod bolt jam nuts Connecting rod bolt cotters Lower base bearing shells (furnished in pairs only)	$\begin{bmatrix} 2 \\ 2 \end{bmatrix}$	1P-C
92P 93P 94P	Valve assembling clips. Water box drain plugs. Engine crank shaft distance ring.	3	4P-C 57P-C
	95P-C Exhaust Pot	1	
95P	Exhaust pot, always fitted with pipe plug	1	
	scew nut, inlet flange (229), inlet flange gasket (415), inlet flange screws.		
96P 97P	Exhaust pot hand hole plate	1 1 1	95P-C 95P-C
98P	Exhaust pot hand hole plate gasket. Exhaust pot jack screw Exhaust pot jack screw nut.	1	95P-C
99P 100P 101P	Exhaust pot outlet nipple	1 1 1	29P-C
102P 103P	Crank pin nut. Pinion cone bushing. Pinion cone bushing screw dowels. Pinion (one 10 and 15 H. P. engines only), always furnished with	2	36P-C 42P-C
	42P	1	42P-C
105P 106P	Pinion cone oil hole cover	1 or 2	42P-C 43P-C
107P 108P	Gear guard upper brace No. 2 Gear guard upper brace rivets. Governor spring adjusting screw.	1 2	43P-C
109P	Governor spring, always fitted with one spring nut (52) and eye bolt (51) for 10 and 15 H. P. engines, and with two spring nuts for 20 and 25 H. P. engines		

Before ordering parts, read instructions on page 3.

Repair Parts List—Type"Y"Horiz'l Oil Engine Combined Pumpers $\frac{11}{2498}$

Repair Nos. Arranged Numerically	The Group Number in Heavy Type when shown at the Head of a Group of Parts, includes all Items mentioned in that Group.	Number Pieces Used	Included In Group No.
115P 116P 117P 118P 119P 119P 120P 121P 122P 18P	Gaskets and Packings Water box stuffing box gasket. Water box head gasket. Water box hand hole plate gasket. Water box bonnet gasket. Water box suction flange gasket. Water box blind flange gasket. Water box bonnet air chamber gasket. Water box bonnet discharge flange gasket. Stuffing box packing (always give material) Piston packing (always give material) Cooling water piping from engine to water box bonnet, including stop cock.	1 4 1 1 1 1 1 1 set 1 set	4P-C 4P-C 4P-C 4P-C 4P-C 4P-C 5P-C 13P-C 15P-C
	Tools		
58P 85P 86P 87P 88P 92P	Friction clutch adjusting nut wrench. Valve stem wrench. Piston nut socket wrench. Removable cylinder with socket wrench. Piston eye bolt. Valve assembling clips.	1 1 1 1	

Before ordering parts, read the instructions on page 3.


TROUBLE CHART

The state of the s		
TROUBLE	POSSIBLE CAUSE	REMEDY
	Instructions to start engine not followed.	Read and follow carefully.
	No gasoline in tank.	Fill tank.
	Battery circuit broken.	Examine all battery and electrical connections carefully and see that timer makes contact with pin on gear at proper time. Close switch and listen for buzz of vibrator.
1000	Vibrator points dirty.	Separate contact points and blow between them or clean with fine emery cloth or a fine file.
Engine does not start.	Foul spark plug.	Remove center part of plug and clean carefully. Replace and test for spark. (See page 5.) See that points are $\frac{1}{32}$ in apart.
	Batteries run down.	Replace with new battery cells, connecting up same as before.
	Cold weather, batteries dead.	Warm batteries. Provide shelter for pumper.
	Water in Gasoline.	Remove suction elbow with gasoline tank attached. Empty into glass dish and see if water settles to bottom. If so, fill tank with fresh gasoline. Straining gasoline through chamois skin will remove water.
一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一 一	Dirt under check valve in gasoline tank.	Clean check valve. (See page 3.)
Engine misses or	Weak batteries.	Test batteries and spark plug. (See pages 4 and 10.) Renew if necessary.
started.	Loose electrical connections.	Examine all electrical connections and tighten if necessary. Cables may be broken inside insulation. Test each.
Lack of compres-	Dirt or carbon under valves.	Remove valves, clean or regrind if necessary. (See page 3.)
sion.	Valve stems may stick.	Remove valves, clean stems, oil and replace.
	Too much clearance between exhaust valve stem and push block cap screw head, caused by wear.	Remove cap screw and shim up under cap screw head with thin tin washers to make valve stem clearance 1/32" to 1/64" when valve is closed.
Uses too much fuel.	Exhaust pipe line too small when run outside building or too many bends.	Increase pipe to 14 inch from engine out. (See page 3.)
	Silencer may be plugged with carbon.	Take silencer apart and clean.
Engine races or runs away.	Relation of governing parts may be incorrect—caused by wear or injury.	See paragraph on governing, and set detent parts according to this.

Instructions No. 2301E

FOR SETTING UP AND OPERATING

Fairbanks-Morse No. 2 Eclipse Pumper



FAIRBANKS, MORSE & CO.

(INCORPORATED)

(Copyright, 1913, by Fairbanks, Morse & Co.)

The No. 2 Eclipse Pumper




Fig. 961M

INSTRUCTIONS Co. 2301E For Setting Up and Operating Fairbanks-Morse No. 2 Eclipse Pumper

These Pumpers are Regularly Fitted with:

1. Evaporator tank, cast with cylinder.

Jack frame, carrying pumper gear and crank.

3. Suction fuel feed, with fuel tank attached to inlet elbow.

Closed base, with splash lubrication.

5. Jump spark ignition.

Read all tags attached to engine, and change no adjustments of moving parts until instructions are carefully read.

Locating Pumper.

In locating pumper on well curb, it is well to place it in such a position that the

pumper gear will clear a pail hanging on the spout of the pump.

If an arrangement is desired which will enable the pump to be operated by hand, If Pump is to place pump handle opposite to engine. After engine has been set around so that gear be Operated by Hand will not strike a pail hanging on the pump spout, the pump handle will be in such a position that it will not strike the spout.




Fig. P7-Fly-wheel removed to show Governor and Timer

To attach pumper to pump, clamp the jack frame to the pump standard, being careful to set the pumper flat on the well platform, and then fasten down with bolts or lag screws to the platform. Put cross-head on the pump rod and turn the flywheel of the engine until crank pins on gear and crank are at their lowest position. Now put pump pitman rods on the pins and attach cross-head on pump rod at the nearest holes, being careful to have pump rod about ½ inch to 1 inch from its lowest point of Lowest Point stroke. After attaching pitmans, turn the engine slowly to see that there is sufficient of Stroke clearance at both ends of the stroke. To get this proper clearance it may be necessary, in some cases, to place a board under the pumper to raise it. If cross-head is to be attached to wood pump pole, remove the clamp piece used with standard well pump and clamp the cross-head directly to wood pump pole.

The pumper is furnished with 5, $7\frac{1}{2}$ and 10-inch strokes.

Strokes

Instructions—Fairbanks-Morse No. 2 Eclipse Pumper 2301E

Cleaning Check Valve

Unusually small pump standards may require fill-up pieces or special cap to allow Small Pump Standards pumper to be attached to standard.

> SUCTION ELBOW FILLER CAP STARTING DAMPER PISTON RINGS GASOLINE TANK FUEL TUBE FYHALIST SILENCES EXHAUST VALVE --LOWER BASE Cut shows No.1 Eclipse Pumper base No.2 Eclipse Pumper base is cast with foot (See front page cut)

Evaporator.

In operating the engine the water tank should be filled up to within 3 inch from the top. The water level must never be allowed to fall below the level of the cylinder top, which can be seen inside.

Boiling Water

It is expected that water will boil under heavy load, but the engine will work properly when the water is boiling. This temperature is 212 degrees F., while the danger point, where the lubricating oil will burn and cause harm, is about 420

Extension Water Tank

Water Level

We will furnish at a small extra cost an extension hopper water tank which can be easily attached by any one on the top of regular jacket tank. This hopper allows

a longer run without replenishing cooling water.

Drain Extension Hopper in Weather Non-freezing Solution

Where the extension hopper is used, it is advisable to drain the jacket and hopper in freezing weather when the engine is not in use, or a mixture of calcium chloride and water may be used and left in the jackets. This mixture will not harm the jacket, as it will not freeze solid. A proportion of three pounds of calcium chloride to a gallon of water will not freeze hard in zero weather.

Exhaust Silencer.

Exhaust Piped

Engines are shipped with exhaust silencer attached to exhaust outlet.

In case it is desired to locate the silencer outside of the building, use 1-inch pipe, with a "T" on the bottom of the upright portion, provided with a drain in the bottom of the "T," as water will collect in long pipes. Use as few bends as possible.

If extension pipe is longer than 8 feet, it is advisable to increase to 11-inch size, decreasing at outlet to 1-inch for silencer.

Fuel Tank.

Filling Tank

Each engine is regularly fitted with a fuel tank, attached to the inlet or suction elbow. This tank is provided with a screw cap filler. The fuel is drawn from the tank by the suction of the engine and held by a check valve placed in the fuel pipe Check Valve in the tank.

If dirt from the fuel gets under this valve, it can usually be dislodged by disconnecting the tank and shaking it. Tank can be removed by unscrewing the two nuts from the study which hold the elbow in place. The tank, with elbow, can then be Tank lifted out. Care must be taken when replacing elbow to have it come against the packing gasket squarely to avoid leaks at one side.

Always keep filler cap on tank and supply can to prevent entrance of water.

Exhaust Valve.

This valve is similar to the inlet valve, with the stem extending downward through its guide and a spring on this stem to hold it to its seat. The spring nut or Valve washer, secured by a pin through the stem, holds this spring. This valve can be removed by first taking out the inlet elbow, as described above, then removing springs as follows: Raise the spring washer which holds the exhaust valve spring clear from its pin. After removing the pin, the spring washer will drop down the stem and the valve can be taken out.

Loss of compression may be due to leaky valves, caused by small particles of Lost carbon or other substances. To remedy this, the valves should be cleaned and Compression reground. The valves may be reground with fine emery and oil by revolving the valve on its seat, rotating it with a screw driver a few times in alternate directions Regrinding and lifting it clear from its seat frequently to allow the cutting emery to distribute Valve evenly. Carefully clean both valve and seat with gasoline before replacing.

See that the timer blade is so placed that the spark will take place when the Timing "spark" mark on the engine flywheel is straight up. Keep timer free from dirt.

Battery and Coil Box.

This box, attached by a bracket to the engine sub-base, carries the spark coil wiring and four 2½x6-inch dry battery cells, and has a switch placed on the bottom of the box. Diagram These batteries are sent out from the factory properly connected, with a diagram to show the connections to the engines, as follows: Each contact on the engine has

Removing

Replacing

TO GROUND ON ENGINE TAG No.4 TO TIME

TO SPARK PLUG-TAG NO 3

a tag attached to show the wire connections to correspond with this diagram. Connect the large cable to the spark plug. The longer of the two small cables is con- Test Battery nected from the switch to the timer and the shorter one from the coil to the ground connection on the engine base. Close the switch and turn the engine slowly until "spark" mark on the flywheel is straight up and the timer in contact. The vibrator on the coil should then buzz. Open switch immediately, as the continuous contact Open Switch will exhaust batteries in a short time. The battery cells are connected in series. See that none of the wires are broken, and that all binding nuts are tight.

2301**E**

Instructions—Fairbanks-Morse No. 2 Eclipse Pumper

Renewing

To renew battery, order new 2½x6-inch dry cells from the nearest supply and connect up the same as this diagram. Keep the outer binding posts of the bat teries from touching the other cells. The batteries we furnish will be of full strength, properly connected up, and in working order when shipped. With proper care they should be sufficient to ignite the engine for six months or more, but if improperly Proper Care connected may be ruined in a short time. We do not replace batteries without charge.

Owner must see that it has proper attention. There can be furnished on special orders a high tension magneto with proper High Tension bracket, gears and bolts which can be attached to engine and do away with the use Magneto of batteries. Engine can be started and run with the magneto.

Spark Plug.

Testing

To test spark plug, unscrew it complete from the cylinder and connect the large cable to it. Lay it on the top of the cylinder, being sure that it is in metallic contact, then turn the engine over to the "spark" point. Close the switch for an instant, and if the connections and plug are in proper condition a spark will be seen between the two sparking points of the plug. This plug can be easily cleaned by unscrewing (Continued on page 10)

REPAIR PARTS LIST for Fairbanks-Morse No. 2 Eclipse Pumper

When ordering parts always give the size, type and **Shop Number** of the engine. The Number is very important. It is stamped on the top of the cylinder. Do not fail to give it.

Parts may be ordered individually or in groups. A Group Number printed in heavy type, followed by the letter "c", such as "5-C"

covers all items in that paragraph down to the first horizontal line, thus-An ordinary repair number printed in light type (such as "5"), covers that one part only. A group may be ordered **less** certain specified parts, for example "1D-C less 10-C and 28-C."


Any part without a repair number is listed directly after the numbered part with which it is used.

				/
Repair Nos. Arranged Numerically	The	Group Number in Heavy Type, when shown at the head of a Group of parts, includes all items in that Group.	Included in Group No.	No. Used.
	1 171 146 146	Cylinder and Upper Base (Babbitted) fitted with Jack to Engine Base Studs and Nuts (four) Drain Plug in Cylinder Jacket. Overflow Plug in Cylinder Jacket.	1A-C	1
1A-C	1 171 34 341 167 10C	1A-C. Cylinder and Upper Base, with Exhaust Valve Cylinder and Upper Base (Babbitted) fitted with 146 (2) Jack to Engine Base Studs and Nuts (four). Cam Shaft Bearing Opposite Governor Side. Cam Shaft Bearing Set Screw. Detent Spring Eye-Bolt. Exhaust Valve (complete).	1D-C	
1B-C	1 171 34 341 167 28C 30	1B-C. Cylinder and Upper Base with Cam Shaft Gear and Governor. Cylinder and Upper Base (Babbitted), fitted with 146 (2). Jack to Engine Base Studs and Nuts (four). Cam Shaft Bearing Opposite Governor Side. Cam Shaft Bearing Set Screw. Detent Spring Eye-Bolt. Cam Shaft Gear and Governor (complete). Cam Shaft.	1D-C	
1C-C	1 171 34 341 167 2 64	10-C. Cylinder and Upper Base, Fitted with Lower Base		
1D-C	1 171 34 341 167 10C 36C 28C 30 39 89	1D-C. Cylinder and Upper Base, Fitted with Exhaust Valve, Exhaust Block Guide, Cam Shaft Bearing, Cam Shaft, Gear, Governor and Detent. Cylinder and Upper Base (Babbitted), fitted with 38 Detent Fulcrum Pin, Washers, Cotters and 146 (2) Plugs. Jack to Engine Base Studs and Nuts (four). Cam Shaft Bearing Set Screw. Cam Shaft Bearing Opposite Governor Side. Detent Spring Eye-Bolt. Exhaust Valve (complete). Exhaust Block (complete). Cam Shaft Gear and Governor (complete). Cam Shaft. Detent. Detent Spring.		

Instructions—Fairbanks-Morse	No. 2 Eclipse Pumper
------------------------------	----------------------

2301E

epair Nos. 1			Included	
Arranged Jumerically	The C	Group Number in Heavy Type, when shown at the head of a Group of parts, includes all items in that Group.	in Group No.	No. Used
2 3	3	Lower Base (Babbitted), fitted with 77 Ground Contact Stud and Nut- Gear Guard, for Gear on Jack Shaft and Pinion on Cam Shaft	1C-C	1
4C 4	4 189 170 173	Jack Frame Jack Frame Jack Frame Brace Jack Frame Brace to Engine Foot Cap Screw Jack Frame Brace to Jack Machine Bolt	4A-C	1
4A-C	4C 107 108 109 45C 44C 46 118C	4A-C. Jack Complete Jack Frame Jack Shaft Bearing ½-inch Grease Cup Jack Frame Clamp Caps (two) Jack Frame Clamp Cap Bolts (four) Gear with Jack Shaft and Crank Pin. Crank Disc with Crank Pin. Pump Pitman (two) Pump Cross Head (complete)		
5C 5	5 79	Crank Disc with Crank Pin. Pump Pitman (two). Pump Cross Head (complete). Piston. Piston Pin Set Screw. Piston Pin Set Screw Cotter.		3
6 7	6 7	Piston Rings (Three) Piston Pin.		1
8C 8	8 101 24 19	8C. Inlet or Suction Elbow. Inlet or Suction Elbow, always fitted with 23 Gasoline Nozzle and Valve Seat, Needle Valve Index and 98-C Starting Damper. Gasoline Check Valve. Tube Tube Fitting.	8A-C	1
8A-C	8C 9C	8A-C. Inlet or Suction Elbow, Fitted with Inlet Valve Inlet or Suction Elbow. Inlet Valve (complete).	8B-C	1
8B-C	8A-C 96 97	8B-C. Inlet or Suction Elbow, fitted with Inlet Valve and Gasoline Needle Valve. Inlet or Suction Elbow. Gasoline Needle Valve and Handle. Gasoline Needle Valve Spring.		1
9C 9	9	9C. Inlet Valve. Inlet Valve Washer Inlet Valve Washer Cotter Inlet Valve Spring		1
10C 10 11	10 11	Exhaust Valve Exhaust Valve Exhaust Valve Exhaust Valve Spring Washer Exhaust Valve Spring Washer Pin Exhaust Valve Spring	·	1 1 1
13 14 15 17	13 14 15 17	Flywheel, fitted with 81 Key. Starter Crank Gasoline Tank, fitted with 103 Set Screw Cap. Pulley, with Machine Bolts (three).		2 1 1 1
18C 18	18 22 162 163 20 80 144	Connecting Rod. Connecting Rod Cap. Connecting Rod Cap. Connecting Rod Crank Babbitt Liner (Upper). Connecting Rod Crank Babbitt Liner (Lower). Connecting Rod Piston Pin Bushing. Connecting Rod Studs, with Nuts, Half Nuts and Cotters. Connecting Rod Shims (Crank End).		
19C	19 101	Check Valve Seat, with Screen. Check Valve.		,1
	19C 24	19C-C. Check Valve, With Tube. Check Valve Seat, with Screen. Check Valve Tube.		1
20 21 22 24 25	20 21 22 24 25	Connecting Rod Piston Pin Bushing. Battery Box Bracket. Connecting Rod Cap. Tube. Crank Shaft.	18-C 48-C 18-C 8C-19C-C	1 1 1 1 1 1
26C 26 27	26 27 104 105	Exhaust Silencer Casting Exhaust Silencer Plate Exhaust Silencer to Plate Stove Bolts (two) Exhaust Silencer Nipple		1 1 1
28C 28	28 164 165 33 85 86 32 87	28C. Cam Shaft Gear and Governor. Cam Shaft Gear, fitted with 145 Timer Pin. Timer Roller. Timer Roller Pin. Governor Weight Fulcrum Pin, with Washer and Cotter. Governor Spring Eye-Bolt. Key. Governor Weight. Governor Spring Eye-Bolt with Nuts.		




8 2301 E		Instructions—Fairbanks-Morse No. 2 Ecli	pse Pur	mper
Repair Nos. Arranged Numerically	The C	Group Number in Heavy Type, when shown at the head of a Group of parts, includes all items in that Group.	Included in Group No.	No. Used.
29 30 32 33 34 36 37	29 30 32 33 •34	Pinion on Crank Shaft, with 88 Key Cam Shaft Governor Weight Governor Weight Fulcrum Pin, with Washer and Cotter Cam Shaft Bearing Opposite Governor Side See 36A-C.	1B-C, 1D-C 28C 1A-C, 1B-C 1C-C	1 1 1 1
36A-C 36A 37A	36A 37A 169 90 134A 36 37 134 36A-C	36A-C. Exhaust Valve Push Block Exhaust Valve Push Block Exhaust Valve Push Block Washer Exhaust Valve Push Block Washer Cap Exhaust Valve Push Block Washer Cap Screws Exhaust Valve Push Block Guide Bushing Exhaust Valve Push Block, used on Engines before 14400 Exhaust Valve Push Block Washer, used on Engines before 14400 Exhaust Valve Push Block Guide Bushing, used on Engines before 14400 To be used for repairs in place of 36, 37, 90 and 134		1
38 39	38 39	Detent Fulcrum Pin with Washers and Cotters. Detent with 92 Timer Insulation	} 1D-C	1 1
41C 41	41 93 91	41C. Timer Blade. Timer Blade. Brass Machine Screw for Attaching to Detent. Binding Post Nuts.		1
42	42	Cam Shaft Pinion, with 111 Key.		1
43C 43	43 114C	43C. Gear, With Crank Pin. Gear on Jack Shaft, with 112 Key. Crank Pin (complete).	} 45C	1
44C 44	44 114C	44C. Crank Disc, With Crank Pin Crank Disc, with 112 Key Crank Pin (complete)	4A-C	1
44A-C 44	44 114C 45	44A-C. Crank Disc, With Jack Shaft and Crank Pin. Crank Disc, with 112 Key Crank Pin (complete). Jack Shaft		1
45C 45	45 114C 43	45C. Gear, With Jack Shaft and Crank Pin	4A-C	1 1
46	46	Pump Pitman.	4A-C	2
48 A-C 48 49 55 56 57 58 64 72 75 76 78 79 80 85	48 49 21 168 121 130 122 124 125 147 126 138 55 56 75 75 86 64 72 75 76 78 79 80 85	48A-C. Battery Box, with Coil, Dry Battery, Switch, Wire Connection, Bracket and Cover Battery Box, with Coil Holder. Battery Box Cover Battery Box Bracket Bracket to Engine Base Machine Bolts (two) Battery Box Linning. Battery Box Linning. Single Unit Spark Coil. Single Unit Spark Coil. Single Throw Switch, Wood Screw (two). 23 x 6 inch Dry Batteries (four). Dry Battery Loop Nuts (eight). Duplex Battery Connectors (four). Packing Block for Dry Batteries. High Tension Cable from Coil to Spark Plug. Low Tension Cable from Switch to Timer on engine. Low Tension Cable from Batteries to Switch. Liners between Cylinder and Lower Base (one set). Jack Shaft Frame Clamp Cap for Extra Small Pump Standard. Clamp Studs, with Nuts for Inlet Elbow (two). Cylinder to Lower Base Machine Bolts, with Lock Nuts, set of six. Drain Cock for Lower Base. Piston Pin Set Screw. Piston Pin Set Screw Cotter. Connecting Rod Cap Studs and Nuts, Half Nuts and Cotters. Governor Spring Eye-Bolt.	1C-C 5C 22C	1 1 1 1 1 1 1 1 1 1 2 6 1 1 1 1 2 1 1
86 87 89 90 91 92 93	86 87 89 90 91 92 93	Key Governor Spring Eye-Bolt with Nuts Detent Spring Exhaust Valve Push Block Washer Cap Screws Binding Post Nuts Insulation for Timer Brass Machine Screw for Attaching to Detent.	36A-C 41C	1 1 1 2 3 1
94 95 96 97	95 96 97	Exhaust Valve Spring. Inlet Valve Spring. Gasoline Needle Valve and Handle. Gasoline Needle Valve Spring.	10C	1 1 1 1
-	, 01			

Instructions—Fairbanks-Morse No. 2 Eclipse Pumper

9 2301E

Repair Nos. Arranged Numerically	The Group Number in Heavy Type, when shown at the head of a Group of parts, includes all items in that Group.	Included in Group No.	No. Used
98C 98	98 Starting Damper, with Handle and Cotter 457 Starting Handle Damper Spring.		
99 100 101 102 104 105 107 108 109 113	99	26C	1 2 1 1 2 1 1 2 2 1 1 2 2 1
114C 114	114C. Crank Pin (for either Gear or Crank Disc),		2 2
115 116 117	115 Crank Pin Half Nut. 116 Crank Pin Washer. 117 Crank Pin Cotter.		2 2 2 2 2 2
118C 118 119	118C Pump Cross Head (complete)		1
121 122 124	121 Battery Box to Bracket Carriage Bolts (two) 122 Single Unit Spark Coil 124 Single Throw Switch Single Throw Switch Wood Screw (two)	48A-C	2 1 1 2
123 125 126 127 128 129 130 131 131 133 142 143 144 145 146 147 160 161 162 163 164 165	123 Spark Plug 125 2	18C 1A-C 1A-C 48A-C 118C 18C 28C	1 4 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1
166C 166	166 Pump Rod Clamp Piece (Complete)		1
167 168 169 170 171 172 173 189 341 447 452 457	167 Detent Spring Eye-Bolt. 168 Bracket to Engine Base Machine Bolts (two). 169 Exhaust Push Block Washer Clip. 170 Jack Frame Brace to Engine Foot Cap Screw. 171 Jack to Engine Base Studs and Nuts (four). 172 Pump Cross Head Clamp Cap. 173 Jack Frame Brace to Jack Machine Bolt. 189 Jack Frame Brace to Jack Machine Bolt. 189 Jack Frame Brace. 180 Jack Frame Brace. 180 Jack Frame Brace. 181 Cam Shaft Bearing Set Screw. 181 Governor Spring. 182 Exhaust Block Spring. 183 Starting Handle Damper Spring.	1A-C 48A-C 26A-C 4C 1A-C 118C 4C 4C 1AC	1 2 1 1 4 1 - 1 1 1
	59		
	180C. Gear Driven High Tension Magneto Outfit. High Tension Magneto, with Cable. High Tension Magneto Bracket. High Tension Magneto Bracket to Engine Machine Bolts, with Lock Washers (two).		,
	High Tension Magneto to Bracket Cap Screws (two)		



the center part from the shell, which may be left in the cylinder, then wiping the soot or oil from the center porcelain insulation with a piece of cloth or paper. The gap Spark Cap between the sparking points on the plug should be a little less than 1/32 inch. If the center porcelain of the spark plug is coated with greasy burnt carbon, it indicates Too Much Oil that too much oil is being fed. If the right amount of fuel is fed, the plug should remain comparatively clean, but it should be examined occasionally.

Extra Plug

It is recommended that an extra plug be kept on hand.

Shut Off Oil

Engine is oiled by splash lubrication, the oil being fed through a sight feed oil cup attached to the cylinder. Oil should be carried in crank case to a level where it will begin to overflow when drain cock in lower base is opened. Oil cup should be set to feed about 3 to 5 drops per minute. In cold weather the oil is sluggish and will work much freer if 25 per cent of kerosene be added, but, in that case, feed eight drops per minute, using nothing but good mineral gas engine oil. If white smoke comes from the exhaust, it may indicate too high a level of oil in the base. The remedy is to reduce the feed somewhat. Be sure to shut off the oil cup when engine is stopped. If oil works out of the bearings and is thrown from the gears or flywheels, reduce

Oil Throwing feed of oil at oil cup and leave plug out of filling elbow on cylinder casting.

Attaching Engine

Fill Tanks and Oiler

Put Oil in Engine Base

Instructions for Running the Engine. Connect the engine as shown by Figs. P1 and P2. Unpack the battery box and bolt it to base under engine (holes drilled for this). See that movable parts about the governor are free from dirt and paint and work easily. Put glass oil cup in place on side opposite Jack. Screw spark plug into place in cylinder tight enough to avoid loss of compression. Connect wires from battery box as indicated by tags. Fill gasoline tank. Fill water jacket to within \(^3\)4 inch from top. Fill glass oil cup with gas engine oil, and put oil into base of engine up to the level of small drain cock near bottom of base opposite flywheel side. Now close switch under battery box and turn engine Test Ignition over slowly a few times, listening for the buzz of the vibrator in the battery box. Circuit If this is heard, the engine is ready to start.

To Start Engine.

Close battery switch. Open gasoline throttle to point "1." Set cylinder oil cup to feed about 3 to 5 drops per minute. Now close starting damper in suction elbow, turning damper handle down. Place starter crank on crank shaft end, turned down to smaller size for that purpose, with ratchet or tooth of crank against head of gib key in flywheel hub, and turn flywheel rapidly in direction indicated by arrow in cut on page 10 until an explosion occurs. The damper handle should then be Starting released and the throttle closed back about to point "2." Set this by trial to point Damper where engine runs best and shows no black smoke from the exhaust. When this Regular point is determined, the throttle should be set at this point for regular running.

To Stop Engine.

Close throttle and open switch. Be sure that switch is open when engine is standing idle, as battery may be run down in a few hours if switch is closed.

Speed of Engine.

The regular speed of the engine is 700 R. P. M., driving the pump gear 28 strokes Reducing per minute. If it is desired to run the engine at slower speed, the tension of the Speed governor spring must be reduced. This may be done by adjusting it at the eyebolt, to which one end of the governor spring is attached. Increasing tension of governor spring speeds up the engine.

Governor Parts.

Turn the engine over by hand thus causing the cam to push the exhaust block Governing up and open the exhaust valve.

While turning the engine over push the governor weight in the cam shaft gear out against its stop and this will force the detent tail out causing the detent blade to swing under the square plate washer attached to the upper end of the exhaust block.

With the proper relation of the detent, governor weight and detent washer plate, the detent will in the course of the turning over of the engine be pushed under the detent plate and remain there until the exhaust block and valve are lowered by the cam and will rest on this detent thus holding the valve open until the next revolution of the engine cam shaft.

If the detent swings in and out again without holding the block up it shows that either the detent plate is too high or that the tail of the detent is bent too far out. To remedy the first remove some of the tin washers under the plate and lower

same until the detent blade swings in with a clearance not to exceed 1/32 inch. To remedy the last bend the detent tail in slightly to give the above clearance

of blade with plate.

If the detent blade strikes the plate before the cam has raised the block and plate high enough the tail of the detent should be bent out slightly, but care should be taken to see that when this is done the clearance between the detent blade and the plate does not exceed the 1/32 inch noted above.

Gears.

If engine is taken apart, the cam gears must be correctly timed when replacing. Replacing There is a zero mark stamped on the outer end of one pinion tooth. This tooth must Cam Gears come between two teeth on the gear, both of which are stamped with a corresponding zero mark. If marks are not found, the gear should be set so that the exhaust valve is just closed when the key-way on the crank shaft is a little past its straight-up position, when the wheel is turned in the direction of the arrow. The closing point Closing Poin of the valve is felt by rotating it by means of the spring washer before it seats. When of Valve the valve is open it turns freely, but, at the closing point, it can scarcely be turned.

Cleaning Piston and Rings.

The piston may be removed as follows: Remove the suction elbow complete Removing in the manner already described. Remove the engine from the jack and turn it bottom upward, having first drained the water from the jacket and oil from the base. Now remove the six bolts holding the upper to the lower base, and lift off praining the lower base. Now remove the connecting rod bolts and lift out the crank shaft. The piston, with connecting rod, may now be drawn out. Clean the rings and piston with kerosene. To remove the piston pin, loosen the set screw (located in the boss on the inside of the piston), which holds the pin in place. The pin may now be driven out, using a wood stick as a punch, and striking it with a hammer. Oil the piston well and replace in reverse order.


Starting Engine


Close Startin Damper

> Starter Crank Release

Running

Removing Piston Pin






FOR THE CARE AND TIMING OF

SUMTER PLUGOSCILLATOR

USED IN CONNECTION WITH

FAIRBANKS-MORSE

10 AND 15 H. P. TYPE "Z" OIL ENGINES



TYPE "Z" OIL ENGINE FIG. 3095G

FAIRBANKS, MORSE & CO.

(INCORPORATED)



SUMTER-SPLITDORF SERVICE

The following Branches will render service on SUMTER or DIXIE MAGNETOS or ACCESSORIES

Address either the sumter Electrical Co., or Splitdorf Electrical Co. at any of the following locations:

Atlanta, Ga.-10 E. Harris St. Boston, Mass-1112 Boylston St. Chicago, Ill.—1466 Michigan Ave. Cincinnati, Ohio.—811 Race St. Dallas, Texas,-402 S. Ervay St. Detroit, Mich.-1295 Woodward Ave. Kansas City, Mo.-1827 Grand Ave. Los Angeles, Cal.—1215 So. Hope St. Minneapolis, Minn.—34 S. Eighth St. Newark, N. J.-280 Halsey St. Oakland, Cal.-3040 Broadway. New York.—3-5-7 W. Sixty-First St. Pittsburgh, Pa.-5943 Ellsworth Ave. Philadelphia, Pa.—210 No. Thirteenth St. San Francisco, Calif.—1022 Geary St. Seattle, Wash.-1628 Broadway. Toronto, Canada.-469 Yonge St. BARCELONA LONDON PARIS CHRISTIANA CAPE TOWN BUENOS AYRES MILAN MELBOURNE

SUMTER ELECTRICAL COMPANY

1466 Michigan Avenue

Chicago, Illinois

NEW YORK OFFICE: 3-5-7 W. 61st St.

SAN FRANCISCO OFFICE: 1022 Geary St.



THE PLUGOSCILLATOR

Patents pending in U.S. and other countries. Made under British patent No. 13815 of 1915; under French patent SGDG 480,546.

FAIRBANKS, MORSE & CO.

(INCORPORATED)

Chicago, Ill. St. Louis, Mo. Cleveland, Ohio Cincinnati, Ohio Atlanta, Ga. Jacksonville, Fla. New Orleans, La. Milwaukee, Wis.

New York, N. Y. Boston, Mass. Baltimore, Md. Louisville, Ky. Detroit, Mich. Indianapolis, Ind.

St. Paul, Minn. Minneapolis, Minn. Kansas City, Mo. Omaha, Neb. Des Moines, Ia. Denver, Colo. Buenos Aires

San Francisco, Cal. Los Angeles, Cal. Spokane, Wash. Seattle, Wash. Portland, Oregon Salt Lake City, Utah London

The Canadian Fairbanks-Morse Co., Limited

Vancouver

Hamilton

Victoria

Montreal Toronto Calgary Ottawa St. John N. B. Winnipeg Saskatoon Quebec Edmonton





Fig. 1.

PLUGOSCILLATOR AND MAGNETO

METHOD OF TIMING SUMTER PLUGOSCILLATOR WITH FAIRBANKS-MORSE 10 and 15 H. P. TYPE "Z" ENGINES

All Sumter Plugoscillators are timed and tested on the engines at the factory and the timing is again checked just before the engines are shipped. It is well, however, to check over the timing from time to time with the engine crank. This can readily be done by turning the "Early and Late" pin(A) so that the letter (E) (indicating the early position) is up, and then turn the flywheels in the direction they run until the Plugoscillator snaps. The spark mark on the governor flywheel should coincide with the exhaust rod at this time.



Note angle of lever for setting or hand firing.


Fig. 2.

Page 3, No. 2402B

If for any reason the Plugoscillator should need adjusting proceed as follows:


It is first necessary to determine if the spring angle (M) is correct. In order to check this up cock the Plugoscillator with the setting and hand firing lever (N) (as shown in Fig. 2). Then loosen the lock nut (O) and adjust the screw (P) so that the pawl (D) just touches the pawl (F) slightly thus loosening the lever (N) before it snaps. Be sure that the lock nut (O) is again tightened. The "Early and Late" pin should of course be in the early position (Letter E up) when the Plugoscillator is being timed.

Next, time the break of the Plugoscillator with the engine crank. To accomplish this set the flywheels so that the "spark" mark on the wheel coincides with the exhaust rod when the piston is on the compression stroke. Loosen the clamp screw (R) and a similar screw on the gear end of operating rod and adjust the operating rod until the Plugoscillator just snaps. Then tighten both clamp screws and the Plugoscillator is correctly timed.



TO REMOVE AND TEST PLUGOSCILLATOR


In order to remove the entire electrical apparatus from the engine it is only necessary to remove the nut (T) Fig. 3, and lightly drive a small chisel or screw driver between the bracket and cylinder to loosen the taper fit in the cylinder. The outfit can then be removed cleaned and tested by tripping it with the hand firing lever (N). If a fat spark is not shown when magneto is connected, carefully look over the wiring; see that all contacts are tight; that the movable electrode is not sticking; that the contact points are clean and that the distance between the boss "H" on the moveable electrode arm and the trip-and-break lever "F" is just the thickness of the hand firing lever



shown as "N" in Fig. 2. This adjustment is clearly shown in Fig. 4, where the firing lever "N" has been slipped in between the boss "H" and the lever "F." If this distance is not just the thickness of the firing lever, adjustment may be made by loosening the screw "S," Fig. 3, and changing the position of the movable electrode arm on the movable electrode shaft. When the correct adjustment has been made, be sure to tighten the screw "S."

CLEANING PLUGOSCILLATOR

The Plugoscillator should be removed occasionally, (about once a week), and cleaned, carbon brushed from electrodes and carbon scraped off the end. Page 4, No. 2402B



The Electrode Points can be cleaned without removing the Plugoscillator from Engine by sliding the Movable Electrode back and forth from the outside.


INSTALLATION OF BATTERIES AND COIL

If by any means the magneto is damaged it can be removed from the bracket by removing two cap screws, as shown in Fig. 5.

A battery and coil can be attached and the engine kept in service, while

the magneto can be returned to its maker for repairs.

With the plugoscillator, when magneto is used, the points are normally closed. When battery is used, it will be necessary to adjust the position of the movable electrode arm in relation to the trip-and-break-lever "F," so that the contact points will be open excepting for a very short interval, just preceeding the instant when the spark occurs. This is in order to save the life of the battery. With the plugoscillator in its neutral position, Fig. 3, loosen the screw "S" and allow the boss "H" on the moveable electrode arm to come in contact with the



lever "F." Then force it down just a little further. This should open the ignitor points slightly. This can be tested by the following method: Attach battery and coil in the regular manner by grounding one battery terminal on the engine frame. Be sure that the wire leading from the magneto to the stationary electrode "C" has been removed; then tap the end of the wire leading from the battery, lightly on "C" and if the plugoscillator is in the neutral position, no spark should be produced. If a spark occurs, the points are still closed and the movable electrode arm should be adjusted downward just a trifle more. Then cock the plugoscillator with the hand firing lever "N" and again tap the stationary electrode with the battery wire. A spark should occur with the outfit in this position. It is very important that the wire leading from the magneto to the stationary electrode "C" be removed before you attach the battery wire to any part of the plugoscillator.

STARTING ENGINE

There are two methods by which the Type "Z" engines can be readily started with the Sumter Plugoscillator.

First Method

- 1st. See that the engine is ready to start as covered by the instructions sent with the engine.
- 2nd. Set the "Early and Late" pin (A) so that the letter "L" is up (indicating the late position).
- 3rd. Prime engine in the regular manner.
- 4th. Turn engine flywheels in the direction they run and when the Plugoscillator snaps the first impulse will occur. The next charge will be drawn from the fuel reservoir in the regular manner.
- 5th. Set the "Early and Late" pin so that the letter "E" is up.
- 6th. Make other adjustments according to the regular engine instruction

Page 5, No. 2402B

Second Method

1st. See that the engine is ready to start as covered by the instructions sent with the engine.

2nd. Set the "Early and Late" pin (A) so that the letter "E" is up.

3rd. Cock Plugoscillator with the hand firing lever (N) always in the direction as shown in Figs. 2 and 7, and prime the engine in the regular manner.

4th. Turn the engine flywheels backward as strongly as possible, compressing the mixture and at the same moment when the flywheels are stopped by the compression, trip the Plugos-cillator by pushing the lever (N) towards the flywheel. A very strong explosion will result if a good mixture and considerable compres-

sion have been obtained.

This method requires more skill than the other method and there is danger of injury if one does not let go of the flywheels just before tripping the Plugoscillator.

5th. After the first explosion is obtained proceed exactly as covered by the preceding method.



Fig. 7.

THE FOLLOWING POINTS ARE IMPORTANT AND SHOULD BE CLOSELY OBSERVED

Carefully Note-

1. That the spring roller and Pawl fulcrum Pins are oiled daily.

2. That the magneto bearings receive a drop or two of fresh light oil every day—Avoid heavy cylinder oil, etc.

3. That Plugoscillator is kept clean.

4. That movable electrode works freely.

5. That screw on movable electrode arm is kept tight.

3. That wire terminals are tight.

7. That timing is correct.

8. That Plugoscillator is clamped tightly into cylinder.

9. That magneto is not taken apart.

10. That Pawl for the operating arm works freely.

11. That instructions are carefully read before making adjustment.

12. That there are other things that will cause the engine to miss as well as the magneto.

WHY THE PLUGOSCILLATOR EQUIPMENT IS BEST

The following points are facts, and a careful comparison of the Sumter with other makes that our competitors may offer, will prove our statements.

First: Sumter Plugoscillators and Magnetos are fully warranted and guaranteed against defective material and workmanship. When repairs are necessary as result of accident or ordinary wear-and-tear, attention is directed to the chain of Service Stations as listed on back cover.

Second: The magnetos are equipped with magnets of the highest grade steel, carefully aged, and made in the Sumter plant. The pole pieces are machined all over from special




Fig. 8.

Page 6, No. 2402B.

iron; the armature has laminated core for the winding, whereas most other makes use a solid core, which is not efficient. The winding is an enamel and cotton-covered wire, wound by hand; and the shafts are ground to fit the bearings.

Third: The bearings are solid bronze, provided with spiral oil grooves and drain holes. The ground brush is placed where wear is reduced to a minimum, and the collector brush supported in imported porcelain, which is instantly removable for cleaning. This brush runs on a hardened steel end in the armature shaft. See Figs. 10 and 11.

Fourth: Sumter Magnetos are dust-, oil-, and water-proof, and can be used on portables exposed to the weather. Neither heat nor cold affects their effective output.

Fifth: Workmanship in Sumter Magnetos is of the finest, a fact which will be realized when it is noted that they are selected by the largest manufacturers of stationary engines, whose engineers are in a position to test all makes, and who naturally want the very best ignition, so that the reputation and performance of the engine will not suffer.

Sixth: Sumter Magnetos are made in a factory which devotes itself exclusively to the manufacture of Magnetos for stationary engine service, and the Sumter factory is the largest of its kind in the world; and therefore the Magneto is backed by a responsible corporation, having a perfect manufacturing and service organization.




Fig. 9.

In the Sumter Armature Assembly the center "G" Fig. 8, is made from punching "Z" of a special grade of iron. These are threaded on two long bolts, which screw into the endpiece "F." The reason for making this part of the armature on which the wire is wound laminated instead of one solid piece (which would be much cheaper), is to reduce current losses to a minimum. This extra efficiency is particularly valuable when starting an engine, where all the reserve power of the magneto is necessary. A solid armature cannot compare with the laminated, owing to the greater internal losses; this is a fundamental fact, readily verified by reference to any text book on the design of electrical apparatus.

The core of the armature being laminated, is of the highest electrical efficiency, and superior in this respect to an armature in which a steel shaft passes all the way through. The Sumter armature has brass heads, and the shafts have square ends, and are pressed in these heads, and then ground to fit the bearings. In the No. 30 machine these heads are reinforced so as to relieve all strain from the screws (M).

With some types of magnetos, it is impossible to determine whether the magneto is at fault or not, owing to its being so inefficient as not to produce any noticeable current when revolved by hand, whereas with the Plugoscillator its maximum efficiency may be tested by hand.

Hand firing, originally patented and introduced by SUMTER, has been applied to the Plugoscillator in a most simple and effective manner. The hand lever operates the mechanism same as the engine push rod, thereby producing a spark enabling the engine to be started from a standstill, provided the necessary compressed charge is in the cylinder.

Provision is made for properly lubricating all working parts, and, as there is less side thrust, less care in this connection is necessary than with other types.




Fig. 10.

The sectional view (Fig. 10), will give some idea of the construction of the magneto. The magnets are made from high-grade steel, and are carefully aged. The pole pieces are machined all over from special iron.

The winding is of enamel- and cotton-covered wire, covered with an oil and waterproof tape, and varnished. The wire is wound in smooth layers, carefully insulated, and permanently free from short circuits, burnouts, etc.

The end plates are of genuine bronze, with the bearings integral, the same being provided with Osgood spiral oil grooves. There are drain holes in the end plate for carrying off the surplus oil, and if a good grade of light oil is used the machine will not gum up.

The ground brush, it will be noted, eliminates the necessity of the bearings having to conduct the current out of the armature, which is the case in machines in which no ground brush is provided.


Page 8, No. 2402B

The igniter equipment is worthy of special mention. The movable electrode is a heavy drop forging. The insulated electrode is N. G. E. A. Standard, see Fig. 12, and can be taken out and replaced in a moment's time without disassembling the mica insulation from around the stem. We claim this is the most efficient and durable electrode known, as it will stand a high tension spark without break down—a test which few electrodes in make and break igniters will withstand.

All wearing parts are of high carbon steel, carefully hardened. The construction permits of a large heavy bearing for the trip lever, and all thrust is taken by this bearing, supported by a heavy web in the bracket casting. In other designs, the thrust and wear is taken by the magneto shaft.

It should be noted that the Plugoscillator bracket carries ALL the actuating mechanism for both magneto and igniter. See Fig. 7. The vanadium steel actuating springs are mounted on the bracket, and carried on easily replaceable hardened rollers.

As a standard magneto is used, all well known methods of testing same, by revolving the armature by hand in case of suspected trouble, can be applied.



The terminal brush is carried in solid porcelain insulation and the connection between the brush and terminal is soldered. This brush runs on a hardened steel end in the armature shaft, which eliminates all copper rings and other parts that wear or require cleaning.

The Pawl or Trip Lever, engaged by the engine push rod, is also mounted on this bracket, and has an independent bearing. There is no tendency for the arm to lift the magneto off the bracket, as in other types, and no side thrust on any part of the magneto, he armature receiving only a true radial impulse. The necessity for a solid armature shaft, which is admittedly inefficient, is removed, as the heavy actuating springs or trip lever are not attached to the shaft. One piece shafts may be necessary where the armature shaft carries the strain of the oscillating springs on one end and trip lever on the other; in otherwords, where the magneto carries the operating mechanism. The Plugoscillator eliminates this condition.

The insulation throughout is of the very highest quality, same being oil, heat- and moisture-proof. There is no exposed fiber or rubber insulation.

From the foregoing, it will be seen that every precaution is taken to insure the Magneto giving long and satisfactory service. Every screw is locked in place, and the construction is such that the machine will run for years without any attention beyond oiling. This being the case, it is useless to tear up the Magneto in case of trouble.




Fig 12.

SUMTER PLUGOSCILLATOR PARTS

Part No.	Part Name	Price
CA-100	Plugoscillator without magneto	\$ 8.00
CA-101	Igniter and Bracket, body only	4.00
CA—102	Trip and Break Lever	2.50
CA-103	Trip and Break Lever Fulcrum Pin	20
CA-104	Magneto crank arm	1.00
CA-105	Moveable Electrode and Point	1.00
CA—106	Moveable Electrode Arm	
CA-107	Spring roller pin—long (upper pin)	25
CA-108	Spring roller pin—short (lower pin)	
CA-109	Spring roller (each)	15
CA-110	Trip and break lever spring (each)	20
CA—111	Starting lever	15
CA-112	Moveable Electrode seating spring	20
CA-113	Moveable electrode arm spring	20
CA—114	Moveable electrode arm fastening screw	10
CA—115	Magneto Crank fastening screw	10
CA—118	Stationary Electrode (Standard N. G. E. A. No. 4)	
CA-122	Spring roller stud spring ring	
CA—128	Magneto only, JR No. 30	12.00
CA—129	Magneto fastening screw washer (each)	05
CA—130	Magneto terminal	25
CA—131	Magneto fastening screw (each)	1.05
CA—137	Igniter Points (each)	

Page 10, No. 2402B




Fig. 13.

JR. No. 30 MAGNETO PARTS LIST

Part No.	Name of Part	Price
20004—Terminal end p	late	\$2.00
20006—Drive end plate		2.00
	sher	
20016—Porcelain bushin	ng	
	(each)	
	each)	
	ninal	
20022—Magnet		2.50
20025—Armature assem	bly	3.50
20031—Frame assembly	7	3.00
	er set)	
20040-Magnet clamp ((each)	
20041—End plate screw	s (per set)	
20042—Assembly of por	celain bushing complete terminal,	etc., with nuts
and brush	, , , , , , , , , , , , , , , , , , , ,	
	(per set of 3)	
20047—Lock washer for	r shaft	.05
	aft	
20050 05 Oil 1 1	No. 1	.05
20055 Magnet clamp	er and pin	.10
20064—Porcelain clamp	crew (per set of 4)screw	
20067—Magnet hand	SCIEW	.05
and the state of t		

Prices subject to change without notice. Always mention number of this bulletin when ordering repairs.

Page 11, No. 2402B